


Dimensions



13 14 15 16 9 10 11 12	1 2 3 4 5 6 7 8	22.6
	99	

Model Number

SB4 Module 4XP


Safety control unit module Module for Evaluation unit SafeBox - series SB4

Features

- Sensor module
- 4 sensor channels
- Micro-Controller controls
- Operating mode can be selected by means of DIP switches
- Individual module for SLA5(S), SLA20, SLA25, SLA28 and SLA40 security through-beam sensors; for SLP safety light grids, for SLC safety light curtains; for switching pads and emergency stop buttons of categories 2 or 4
- Screw terminals or spring terminals

Electrical connection

0000	Terminal	Function	Channel classification	Connection Beam sensor / Light grid safety feature	Connection 2-channel p ON	Connection Switching pad
13 14 15 16	1	Receiver 2 Input	Input	Receiver output 2	OSSD Output 1.2	Switching pad 1.4
9 10 11 12 -XFR4	2	Sensor 2 24 V DC +U	Channel 2	24 V Receiver2	24 V Power supply 1	
12-H4 23-R3	3	Sensor 2 Mass GND		0 V Receiver 2, Emitter 2	0 V Power supply 1	
‡ R2	4	Emitter 2 Output	Output	Emitter input 2		Switching pad 1.3
‡‡-R1	5	Receiver 1 Input	Input	Receiver output 1	OSSD Output 1.1	Switching pad 1.2
1 2 3 4 5 6 7 8	6	Sensor 1 24 V DC +U	Channel 1	24 V Receiver 1		
0000	7	Sensor 1 Mass GND		0 V Receiver 1, Emitter 1		
0000	8	Emitter 1 Output	Output	Emitter input 1		Switching pad 1.1
	9	Emitter 3 Output	Output	Emitter input 3		Switching pad 2.4
	10	Sensor 3 Mass GND	Channel 3	0 V Receiver 3, Emitter 3	0 V Power supply 2	
	11	Sensor 3 24 V DC +U		24 V Receiver 3	24 V Power supply 2	
	12	Receiver 3 Input	Input	Receiver output 3	OSSD Output 2.2	Switching pad 2.3
	13	Emitter 4 Output	Output	Emitter input 2		Switching pad 2.2
	14	Sensor 4 Mass GND	Channel 4	0 V Receiver 4, Emitter 4		
	15	Sensor 4 24 V DC +U		24 V Receiver 4		
	16	Receiver 4 Input	Input	Receiver output 4	OSSD Output 2.1	Switching pad 2.1



Technical data

Functional s	afety	related	parameters
--------------	-------	---------	------------

Safety Integrity Level (SIL)	SIL 3
Performance level (PL)	PL e
Category	Cat. 4
Mission Time (T _M)	20 a
Type	4

Indicators/operating means

Function display LED yellow (4x): indicator lamp channel 1 ... 4 LED yellow flashing: Indicator lamp channel 1 ... 4 Pre-fault indication Controls DIP-switch

Electrical specifications

24 V DC \pm 20 % , via SB4 Housing Operating voltage

Input

Actuating voltage approx. 10 V Activation current approx. 4 ... 20 mA

Ambient conditions

0 ... 50 °C (32 ... 122 °F) Ambient temperature -20 ... 70 °C (-4 ... 158 °F) Storage temperature

Mechanical specifications

Protection degree

screw terminals , lead cross section 0.2 ... 2 \mbox{mm}^2 Connection

Copyright Pepperl+Fuchs

Singapore: +65 6779 9091

fa-info@sg.pepperl-fuchs.com

Option /165: Cage tension spring terminals , Cable cross-section 0.2 \dots Material

Polyamide (PA) Housing Mass approx. 150 g

General information

www.pepperl-fuchs.com

Ordering information	without Option /165 -> with screw terminals with Option /165 -> spring clamp terminals
Compliance with standards and directives	ti-
Standard conformity	(extract)
Standards	EN IEC 61496-1 EN IEC 61508 EN ISO 13849-1
Approvals and certificates	
SIL classification	up to SIL3 acc. to IEC 61508 tested and certified by TÜV SÜD according to: IEC 61508:1998 part 1, 3.4 IEC 61508: 2000 ISO 13849-1:2006 EN 50178:1997 IEC 61496-1:2004 IEC 61496-2:2006
UL approval	cULus
TÜV approval	τΰν

This module can only be operated within an evaluation device of the SafeBox SB4 type.

The operating instructions of the SafeBox must be observed.

Function

The 4-channel sensor module -4X* makes possible the connection of the so-called "3-wire" light barriers of the SLA family (for example SLA5) and light grids of type SLP. But also p-switching safety devices with dedicated cross circuit monitoring can be connected, for example safety light curtains from the SLC family. In addition switch-off mats of the 4-wire principle or integrated safety sensors in the 1 or 2 channel version can be connected.

It also contains the microcontroller control of the SafeBox. This module exists only once in a SafeBox SB4 and has to be mounted on position 2.

The module is equipped with a plug-in jumper. If the system features additional components, this plug-in jumper has to be mounted on the last mounting station.

In the assembly is also found a six-way DIP switch with which the sensors to be connected are selected. 2 switches must be activated as a pair for selection. The connection of the safety sensors is done on channels 1 and 2 or 3 and 4.

"3-wire" light barriers and light grids of the SLA and SLP families can be connected to channels 1 to 4.

The cable or the manner it is laid to the light barriers and light grids must be chosen that no short circuit between the receiver and transmitter wires is possible.

Light curtains with semiconductor switch outputs and integrated safety sensors in 2 channel design are monitored for simultaneousness. During simultaneousness monitoring the 2 channel safety devices are monitored for simultaneous opening or changing of the signals. The monitoring time is 2 s.

The connection is done on channels 3 and 4 and/or 1 and 2.

It is necessary that these sensors must have a dedicated cross circuit monitoring, since the module does not perform cross circuit monitoring with these sensors.

Integrated safety sensors, which are connected to the Safebox must work according to the normally closed principle. An open contact means "safe status".

Switch-off mats of the 4-wire principle can be connected to channels 1 and 2 and/or 3 and 4. If there is a faulty contact of the switch-off mat, the system reports Error 9 or Error 8, like the detection of an integrated safety sensor in the two-channel design.

Operating modes

The assembly contains 6 DIP switches for selecting the sensor types and the position. Six possibilities are offered for combining sensors. The desired combination is to be set binary. For function selection, always 2 switches must be actuated, that means DIP switches 1 - 3 have the same switch position as DIP switches 4 - 6.

Germany: +49 621 776-4411


fa-info@pepperl-fuchs.com

	DIP switch			Operating mode
Ī	3 and 6	2 and 5	1 and 4	Operating mode
ſ	0	0	0	SLA /SLP/ bridge channel 1 + 2 and channel 3 + 4
	0	0	1	SLA / SLP / jumper to channel 1 + 2 and SLC channel 3 + 4



0	1	0	SLC channel 1 + 2 and channel 3 + 4
0	1	1	SLA / SLP / jumper channel 1 + 2 and safety mat channel 3 + 4
1	0	0	Safety mat channel 1 + 2 and channel 3 + 4
1	0	1	SLC channel 1 + 2 and safety mat channel 3 + 4

Position of the DIP switches



Displays


There is a yellow LED for each channel on the front plate of the module which displays the status of the input channel.

Display	LED	Meaning
R1 - R4 (R1 - R6)	yellow	Status sensor input 1 - 4 OFF: interrupted ON: released Flashing: light beam released, function reserve fallen short of (frequency approx. 2.5 Hz) Flashing rapidly: error (frequency approx. 5 Hz)


Connections

Connections are designed as removable screw terminals. The terminal assignment can be found in the adjoining table.

Up to 4 light barriers or 2 two-channel p-switching safety devices or 2 switch-off mats can be connected to the 4-channel sensor module. Unused channels must be deactivated by means of a bridge between transmitter output and receiver input.



fa-info@us.pepperl-fuchs.com



www.pepperl-fuchs.com