



Technical specifications and mounting description Equiflow PVDF-X Turbine Flowmeters


Process specifications	Models	
	0045	0085
Flowrange (L/min)		
Minimum:	0,03	0,5
Start linear*:	0,10	1,0
Maximum:	2,00	20,0
Wetted parts	PVDF and ruby	
Process connections	¼" BSP	¾" BSP
Maximum temperature (°C / °F)	80 / 176	
Maximum pressure (bar)	25	20
Viscosity (cSt)	0,8 - 10	
Approximate K-factor (pulses/L)	100.000	4.800
Recommended filter pore size (µm)	100	100

*The linear range (from the start linear up to the maximum flowrate) is the flowrange where the K-factor is almost independent of the flowrate

Recommendations for using Equiflow flowmeters

- Check flow direction (arrow on the housing/tubeholder), fluid going in the opposite direction will not generate an output signal.
- Install a suitable filter in front of the sensor (see table for recommended pore size).
- De-aerate the system with a gentle flow before starting the system.
- Check for leakages after starting the system.
- Never clean the flowtube with compressed air.
- Check chemical resistance of the wetted parts before use.
- Only the wetted parts of the flowmeter should come in contact with liquids. Avoid liquid from reaching the sensor's electronics.

Electrical specifications and sensor connections



Technical specifications and mounting description Equlflow PVDF-X Turbine Flowmeters

Process specifications		Models	
		0045	0085
Flowrange (L/min)	Minimum:	0,03	0,5
	Start linear*:	0,10	1,0
	Maximum:	2,00	20,0
Wetted parts		PVDF and ruby	
Process connections		¼" BSP	¾" BSP
Maximum temperature (°C / °F)		80 / 176	
Maximum pressure (bar)		25	20
Viscosity (cSt)		0,8 - 10	
Approximate K-factor (pulses/L)		100.000	4.800
Recommended filter pore size (µm)		100	100

*The linear range (from the start linear up to the maximum flowrate) is the flowrange where the K-factor is almost independent of the flowrate

Recommendations for using Equlflow flowmeters

- Check flow direction (arrow on the housing/tubeholder), fluid going in the opposite direction will not generate an output signal.
- Install a suitable filter in front of the sensor (see table for recommended pore size).
- De-aerate the system with a gentle flow before starting the system.
- Check for leakages after starting the system.
- Never clean the flowtube with compressed air.
- Check chemical resistance of the wetted parts before use.
- Only the wetted parts of the flowmeter should come in contact with liquids. Avoid liquid from reaching the sensor's electronics.

Electrical specifications and sensor connections

