


Grove Vision AI Module



Get One Now 

Introduction

Grove Vision AI Module Sensor represents a thumb-sized AI camera, customized sensor which has been already installed ML algorithm for people detection, and other customized models. Being easily deployed and displayed within minutes, it works under ultra-low power model, and provides two ways of signal transmission and multiple onboard modules, all of which make it perfect for getting started with AI-powered camera.

In this wiki, we will show you how to utilize the Grove Vision AI module Sensor connecting seed studio XIAO Series and Arduino, to detect people, panda, and then display it on the website.

Specification

Parameters	Description	Note
Connector	Grove (Grove base for Arduino)	5V Charge and Data Transmission
	Double row 7pin socket (seed duino XIAO)	5V Charge and Data Transmission
	USB Type-C	5V Charge and Firmware burn
Communication Mode	IIC	

Parameters	Description	Note
Processor	Himax HX6537-A	400Mhz DSP (ultra low power consumption)
Camera Sensor	OV2640 chip	Resolution Ratio 1600*1200
Microphone	MSM261D3526H1CPM chip	-26dBfs sensitivity
Accelerometer Sensor	STLSM6DS3TR-C Sensor	3D accelerometer and 3D gyroscope

Feature

- Easy-to-use AI Camera: Apply Edge Machine Learning algorithm in the camera sensor perfectly for detecting objects
- Plug and Play: Make toilsless effort to perform full function and display within minutes
- Ultra-low Power consumption: Activate while detected objects moving for power saving
- Compact AI-powered Camera Sensor: The device itself is thumb-sized, vision-based, and suitable for Edge Intelligence
- Customized Sensor Design: Support custom ML models by users define

- Two Signal Transmission Supported: Refer to seeed studio XIAO elegant connecting and Grove base for Arduino simple connection
- Onboard Camera Sensor: Corporate OV2640 chip with 1600*1200 resolution ratio
- Onboard Microphone: Corporate MSM261D3526H1CPM chip with -26dBfs sensitivity
- Onboard Accelerometer Sensor: Corporate STLSM6DS3TR-C sensor for 3D accelerometer and 3D gyroscope detected
- Onboard 32 MB SPI Ultra Low Power Flash
- One wire for all data output: Represent Grove family simplified connection for only one Grove cable required between the sensor and the single board


Hardware Overview

We assume you might want to be aware of some basic parameters of the product. The following tables present information about the characteristics and pinout of Grove Vision AI Module Sensor.

Characteristic	Value	Unit
Operating Voltage	5	V
Rate	115200	


Characteristic	Value	Unit
I2C Interface	seeed studio XIAO & Arduino	-
Power Supply	dual 7-pin connector & Type-C	-
Downloading & Firmware Burn Interface	Type-C	-
Dimensions	402013	mm

Pinout Overview



- 2 — BL702
- 3 — MIC MSM261D3526H1CPM

- 4 — 6-axis LSM6DS3TR-C
- 5 — SPI Flash
- 9 — USB type C
- 10 — Dual 7-pin female socket
- 11 — **Reset button**
- 12 — **BOOT button**
- 13 — **USER button**



- 1 — HX6537-A
- 6 — Camera Connector
- 7 — DC-DC Chip
- 8 — Grove Connector

- 14 — Power Light
- 15 — Burning indicator light

Getting Started

We will show you the basic function about the module, and then introduce you the customized way that you can build the ML model of your own. But before we fully apply the module to our projects, it will take us several steps to get the module ready.

Preparation

Hardware

- Grove Vision AI Module Sensor
- **Windows host** PC (Win10 tested)
- Type-C cable

Arduino Library Overview



If this is your first time using Arduino, we highly recommend you to refer to [Getting Started with Arduino](#).

The code we use here provides several methods of classification and selectable models, including customized models. The default we select here is object detection method and pre-trained model.

Seed Studio will develop more methods and models for the foreseeable future, stay tuned with us.

Download the Libraries 

Function

Before we get started developing a sketch, let's look at the available functions of the library.

1. `if (ai.begin(ALGO_OBJECT_DETECTION, MODEL_EXT_INDEX_1))` - This is where we can select our methods of classification and the models.

You can change `ALGO_OBJECT_DETECTION` to `ALGO_OBJECT_COUNT` or `ALGO_IMAGE_CLASSIFICATION`.

Meanwhile, if you also burn your customized model(firmware) into the module, you can change `MODEL_EXT_INDEX_1` to `MODEL_EXT_INDEX_2` or 3, 4, as you named it.

2. `object_detection_t data` - This is the struct dataset where the result output.

If you change the classification method, you need to change `object_detection_t` correspondingly to `image_classification_t` or `object_count_t`.

3. `uint8_t len = ai.get_result_len()` - The "len" here means how many human face it detects.
4. `object_detection_t data` - The data here represent a **struct** format and the tpye is "object_detection_t" that is pre-defined.

Meanwhile, if you choose other methods of classification, you need to change it to `image_classification_t data` or `object_count_t data`.

5. `Serial.print(data.confidence)` - The **struct** format can not be directly used to print, it should point to the specific type which is defined in the head file.

```
typedef struct
{
    uint16_t x;
    uint16_t y;
    uint16_t w;
    uint16_t h;
    uint8_t confidence;
    uint8_t target;
} object_detection_t;
```




TIP

The "confidence" we want to print here shows how much "confidence" the camera has to detect the object.

Library Installation


Since we have downloaded the zip Library, open your Arduino IDE, click on **Sketch > Include Library > Add .ZIP Library**. Choose the zip file you just downloaded, and if the library install correct, you will see **Library added to your libraries** in the notice window. Which means the library is installed successfully.



Library Upgrading

In the foreseeable future, we will optimize and upgrade the product library for more interesting function. According to the library installation methods provided above, we here introduce you the way to upgrade.

We will update the link when the library is optimized. You can **delete the original library folder** in your computer's folder, then download the latest version, unzip it and put it in the Arduino IDE library directory. (...\\Arduino\\libraries. is the path you setup Arduino)



Seed Studio XIAO / Seeduino / Arduino Example

Now that we have our library installed and the firmware burned, we can now run some examples with Grove AI module sensor on Seed Studio XIAO nRF52840 and Seeduino V4.2 to see how it behaves.

Step 1. Launch the Arduino application.

```
sketch_mar18a | Arduino 1.8.18
sketch_mar18a
1 void setup() {
2   // put your setup code here, to run once:
3
4 }
5
6 void loop() {
7   // put your main code here, to run repeatedly:
8
9 }
1
Arduino Yún 在 /dev/cu.usbmodem113401
```

Step 2. Select your development board model and add it to the Arduino IDE.

- If you want to use **Seeeduno** for the later routines, please refer to [this tutorial](#) to finish adding.
- If you want to use **Seeed Studio XIAO SAMD21** for the later routines, please refer to [this tutorial](#) to finish adding.

- If you want to use **Seed Studio XIAO RP2040** for the later routines, please refer to [this tutorial](#) to finish adding.
- If you want to use **Seed Studio XIAO nRF52840** for the later routines, please refer to [this tutorial](#) to finish adding.

Demo 1 Human Detection with Seed Studio XIAO nRF52840 / Seeeduino / Arduino

In this demo, we will detect human face and count how many people the module detects on both [Seed Studio XIAO nRF52840 Sense](#) and Seeeduino V4.2 (Arduino UNO). Meanwhile, Seed Studio provides a [website](#) to display what the module sees.

Materials Required


- **For seed studio XIAO BLE Sense**

Seeed Studio XIAO nRF52840 Sense



Get One Now 

Grove AI Camera




Get One Now 

- For Seeeduino V4.2


Seeeduino V4.2



Base Shield



Grove AI Camera



Get One Now 


Get One Now 

Get One Now 


Operation Steps

- **Step 3 (Seed Studio XIAO).** Prepare a Type-C cable and connect it to one seed studio XIAO Series board. Plug it pin by pin into the Grove AI Module and use another Type-C cable to connect the module.

Both Type-C cable should be connected with the PC. In the end, the direction of the Type-C connector on the module should be the same as Type-C connector on the seed studio XIAO samd21. For instance:



- **Step 3 (Arduino).** Prepare a Grove cable and connect it to one Arduino board. Use another Type-C cable to connect the module.



- **Step 4.** Upload the program.

```
#include "Seed_Arduino_GroveAI.h"  
#include <Wire.h>  
  
GroveAI ai(Wire);  
uint8_t state = 0;  
void setup()
```

```
{
  Wire.begin();
  Serial.begin(115200);

  Serial.println("begin");
  if (ai.begin(ALGO_OBJECT_DETECTION, (MODEL_INDEX_T)0x11)) // Object detection and pre-
trained model 1
  {
    Serial.print("Version: ");
    Serial.println(ai.version());
    Serial.print("ID: ");
    Serial.println( ai.id());
    Serial.print("Algo: ");
    Serial.println( ai.algo());
    Serial.print("Model: ");
    Serial.println(ai.model());
    Serial.print("Confidence: ");
    Serial.println(ai.confidence());
    state = 1;
  }
  else
  {
    Serial.println("Algo begin failed.");
  }
}

void loop()
{
```

```
if (state == 1)
{
  uint32_t tick = millis();
  if (ai.invoke()) // begin invoke
  {
    while (1) // wait for invoking finished
    {
      CMD_STATE_T ret = ai.state();
      if (ret == CMD_STATE_IDLE)
      {
        break;
      }
      delay(20);
    }

    uint8_t len = ai.get_result_len(); // receive how many people detect
    if(len)
    {
      int time1 = millis() - tick;
      Serial.print("Time consuming: ");
      Serial.println(time1);
      Serial.print("Number of people: ");
      Serial.println(len);
      object_detection_t data; //get data

      for (int i = 0; i < len; i++)
      {
        Serial.println("result:detected");
      }
    }
  }
}
```

```
Serial.print("Detecting and calculating: ");
Serial.println(i+1);
ai.get_result(i, (uint8_t*)&data, sizeof(object_detection_t)); //get result

Serial.print("confidence:");
Serial.print(data.confidence);
Serial.println();
    }
}
else
{
    Serial.println("No identification");
}
}
else
{
    delay(1000);
    Serial.println("Invoke Failed.");
}
}
else
{
    state == 0;
}
}
```

Open the serial monitor and set baud rate as 115200 and the result of people detection should be showed continuously. Meanwhile, the image that is captured by the module also will display on the [website](#). The successful ongoing output should be like:



```
Invoke Success: 960
people: 0
Invoke Success: 1004
people: 1
result:detected
Detecting and calculating: 1
confidence:75
Invoke Success: 960
people: 2
result:detected
Detecting and calculating: 1
confidence:75
result:detected
Detecting and calculating: 2
confidence:50
```

Autoscroll Show timestamp

On the display [website](#), you can see that two faces are framed with dual number. Number 0 means the human face that module detected, and the other number means the confidence.

i NOTE

Not all browsers support the display of Vision AI results. Please refer to the table below for the support of each major browser.

Chrome	Edge	Firefox	Opera	Safari
Support	Support	Not support	Support	Not support

About Models

The Seeed Studio has provided pre-trained people detected model and will provide more models in the foreseeable future. You can directly use them to quickly get to know AI camera.

You can find our firmware and models for Grove Vision AI at the following locations.


[Download the Model](#) 

Default Firmware: People Detected Model

2 hours ago

 LynnL4

 v1.1.0

 cb0a442

Compare ▾

Release v1.1.0 Latest



update readme.

▼ Assets 10

 grove_ai_capture_firmware_v01-00.uf2	1.47 MB	2 hours ago
 grove_ai_v01-30.uf2	1.37 MB	2 hours ago
 grove_ai_without_crc_v01-30.uf2	1.37 MB	2 hours ago
 person_detection_pre_17.uf2	1.43 MB	2 hours ago
 sensecap_ai_capture_firmware_v01-00.uf2	1.48 MB	2 hours ago
 sensecap_ai_v01-30.uf2	1.38 MB	2 hours ago
 tinyuf2-grove_vision_ai_v2.0.0.bin	91.3 KB	2 hours ago
 tinyuf2-sensecap_vision_ai_v2.0.0.bin	91.3 KB	2 hours ago
 Source code (zip)		3 hours ago
 Source code (tar.gz)		3 hours ago



More Models

Release v2.0.0 Latest



New Features:

- Introducing AT Server Support: Now you can take advantage of AT Server, which offers a comprehensive set of commands with functionality on par with I2C Server.
- Enhanced Algorithm Capabilities: Added support for pointer-based tables and numerical table calculations to further enhance your workflow.

Bug Fixes:

- Resolved Error Code Mishap: Fixed an issue where incorrect error codes were displayed when retrieving storage models, ensuring accurate error identification.
- Centered Grove Vision AI Display: Addressed the problem of the Grove Vision AI screen not being properly centered, resulting in a more visually appealing user experience.

▼ Assets 9

erase_model.uf2	37.5 KB	last month
grove_ai_v02-00.uf2	1.47 MB	last month
meter_seg7_pre_6.uf2	1.61 MB	last month
meter_water_pre_6.uf2	1.61 MB	Aug 2
person_detection_pre_17.uf2	1.43 MB	Aug 2
pfld_meter_pre_5.uf2	470 KB	Aug 2
sensecap_ai_v02-00.uf2	1.48 MB	last month
Source code (zip)		Apr 28



We are continuously maintaining and updating more useful models, so you can keep an eye on this repository.



TIP

Typically, model files are in **UF2** format and have a suffix in the format **pre_num**.

Custom Models

If you want to customize your own model, you can refer to [here](#) which is powered by YOLOV5.

Or refer to [the tutorial here](#) and train your own model to suit your needs.


Replacement of new models

The training models are all represented as ".uf2" file, which is what we need.


 TIP

Typically, model files are in **UF2** format and have a suffix in the format **pre_num**.

- **Step 1.** Connect module to the host PC with a Type-C cable and **double click** BOOT button on the module.




There will be a "GROVEAI" disk pop up.



- **Step 2.** Please copy the Model `.uf2` file to the GROVEAI disk to complete the firmware flash.

We can see that Work LED on the module flash in speed, that means the process is ongoing. After the disk disappear, the process of burning firmware is finished.



- **Step 3.** Please modify the program according to the model you are using.

In the demo we provided, inside the `setup()` function is initializing the model by calling `ai.begin()`.

```
if (ai.begin(ALGO_OBJECT_DETECTION, (MODEL_INDEX_T)0x11))
```

`ai.begin()` has two arguments, the type of model and the model number. The numbering is generally different for different models. That is to say, the model number of the sample program only applies to the **People Detected Model**, if you use other models, then the number is no longer `0x11`.

CAUTION

If you encounter the error message "Algo begin failed." when using the demo, you should first check if the model number is wrong.

So how do you determine the model number? Our R&D engineers have provided a detailed introductory document for developers to read.

- [Protocol](#)

But if you don't want to read such a long article, a simple way to determine this is to keep an eye out for the last number of the model in Release, which is the number we need.

For example, for the model **pfld_meter_pre_5.uf2**, the last digit is **5**, which means the model number is **5**. You can use

```
ai.begin(ALGO_OBJECT_DETECTION, (MODEL_INDEX_T)5)
```

directly, or rewrite it as hexadecimal

```
ai.begin(ALGO_ OBJECT_DETECTION, (MODEL_INDEX_T)0x05)
```

Exception Processing


If you have encountered an unforeseen situation in actual use, or if you have used it incorrectly and have experienced an outcome other than medical treatment. Please refer to the following steps to troubleshoot and attempt to repair the module.

Part 1. Check BootLoader Version

You may need to detect if the BootLoader version needs to be updated to decide if the update should be done. The method to check the version number is as follows.

Connect the Grove Vision AI to your computer via the USB-C port. Then double-click the Boot button until the computer comes up with a USB flash drive named GROVEAI.

Open this disk drive and open the **INFO_UF2.TXT** file.



As shown in the figure, you can see the Bootloader version number on the first line. As of September 2023, the latest BootLoader version number should be **v2.0.1**. If you also check the same version number, then in principle you don't need to do the next second step.

Part 2. Update BootLoader

If your Grove Vision AI is not recognized by your computer and behaves as no port number, then you may need to update the BootLoader.


- **Step 1.** Download the BootLoader `.bin` file on the windows PC.

Please download the latest version of the BootLoader file in the link below. The name of the BootLoader is usually `tinyuf2-grove_vision_ai_vx.x.x.bin`.

[Download BootLoader](#) 

This is the firmware that controls the BL702 chip that builds the connection between the computer and the Himax chip. The latest version of the BootLoader has now fixed the problem of Vision AI not being able to be recognised by Mac and Linux.

- **Step 2.** Download and open **BLDevCube.exe** software, select **BL702/704/706**, and then click **Finish**.



- **Step 3.** Click **View**, choose **MCU** first. Move to **Image file**, click **Browse** and select the firmware you just downloaded.

- IOT
- MCU**
- RF MFG

Interface: Uart
COM Port: COM42
Uart Speed: 2000000
JLink Speed: 1000
Chip Erase: True
Xtal: 32M

General Options

Boot Source: Flash BootInfo Addr: 0x0
Image Type: SingleCPU Image Addr: 0x2000
Image File: C:\Users\mengd\Desktop\tinyuf2-grove-ai-debugger.bin
Device Tree: 2

Bind
Save Image
Browse
Browse

Refresh
Clear

[click here to show advanced options >>](#)

0%


Log Create & Program Open UART

LOG


search

Empty log area

- **Step 4.** Make sure there are no other devices connect to the PC. Then hold the Boot button on the module, connect it to the PC.



We can see 5V light and 3.3V LED light are lighting on the back of the module, then loose the Boot button.



- **Step 5.** Back to the BLDevCube software on the PC, click **Refresh** and choose a proper port. Then click **Open UART** and set **Chip Erase** to **True**, then click **Creat&Program**, wait for the process done.

Image Partition Security Efuse Key Flash Utils IAP

General Options

Interface
COM Port
Uart Speed
JLink Speed
Chip Erase
Xtal

Boot Source BootInfo Addr
Image Type Image Addr
Image File
Device Tree

click here to show advanced options >>

Success

LOG

search

```
[10:07:56.632] - Flash load time cost(ms): 429.7392578125
[10:07:56.632] - Finished
[10:07:56.634] - Sha caled by host: 0a54fd55149929b4dc6877bae80b82e34deee9885eb0dd5e9d6d493f18fffd43
[10:07:56.635] - xip mode Verify
[10:07:56.655] - Read Sha256/85776
[10:07:56.656] - Flash xip readsha time cost(ms): 19.98828125
[10:07:56.656] - Finished
[10:07:56.657] - Sha caled by dev: 0a54fd55149929b4dc6877bae80b82e34deee9885eb0dd5e9d6d493f18fffd43
[10:07:56.657] - Verify success
[10:07:56.658] - Program Finished
[10:07:56.659] - All time cost(ms): 3359.08056640625
[10:07:56.774] - [All Success]
```

- **Step 6.** It is recommended to check the Vision AI version number again to ensure that the latest BootLoader is being used.


Part 3. Restore Factory Firmware



TIP

If ever uploading firmware on the latest version of Windows 11 has rendered the device unusable, you may need to refer to the section on [Update BootLoader](#).

- **Step 1.** Erase firmware



CAUTION

You can try to skip this step and copy the firmware directly to the Vision AI, if it works, then you don't have to erase the original firmware. If it fails, you may need to erase the firmware.

Please use the Arduino motherboard you have, the Seeed Studio XIAO series, Wio Terminal or Seeduino are recommended. Connect the Grove Vision AI to the motherboard via the IIC interface.

Open the Arduino IDE and upload the program to erase the firmware.

```
#include "Seeed_Arduino_GroveAI.h"  
#include <Wire.h>
```

```
WEI wei(Wire);


void setup()
{
    Wire.begin();
    Serial.begin(115200);
    while (!Serial)
    {
        /* code */
    }
    delay(1000);
    Serial.println("Press any key to start erase");
}

void loop()
{
    if (Serial.available())
    {
        while (Serial.available())
        {
            Serial.read();
        }
        uint32_t id = wei.ID();
        Serial.print("ID: 0x");
        Serial.println(id, HEX);
        wei.enter_bootloader();
        Serial.println("Erase");
        wei.erase();
    }
}
```




```
        Serial.println("Erase done");  
    }  
}
```


Open the serial monitor, enter some random characters, such as "a", click send, then the erase operation will start to execute. If you see the following message, then it proves that the firmware erase was successful. We can go to the next step.



- **Step 2.** Connect module to the host PC with a Type-C cable and **double click** BOOT button on the module.



Connect Cable



There will be a "GROVEAI" disk pop up.



GROVEAI (I:)

31.8 MB free of 31.8 MB

- **Step 3.** Download the factory firmware.

Please download the latest version of the factory firmware in the link below. The name of the factory firmware is usually `grove_ai_without_crc_vxx.uf2` or `grove_ai_vxx.uf2`.

Download the Firware 



TIP

As of September 2023, the latest firmware version is **grove_ai_v02-00.uf2**.

- **Step 4.** Flash the factory firmware.

Copy the `grove_ai_without_crc_vxx.uf2` or `grove_ai_vxx.uf2` file to the GROVEAI disk to complete the firmware flash.

The above three parts need to be judged and executed in turn, when the above steps are executed, you can do your operation again, if there are still problems, please contact our technical support team.

Trouble Shooting

Q1: What is the main method of connection?

- a. Link the microcontroller and the module first.
- b. Connect the microcontroller with host PC second.
- c. Connect the module with host PC at last.

Q2: Why can't I see the image display on the website? Nor the detecting?

- a. Is the module heated? Connect the module only will cost heat problem and let the module not functioning for a moment.
- b. Is connecting after the correct method?

Q3: Why does Grove Vision AI suddenly get an "Algo begin failed." error one day while in use?

In the demo we provided, inside the `setup()` function is initializing the model by calling `ai.begin()`.

```
if (ai.begin(ALGO_OBJECT_DETECTION, (MODEL_INDEX_T)0x11))
```

`ai.begin()` has two arguments, the type of model and the model number. The numbering is generally different for different models. That is to say, the model number of the sample program only applies to the **People Detected Model**, if you use other models, then the number is no longer `0x11`.

CAUTION

If you encounter the error message "Algo begin failed." when using the demo, you should first check if the model number is wrong.

So how do you determine the model number? Our R&D engineers have provided a detailed introductory document for developers to read.

- Protocol

But if you don't want to read such a long article, a simple way to determine this is to keep an eye out for the last number of the model in Release, which is the number we need.

For example, for the model **pfld_meter_pre_5.uf2**, the last digit is **5**, which means the model number is **5**. You can use

```
ai.begin(ALGO_OBJECT_DETECTION, (MODEL_INDEX_T)5)
```

directly, or rewrite it as hexadecimal


```
ai.begin(ALGO_ OBJECT_DETECTION, (MODEL_INDEX_T)0x05)
```

Tech Support & Product Discussion

Thank you for choosing our products! We are here to provide you with different support to ensure that your experience with our products is as smooth as possible. We offer several communication channels to cater to different preferences and needs.





 [Edit this page](#)

Last updated on **Mar 22, 2023** by **Citric**

0 reactions



0 comments

