

# Earthquake click

MIKROE-2561

Weight: 30 g



**Earthquake click** carries [D7S](#), the world's smallest high-precision seismic sensor from Omron.

The click is designed to run on either 3.3V or 5V power supply. It communicates with the target MCU over I2C interface, with additional functionality provided by the following pins on the mikroBUS™ line: PWM, INT, CS.

**Earthquake click** carries [D7S](#), the world's smallest high-precision seismic sensor from Omron. The click is designed to run on either 3.3V or 5V power supply. It communicates with the target MCU over I2C interface, with additional functionality provided by the following pins on the mikroBUS™ line: PWM, INT, CS.

When an earthquake occurs with a seismic intensity equivalent to 5 Upper or higher on the JMA (Japan Meteorological Agency) Seismic Intensity Scale, the D7S will activate the shutoff output to notify the user that an earthquake has occurred.

## How it works

Using the SI (spectral intensity) value, which has a high correlation with the seismic intensity scale that indicates the magnitude of an earthquake, provides higher-precision judgment of seismic intensity scales.

The 3-axis acceleration Sensor and Omron's unique SI value calculation algorithm achieve high precision and low consumption. (Higher degree of freedom for incorporation into devices and prolonged operation on battery power).

Shutoff output terminal (INT1) operates equivalent to a conventional mechanical vibration sensor and ensures compatibility with mechanical vibration sensors.

I2C interface is able to obtain earthquake-related information from the sensor with communications from external devices.

## Spectral intensity

The SI value (or spectral intensity) is equivalent to the magnitude of the destructive energy imposed by seismic motion on structures.

## Low power consumption

The power consumption during standby is **90  $\mu$ A or less**. On average, during processing, the sensor uses around 300  $\mu$ A.

## JMA seismic intensity scale


JMA or Japan Meteorological Agency intensity scale is used in Japan and Taiwan to measure the intensity of earthquakes. The scale goes from 0 to 7. The level 5 on this scale indicates when objects inside a house start falling down, like books from the shelf, dishes in a cupboard, cracks are formed on walls, etc.

## Specifications

<b>Type</b>	Motion
<b>Applications</b>	Vibration sensor, fire prevention systems, electricity meters, gas meters, chemical plants, bridges, tunnels, etc.
<b>MCU</b>	D7S seismic sensor
<b>Key Features</b>	Low power consumption, Acceleration Detection Range –2,000 to 2,000 gal, Shutoff Output (INT1) Output at seismic intensity level 5 or higher
<b>Key Benefits</b>	The click can calculate seismic activity and detect an earthquake
<b>Interface</b>	GPIO,I2C
<b>Input Voltage</b>	3.3V or 5V
<b>Compatibility</b>	mikroBUS
<b>Click board size</b>	S (28.6 x 25.4 mm)

## Pinout diagram

This table shows how the pinout on **Earthquake click** corresponds to the pinout on the mikroBUS™ socket (the latter shown in the two middle columns).

Notes	Pin					Pin	Notes
	NC	1	AN	PWM	16	<b>INT2</b>	Processing notification output
	NC	2	RST	INT	15	<b>INT1</b>	Shutoff output
Initial setting input	<b>SETTING</b>	3	CS	TX	14	NC	
	NC	4	SCK	RX	13	NC	
	NC	5	MISO	SCL	12	<b>SCL</b>	I2C clock
	NC	6	MOSI	SDA	11	<b>SDA</b>	I2C data
Power supply	<b>+3.3V</b>	7	3.3V	5V	10	<b>+5V</b>	Power supply
Ground	<b>GND</b>	8	GND	GND	9	<b>GND</b>	Ground

## Maximum ratings

Description	Min	Typ	Max	Unit
Power Supply Voltage	-0.3		6.0	V
Average Current Consumption during Processing			300	uA
Operating Temperature	-30		70	°C

## Jumpers and settings

Designator	Name	Default Position	Default Option	Description:
JP1	PWR.SEL.	Left	3.3V	Power Supply Voltage Selection 3.3V/5V, left position 3.3V, right position 5V