stay connected

EUROCARD HOLDER

SKP 31/1

Screw terminals 31-pole (DIN 41617) all


With the vertical snap adapter SASA 135 Art.-No. 63900 the holder can be mounted at right-angles on the rail. The D2 size is for a card without a front plate.

Link to Product

Illustration







Product may differ from Image



stay connected

stay connecte
250 V AC
max. 5 A
31-pole (DIN 41617)
(EN 60664-1) over voltage, category I
Plastic, flame retardant
4 mm² single core
DIN-rail mountable (EN 60715) or screw fixing
137×63×170 mm
To insert the card first press down the 2 yellow buttons. Then slide the Eurocard into the guide slots pushing until fully engaged. The card is now locked into position. It can be removed by pressing down on the 2 yellow buttons.
CZ
85369010
1