


DRAPER[®]

PETROL

CULTIVATOR/ TILLER



04603 - CP145 SPARE PARTS DRAWING




DRAPER®

PETROL

CULTIVATOR/ TILLER



04603 - CP145 SPARE PARTS DRAWING / LISTING



KEY No.	PART No.	STOCK No.	DESCRIPTION
1	YCP145-63	40926	BOLT M6x12
2	YCP145-64	40939	COVER COMP, CYLINDER HEAD
3	YCP145-65	41191	PACKING, HEADCOVER
4	YCP145-66	41202	ROCKER ARM
5	YCP145-67	41317	PLATE, PUSH ROD GUIDE
6	YCP145-68	41390	SEAT, VALVE SPRING, IN

KEY No.	PART No.	STOCK No.	DESCRIPTION
7	YCP145-69	41403	SPRING, VALVE
8	YCP145-70	41418	RETURNER, INTAKE VALVE
9	YCP145-71	41448	VALVE, INTAKE
10	YCP145-72	41501	VALVE EXHAUST
11	YCP145-73	41547	SPARK PLUG
12	YCP145-74	41559	COVER, RECOIL

DRAPER[®]

PETROL

**CULTIVATOR/
TILLER****04603 - CP145 SPARE PARTS LISTING**

KEY No.	PART No.	STOCK No.	DESCRIPTION
13	YCP145-75	41693	BOLT M6x25
14	YCP145-76	42041	WIND DEFLECTOR SHALL BE LEFT
15	YCP145-77	42089	PLATE, GOVERNOR
16	YCP145-78	42090	ROD, PUSH
17	YCP145-79	42092	LIFTER, VALVE
18	YCP145-80	42100	CAMSHAFT ASSY
19	YCP145-81	42141	SCRAPER RING SET, PISTON
20	YCP145-82	42282	PISTON
21	YCP145-83	42542	PIN, PISTON
22	YCP145-84	42543	CLIP, PISTON
23	YCP145-85	42558	ROD ASSEMBLY., CONNECTING
24	YCP145-86	42562	CYLINDER
25	YCP145-87	42563	OIL SEAL
26	YCP145-88	42586	NUT, FLANGE
27	YCP145-89	42609	ADJUSTER ROCKER ARM
28	YCP145-90	42611	SHROUD
29	YCP145-91	42612	ENGINE STOP WIRE
30	YCP145-92	42614	CIRCULAR PLATE
31	YCP145-93	42627	BREATHING VALVE SPRING
32	YCP145-94	42629	BOLT, STUD
33	YCP145-95	42634	FUEL TANK CAP COMP
34	YCP145-96	42886	FUEL TANK
35	YCP145-97	43003	BOLT M6x38
36	YCP145-98	43005	BUSHING, FUEL TANK
37	YCP145-99	43019	BOLT M6x16
38	YCP145-100	43024	ENGINE STOP WIRE
39	YCP145-101	43027	CLIP, FUEL LINE
40	YCP145-102	43029	FUEL LINE
41	YCP145-103	43033	SHAFT, GOVERNOR ARM
42	YCP145-104	43034	WASHER, GOVERNOR ARM SHAFT
43	YCP145-105	43035	SEAL, GOVERNOR ARM SHAFT
44	YCP145-106	43036	PIN, LOCK
45	YCP145-107	43037	GOVERNOR ARM
46	YCP145-108	43105	BOLT, GOVERNOR ARM
47	YCP145-109	43308	HEXAGON BOLTS WITH FLANGE
48	YCP145-110	43312	ROD, GOVERNOR
49	YCP145-111	43370	SPRING, THROTTLE RETURN
50	YCP145-112	43407	SPRING, GOVERNOR
51	YCP145-113	43408	NUT
52	YCP145-114	43409	SHROUD ASSY, UPPER
53	YCP145-115	43410	TUBE, BREATHER

KEY No.	PART No.	STOCK No.	DESCRIPTION
54	YCP145-116	43411	CLIP, WIRE HARNESS
55	YCP145-117	43412	CRANKSHAFT ASSY
56	YCP145-118	43413	NUT
57	YCP145-119	43420	WASHER, CRANKSHAFT
58	YCP145-120	43434	GOVERNOR ASSEMBLY
59	YCP145-121	43450	GASKET, BREATHER CHAMBER
60	YCP145-122	43455	CAP, BREATHER CHAMBER
61	YCP145-123	43756	DOWEL PIN, CASECOVER
62	YCP145-124	43856	COVER ASSEMBLY, CRANKCASE
63	YCP145-125	43870	OIL SEAL
64	YCP145-126	43994	BOLT M6x18
65	YCP145-127	44046	BOLT M6x45
66	YCP145-128	44061	TUBE
67	YCP145-129	44065	CLIP, FUEL LINE
68	YCP145-130	44068	DIPSTICK
69	YCP145-131	44069	NUT M6
70	YCP145-132	44073	CLAMP, BREATHER TUBE
71	YCP145-133	44074	IGNITION COIL ASSY
72	YCP145-134	44075	BOLT STUD, IGNITION COIL
73	YCP145-135	44080	BOLT STUD, RECOIL STARTER
74	YCP145-136	44092	FLYWHEEL ASSEMBLY
75	YCP145-137	44082	FAN, RECOIL STARTER
76	YCP145-138	44095	PULLEY, STARTER
77	YCP145-139	44103	NUT
78	YCP145-140	44137	SHIELD, MUFFLER
79	YCP145-141	44152	GASKET, AIR CLEANER
80	YCP145-142	44239	AIR CLEANER ASSEMBLY
81	YCP145-143	44241	BOLT, STUD
82	YCP145-144	44369	PACKING, INTAKE
83	YCP145-145	44377	INSULATOR, CARBURETOR
84	YCP145-146	44393	PACKING, CARBURETOR
85	YCP145-147	44400	CARBURETOR ASSY
86	YCP145-148	44426	GASKET, EXHAUST
87	YCP145-149	44484	MUFFLER ASSY
88	YCP145-150	44489	FILTER, BREATHER
89	YCP145-151	44490	FILTER
90	YCP145-152	44491	DAMPER PUTTER