

Probe/oscilloscope chart

Base unit: R&S®		RTC1000	RTB2000	RTM3000	RTA4000	RTE	RTO	RTP	RTH	RT-ZA9	RT-Z1M	Page
Probe: R&S®												
Passive probes												
RT-ZH03	BNC, 1 MΩ	●	●	●	●	●	●				●	6
RT-ZH10	BNC, 1 MΩ, readout	○	○	●	●	●	●				●	9
RT-ZH11		○	○	●	●	●	●				●	9
RT-ZI10									●			12
RT-ZI10C									●			12
RT-ZI11									●			12
Differential probes												
RT-ZD002	BNC, 1 MΩ	●	●	○	○	○	○				○	16
RT-ZD003		●	●	○	○	○	○				○	16
RT-ZD01		●	●	●	●	●	●				●	19
RT-ZD02	BNC, 50 Ω ¹			●	●	●	●	●		●		22
RT-ZD08				●	●	●	○	●		●		22
RT-ZHD07	Rohde & Schwarz, 1 MΩ			●	●	●	●				●	24
RT-ZHD15				●	●	●	●				●	29
RT-ZHD16				●	●	●	●				●	29
RT-ZHD60				●	●	●	●				●	33

¹ Probe requires 50 Ω input coupling. It can be attached to oscilloscopes with 1 MΩ input coupling using a BNC feedthrough termination adapter.