



the sensor people





Part no.: 426128 **AC-MLC-END** Connector set

Figure can vary

Contents

- · Set consists of
- Technical data
- Notes

Part no.: 426128 - AC-MLC-END - Connector set

Set consists of

Quantity	Part no.	Designation	Article	Description
1	426127	AC-MLC-HR- END	Host receiver termination	Connection 1: Connector, M12, Axial, Male, 8 -pin Connector, encoding: A-coded Degree of protection: IP 67
1	426126	AC-MLC-HT- END	Host transmitter termination	Connection 1: Connector, M12, Axial, Male, 8 -pin Connector, encoding: A-coded Degree of protection: IP 67

Technical data

Alignment and setup aid for MLC 520 Host versions		
MLC 500 host transmitter safety light curtains MLC 520 host receiver safety light curtains		
IP 67		
85366990		
27069190		
27069190		
EC001578		

EC001578

Notes

ETIM 6.0

WARNING!

Risk of injury due to insufficient safety distance

- Integration of a Guest device results in an increase in reaction time. For this reason, a large safety distance must be allowed for.
- For further information, refer to calculation of the safety distance in the connecting and operating instructions.



Part no.: 426128 - AC-MLC-END - Connector set

WARNING!

Risk of injury due to missing stepping behind protection

· If the terminating plugs are used, take appropriate measures to ensure that it is not possible to step behind the safety light curtain.

WARNING!

Risk of injury due to unforeseeable machine behavior

- Changes made to the protective device can lead to unforeseeable machine behavior.
- · After making changes, have the protective device checked by a qualified person.

NOTE

· Refer to the MLC 520 Host connecting and operating instructions.