

Earth measurement set perfect for:

• e.g. Telaris ProInstall-200

Included:

1x carrying case

2x ground spikes (235 x Ø 10 mm)

1x test lead, red, 25 m

1x test lead, blue, 25 m

1x test lead, green, 5 m

3x test lead winders

3x crocodile clips

Earth measurement set

Article no. 4388671



AC current clamp adapter

- Current measurement from approx. 1 mA to 1000 A
- Jaw opening 48 mm
- Current output, output signal: 1 mA corresponds to 1 A test current
- Fixed test lead
- · No batteries required

AC current clamp adapter

Article no. 3313401



DAA-16

DAA-32

DAA-16, DAA-32

Three-phase adapter 16 A or 32 A

- Three-phase current plug CEE 16 A or CEE 32 A
 Connections via five separate 4 mm sockets
- for L1, L2, L3, N and PE
- For quick connection of test devices to three-phase sockets when testing according to DIN VDE 0100
- *with Schuko plug

DAA-16

Article no. 2743806

DAA-32

Article no. 2743850



Barcode Scanner

For reading in barcoded sample numbers*

Model BC-GT07XX for:

• for equipment tester GT-0751

Model BC-1250G for:

- for machine tester MT 204-S (Model 9085)
- for equipment tester GT-650 and GT-900

Barcode Scanner

Article no. 4377939

Barcode sticker

- Abrasion-resistant numbered barcodes for identifying samples
- Consecutive numbering
 Barcoded (code 39) and clear text
- Size 54 x 15 mm
- For 0701/0702 test equipment
- 250 pcs. on roll

*for reading in code 39, code 128, code 2/5, EAN, **UPC** barcodes

Barcode sticker

Article no. 2389952




VLP 5 Three-phase current extension test adapter

- For testing portable equipment and extension cables with the plugs and couplings:
- 16 A CEE 3-pole
- 16 A CEE 5-pole
- 32 A CEE 5-pole
- IEC power cable and Schuko
- Measurement of protective earth resistance, insulation resistance, function of active conductors (L-N), and rotary field
- Suitable for all test equipment with an earthed socket and test probe

VLP 5 Model: 1343

Article no. 3313514





KBGE-MT204S USB keyboard

- For convenient entry of client/sample information
- For equipment tester GT-650 and GT-900
- For machine tester MT204-S

KBGE-MT204S

Article no. 3504388



Measurement adapter for stray current/leakage current measurement

- Measurement adapter for measuring differential current, protective earth current, load current, and neutral conductor current in portable consumers via a leakage current clamp
- All conductors are individually brought out



Wiring diagram 1233

Application example for a leakage test under mains voltage (leakage current) e.g. with ALC-110-EUR CHB5 or CHB1



Wiring diagram 1235/1236 Application example for a leakage test under mains voltage (leakage current) e.g. with ALC-110-EUR CHB5 or CHB1