





Between Series Adapters

P.N.	Description
SMAM-BF-NT3G-50	SMA Plug to BNC Jack



Technical drawing dimensions: 11 [.433], 20.3 [.800], 30.3 [1.194], 8.4 [.331], 8 HEX, 1/4-36UNS-2B

P.N.	Description
SMAM-TF-NT3G-50	SMA Plug to TNC Jack



Technical drawing dimensions: 12 [.473], 10.7 [.422], 25.07 [.988], 4.24 [.167], 7/16-28UNEF-2A, 8 HEX, 1/4-36UNS-2B

P.N.	Description
SMAF-BM-3GT3G-50	SMA Jack to BNC Plug



Technical drawing dimensions: 14.5 [.571], 15 [.591], 19 [.749], 25.4 [1.001], 1/4-36UNS-2A

P.N.	Description
SMAF-TM-NT3G-50	SMA Jack to TNC Plug



Technical drawing dimensions: 14.5 [.571], 15 [.591], 25.4 [1.001], 7/16-28UNEF-2B, 1/4-36UNS-2A

P.N.	Description
SMAF-BF3-NT3G-50	SMA Jack to BNC Jack



Technical drawing dimensions: 21.34 [.841], 10.7 [.422], 12.0 [.473], 1/4-36UNS-2A

P.N.	Description
SMAM-TM-NT3G-50	SMA Plug to TNC Plug



Technical drawing dimensions: 14.5 [.571], 15 [.591], 19.6 [.772], 29.5 [1.162], 7/16-28UNEF-2B, 8 HEX, 1/4-36UNS-2B

P.N.	Description
SMAM-BM-NT3G-50	SMA Plug to BNC Plug

Technical drawing dimensions: 14.5 [.571], 15.02 [.592], 19.6 [.772], 29.5 [1.162], 3 [.118], 8 HEX, 1/4-36UNS-2B

P.N.	Description
SMAF-TF-NT3G-50	SMA Jack to TNC Jack





Technical drawing dimensions: 12 [.473], 10.7 [.422], 21.34 [.841], 6.4 [.252], 7/16-28UNEF-2A, 1/4-36UNS-2A

Between Series Adapters


P.N. Description

SMAM-SMBM1-3GT50G-50 SMA Plug to SMB Plug




P.N. Description

NF-SMAM-NT3G-50 N Jack to SMA Plug




P.N. Description

SMAF-SMBF1-3GT50G-50 SMA Jack to SMB Plug




P.N. Description

NM-SMAF-NT3G-50 N Plug to SMA Jack




P.N. Description

SMAM-SMBF-3GT50G-50 SMA Plug to SMB Jack




P.N. Description

NM-SMAM-NT3G-50 N Plug to SMA Plug




P.N. Description

SMAF-SMBM1-3GT50G-50 SMA Jack to SMB Plug





P.N. Description

NF-SMAF-NT3G-50 N Jack to SMA Jack





Between Series Adapters



P.N.	Description
NF-SMAF2-NT3G-50	N Jack to SMA Jack



P.N.	Description
SMAF-UF-NT3G-50	SMA Jack to UHF Jack



P.N.	Description
SMAM-UF-NT3G-50	SMA Plug to UHF Jack



P.N.	Description
SMAM-MUF-NT3G-50	SMA Plug to MINI-UHF Jack



P.N.	Description
SMAF-UM-NT3G-50	SMA Jack to UHF Plug



P.N.	Description
SMAF-MUM-NT3G-50	SMA Jack to MINI-UHF Plug

P.N.	Description
SMAM-UM-NT3G-50	SMA Plug to UHF Plug


P.N.	Description
SMAM-MUM-NT3G-50	SMA Plug to MINI UHF Plug

Between Series Adapters


P.N. **Description**

SMAF-MUF-NT3G-50 SMA Jack to MINI-UHF Jack




P.N. **Description**

SMAF-MCXF1-3GT50G-50 SMA Jack to MCX Jack




P.N. **Description**

SMAM-MCXF1-3GT50G-50 SMA Plug to MCX Jack




P.N. **Description**

SMAM-MMCXF1-3GT50G-50 SMA Plug to MMCX Jack




P.N. **Description**

SMAF-MCXM1-3GT50G-50 SMA Jack to MCX Plug




P.N. **Description**

SMAF-MMCXM1-3GT50G-50 SMA Jack to MMCX Plug




P.N. **Description**

SMAM-MCXM1-3GT50G-50 SMA Plug to MCX Plug





P.N. **Description**

RSMAM-MMCXM1-3GT50G-50 Reversed SMA Jack to MMCX Plug





Between Series Adapters



P.N.	Description
SMAM-MMCXM1-3GT50G-50	SMA Plug to MMCX Plug



P.N.	Description
NF-BF-NT3G-50	N Jack to BNC Jack



P.N.	Description
SMAF-MMCXF1-NT3G-50	SMA Jack to MMCX Jack



P.N.	Description
OS-7051-NDG	N Plug to BNC Plug



P.N.	Description
OS-7324-NDG	N Plug to BNC Jack



P.N.	Description
OS-7328-NDG	N Plug to TNC Jack

P.N.	Description
NF-BM-NT3G-50	N Jack to BNC Plug






P.N.	Description
NF-TM-NT3G-50	N Jack to TNC Plug






Between Series Adapters



P.N.	Description
OS-7334-NTN	N Jack to TNC Jack



P.N.	Description
NF-FM2-NT3G-75	N Jack to F Plug



P.N.	Description
NM-TM1-NT3G-50	N Plug to TNC Jack



P.N.	Description
NM -716F-120STS-50	N Plug to 7/16 Jack



P.N.	Description
NF-TF2-NT3G-50	N Jack to TNC Female



P.N.	Description
NF -716M-120STS-50	N Jack to 7/16 Plug

P.N.	Description
OS-7249-NDG	N Jack to F Jack



P.N.	Description
NF -716F-120STS-50	N Jack to 7/16 Jack



Between Series Adapters

Between Series Adapters



P.N.	Description
NM -716M-120STS-50	N Plug to 7/16 Plug



P.N.	Description
BM-TF1-NT3G-50	BNC Plug to TNC Jack



P.N.	Description
OS-7330-NDG	N Plug to UHF Jack



P.N.	Description
BF-TM-NT3G-50	BNC Jack to TNC Plug



P.N.	Description
BM-SMBF-3GT3G-50	BNC Plug to SMB Jack



P.N.	Description
BF-TF1-NT3G-50	BNC Jack to TNC Jack

P.N.	Description
BM-SMBM-NT3G-50	BNC Plug to SMB Plug






P.N.	Description
BM-TM1-NT3G-50	BNC Plug to TNC Plug






Between Series Adapters



P.N.	Description	P.N.	Description
OS-7060-NDG	BNC Plug to UHF Jack	TF-L-MCXF-NT3G-50	Bulkhead Right Angle TNC Female to MCX Female Adapter





P.N.	Description	P.N.	Description
OS-7050-NDG	BNC Plug to F Jack	BM-FMEM-NDS-50	Nipple Plug to BNC Plug



P.N.	Description	P.N.	Description
OS-7059-NDG	BNC Plug to UHF Plug	TM-FMEM-NDS-50	Nipple Plug to BNC Plug





P.N.	Description	P.N.	Description
OS-7610-NDG	MINI-UHF Plug to UHF Jack	BM-L-FMEM-NT3G-50	Right Angle Adapter - Nipple Plug to BNC Plug





Between Series Adapters



P.N.	Description
TM-L-FMEM-NT3G-50	Right Angle Adapter — Nipple Plug to TNC Plug



P.N.	Description
SMAF-FMEM-NT3G-50	Nipple Plug to SMA Jack



P.N.	Description
FMEM-MUM-NDS-50	Nipple Plug to Mini-UHF Plug



P.N.	Description
SMAM-FMEM-NT3G-50	Nipple Plug to SMA Plug

P.N.	Description
FME2071N1-NTS-50	Nipple Plug to N Plug

P.N.	Description
FMEM-MCXM-NT3G-50	Nipple Plug to MCX Plug

P.N.	Description
FMEM-UM-NTS-50	Nipple Plug to UHF Plug

