



Item	Part No.	Description
1	SA56.01	HOUSING
2	SA56.02	AIR INLET
3	SA56.03	EXHAUST DIFFUSER
4	SA56.04	O-RING
5	SA56.05	O-RING
6	SA56.06	TRIGGER PIN
7	SA56.07	VALVE BUSHING
8	SA56.08	O-RING
9	SA56.09	VALVE SPINDLE
10	SA56.10	TRIGGER
11	SA56.11	SCREW
12	SA56.12	O-RING
13	SA56.13	BEARING
14	SA56.14	REAR END PLATE
15	SA56.15	CYLINDER
16	SA56.16	ROTOR
17	SA56.17	ROTOR BLADES(5PCS)
18	SA56.18	FRONT END PLATE
19	B/608ZZ	BEARING 608ZZ
20	SA56.20	GEAR PIN

Item	Part No.	Description
21	SA56.21	PLANET GEAR
22	SA56.22	WORKING SPINDLE
23	SA56.23	BEARING
24	SA56.24	INTERNAL GEAR
25	SA56.25	GEAR CASE
26	B/R8ZZ	BEARING R8ZZ
27	SA56.27	ECCENTRIC NUT
28	SA56.28	REPAIR WASHER M8x32 BLACK
29	SA56.29	SPACER
30	SA56.30	CUTTER HOUSING
31	SA56.31	RIGHT BLADE for SA56
32	SA56.32	LEFT BLADE for SA56
33	SA56.33	CENTRE BLADE for SA56
34	SA56.34	BUSHING
35	SA56.35	LOCK NUT
36	SA56.36	LOCK SCREW
37	SA56.37	SPRING
38	SA56.38	PIN
--	SA56.39	HEX KEY (NOT SHOWN)

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.