



Item	Part No.	Description
1	1000E.V2-01	Handle Grip
2	1000E.V2-02	Handle
3	1000E.V2-03	Pin

Item	Part No.	Description
4	1000E.V2-04	Rod Joint
5	1000E.V2-05	Snap Ring
6	1000E.V2-06	Dustproof Ring

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.



Parts Information:
Transmission Jack 1 Tonne Floor
Model No: 1000E.V2

Item	Part No.	Description
7	1000E.V2-07	Pump Cylinder
8	1000E.V2-08	Pump Plunger
9	1000E.V2-09	O-Ring
10	1000E.V2-10	Y-Seal
11	1000E.V2-11	Pin
12	1000E.V2-12	Pump Seat
13	1000E.V2-13	Copper Washer
14	1000E.V2-14	Bolt
15	1000E.V2-15	Copper Washer
16	1000E.V2-16	Spring
17	1000E.V2-17	Steel Ball
18	1000E.V2-18	Spring
19	1000E.V2-19	Steel Ball
20	1000E.V2-20	Bolt
21	1000E.V2-21	Sealing Washer
22	1000E.V2-22	Screw
23	1000E.V2-23	Spring
24	1000E.V2-24	Ball Seat
25	1000E.V2-25	Steel Ball
26	1000E.V2-26	Release Knob
27	1000E.V2-27	Pin
28	1000E.V2-28	Oil Release Valve Rod
29	1000E.V2-29	O-Ring
30	1000E.V2-30	Oil Cylinder Ass'y
31	1000E.V2-31	Bolt
32	1000E.V2-32	Oil filler Plug
33	1000E.V2-33	Snap Ring
34	1000E.V2-34	O-Ring
35	1000E.V2-35	O-Ring
36	1000E.V2-36	Sealing Washer
37	1000E.V2-37	Piston Ring
38	1000E.V2-38	Piston Rod
39	1000E.V2-39	Bushing
40	1000E.V2-40	O-Ring
41	1000E.V2-41	Snap Ring
42	1000E.V2-42	Pin
43	1000E.V2-43	Connecting Block
44	1000E.V2-44	Pin
45	1000E.V2-45	Shaft
46	1000E.V2-46	Rod Link
47	1000E.V2-47	Snap Ring
48	1000E.V2-48	Shaft
49	1000E.V2-49	Nut
50	1000E.V2-50	Lock Washer

Item	Part No.	Description
51	1000E.V2-51	Washer
52	1000E.V2-52	Frame
53	1000E.V2-53	Nut
54	1000E.V2-54	Washer
55	1000E.V2-55	Spring Washer
56	1000E.V2-56	Wheel, Swivel Castor, 4-Bolt Fix
57	1000E.V2-57	Bolt
58	1000E.V2-58	Shaft
59	1000E.V2-59	Snap Ring
60	1000E.V2-60	Connecting Bar
61	1000E.V2-61	Snap Ring
62	1000E.V2-62	Arm
63	GNM19S	Grease Nipple Str 6 x 1.00mm Single
64	1000E.V2-64	Snap Ring
65	1000E.V2-65	Knob
66	1000E.V2-66	Pin
67	1000E.V2-67	Lead Screw
68	1000E.V2-68	Shaft
69	GSM66.S	Grub Screw M6x6 (Single)
70	1000E.V2-70	Bushing
71	B/51102	Bearing Race 51102
72	1000E.V2-72	Shaft
73	1000E.V2-73	Bracket
74	1000E.V2-74	Bolt
75	1000E.V2-75	Screw
76	1000E.V2-76	Bolt
77	1000E.V2-77	Bracket
78	1000E.V2-78	Shaft
79	1000E.V2-79	Snap Ring
80	1000E.V2-80	Nut
81	1000E.V2-81	Washer
82	1000E.V2-82	Chain
83	1000E.V2-83	Chain Shackle
84	1000E.V2-84	Shackle Screw
85	1000E.V2-85	Screw
86	1000E.V2-86	Washer
87	1000E.V2-87	Saddle Angle (3)
88	1000E.V2-88	Hook Bolt 58mm Thread
89	1000E.V2-89	Nut
90	1000E.V2-90	Screw
91	1000E.V2-91	Saddle Angle (2)
92	1000E.V2-92	Wing Nut
93	1000E.V2-93	Saddle Angle (1)
94	1000E.V2-94	Fixing Board

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

IMPORTANT: No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR



01284 757500



01284 703534



sales@sealey.co.uk



www.sealey.co.uk