


SR 540

Spare parts / Accessories



| No. | Description | Ordering No. |
|------------|--------------------------------|---------------------|
| 1. | Visor PC, 10 pcs | R06-0507 |
| 1. | Visor set PC | R06-0502 |
| 1a. | Closing panel, right + left | - |
| 1. | Visor set PETG | T06-0502 |
| 1a. | Closing panel, right + left | - |
| 2. | Flat gasket | R06-0506 |
| 3. | Hose SR 541. 0,9 m. | R06-0501 |
| | Hose SR 541. 1,0 m | R10-0068 |
| 4. | O-ring | R06-0202 |
| 5. | Peel of set SR 542 | T06-0501 |
| 6. | Face seal SR 546 | T06-0504 |
| 7. | Set of valves SR 540 | R06-0505 |
| 7a. | Exhalation membrane 1 pc. | - |
| 7b. | Cover exhalation valve 1 pc. | - |
| 8. | Sweatband SR 544 | R06-0504 |
| 9. | Neck comfort band | T06-0803 |
| 10. | Sweatband/Crown band | T06-0506 |
| 11. | Head harness | R06-0511 |
| 12. | Head cover SR 543 | T06-0505 |
| 13. | Tyvek Hood SR 586 | T06-0806 |
| 14. | Sealing for visor | R06-0508 |
| 15. | Cleaning wipes SR 5226. 50/box | H09-0401 |