



the sensor people





Part no.: 426126 AC-MLC-HT-END Host transmitter termination

Figure can vary

Contents

- Technical data
- Electrical connection
- Notes



Part no.: 426126 – AC-MLC-HT-END – Host transmitter termination

Technical data

Basic data	
Application	Alignment and setup aid for MLC 520 Host versions
Suitable for	MLC 500 host transmitter safety light curtains

Connection		
Connection 1		
Type of connection	Connector	
Thread size	M12	
Туре	Male	
No. of pins	8 -pin	
Encoding	A-coded	
Design	Axial	

Certifications	
Degree of protection	IP 67

Classification		
Customs tariff number	85366990	
eCl@ss 8.0	27069190	
eCl@ss 9.0	27069190	
ETIM 5.0	EC001578	
ETIM 6.0	EC001578	

Electrical connection

Connection 1	
Type of connection	Connector
Thread size	M12
Туре	Male
No. of pins	8 -pin
Encoding	A-coded
Design	Axial

Notes

WARNING!

Risk of injury due to insufficient safety distance

- Integration of a Guest device results in an increase in reaction time. For this reason, a large safety distance must be allowed for.
- · For further information, refer to calculation of the safety distance in the connecting and operating instructions.



Part no.: 426126 - AC-MLC-HT-END - Host transmitter termination

WARNING!

Risk of injury due to missing stepping behind protection

· If the terminating plugs are used, take appropriate measures to ensure that it is not possible to step behind the safety light curtain.

WARNING!

Risk of injury due to unforeseeable machine behavior

- · Changes made to the protective device can lead to unforeseeable machine behavior.
- · After making changes, have the protective device checked by a qualified person.

NOTE

Refer to the MLC 520 Host connecting and operating instructions.