

5.3 SPARE PARTS LIST

Sender (Company name):

.....

Send, ATTENTION to:

.....

ORDER FORM

Unit serial number:
 (on the technical label)

For a quick response to your spare parts requirement kindly use the list below. Just fill in the quantity of each part you require and send it to us - Thank you. You will find the addresses at the end of this manual.



Part no.	Pos.	Description	Qty	Order-qty
ET4500	9	Soldering iron 55 W	1	
ET4550		Heating element	1	
ET4520		Soldering tips Type S, B, C	1	
ET4521		Soldering tips Type SL, SS, CA	1	
ET4522		Soldering tips SMD Type SM8 SM14	1	
		Type SM16 SM23	1	
		Type SM0805 SM1206	1	
		Type SM5588	1	
ET4523		SMD-Adapter	1	
ET4524		Cleaning brush, Copper	1	
ET3008		Spare sponges, (bag of 8 pieces)	1	
ET3010		Front cover, black	1	
ET3011		Tinbox, axe standards included	1	
ET3012	8	Iron holder assembly	1	
ET3015		Axe standards to tinbox ET3011	1	
ET3016		Box ESD, black	1	
ET3017		Box, green	1	
ET3019		Holder	1	
ET3020		Rocker switch	1	
ET3021		Complete switch to "Stop & Go"	1	
TR4200		Supply unit to E911D/A 230 VAC / 50 VA	1	
TR4220		Supply unit to E912A 230 VAC / 100 VA	1	
TR4111		Supply unit to E911D/A 115 VAC / 50 VA	1	
TR4121		Supply unit to E912 A 115 VAC / 100 VA	1	