





# ThermoJet Tips

## SensaTemp Handpieces Tips

| REMOVAL TIPS   | DESCRIPTION   | TIP SIZE A x B                            | PART NUMBERS |
|--|---|---|--------------|
|   | <b>Tips for TJ-70 Handpiece</b><br>Small, Straight, Single Jet Tip                | 0.060" I.D.                               | 1121-0366-P1 |
|  |  | Small, Curved, Single Jet Tip             | 0.060" I.D.  |
|   | SOT/Chip Component Tip (dual-jet)   | A = 3.56mm (0.14")                        | 1121-0329-P1 |
|  | SOIC Tip (dual-jet)   | A = 4.32mm (0.17")                        | 1121-0330-P1 |
|  | SOICL Tip (dual-jet)  | A = 9.40mm (0.37")                        | 1121-0331-P1 |
|  | Flat End Tip  | A = 7.11mm (0.28")<br>B = 1.88mm (0.074") | 1121-0365-P1 |
|  |   | A = 6.10mm (0.24")<br>B = 1.88mm (0.074") | 1121-0371-P1 |