



Item	Part No.	Description
1	ECS300.01	FRONT PANEL
2	ECS350.02	CORD SUPPORT
3	ECS300.03	DISPLAY PANEL
4	ECS650.04	HANDLE
5	ECS350.05	CABLE REEL KIT
6	ECS350.06	CLAMP SUPPORT KIT
7	ECS350.07	WHEEL AXLE
8	ECS350.08	WHEEL KIT (160x39)
9	ECS300.09	TRANSFORMER
10	ECS650.10	PCB UNIT
11	ECS300.11	RECTIFIER
12	ECS350.12	FUSE SUPPORT

Item	Part No.	Description
13	ECS300.13	POWER OUTLET
14	ECS300.14	NEGATIVE CABLE
15	ECS300.15	POWER SUPPLY CABLE
16	ECS650.16	THERMOSTAT 13A
17	ECS650.17	THERMOSTAT 11A
18	ECS350.18	BASE
19	ECS650.20	POSITIVE CLAMP
19A	ECS650.20A	NEGATIVE CLAMP
20	ECS300.20	POSITIVE CABLE
21	120/122351	FUSE 80Amp 40x11mm
22	ECS350.22	OUTPUT KNOB KIT

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.