

Accessories

Category		Description		Parts no	Parts no	Illustration
Colour Lens (Acrylic resin)	Round	CONCAVE		<input type="checkbox"/> blue <input type="checkbox"/> green <input type="checkbox"/> orange <input type="checkbox"/> red <input type="checkbox"/> white <input type="checkbox"/> yellow	50-001-01 50-001-02 50-001-03 50-001-04 50-001-05 50-001-06	
	Rectangular	CONCAVE		<input type="checkbox"/> blue <input type="checkbox"/> green <input type="checkbox"/> orange <input type="checkbox"/> red <input type="checkbox"/> white <input type="checkbox"/> yellow	50-002-01 50-002-02 50-002-03 50-002-04 50-002-05 50-002-06	
	Square	CONCAVE		<input type="checkbox"/> blue <input type="checkbox"/> green <input type="checkbox"/> orange <input type="checkbox"/> red <input type="checkbox"/> white <input type="checkbox"/> yellow	50-003-01 50-003-02 50-003-03 50-003-04 50-003-05 50-003-06	
	Mushroom head	Opaque		<input type="checkbox"/> green <input type="checkbox"/> red	50-012-01 50-012-02	
	Round	Flat		<input type="checkbox"/> blue <input type="checkbox"/> green <input type="checkbox"/> orange <input type="checkbox"/> red <input type="checkbox"/> white <input type="checkbox"/> yellow	50-001-11 50-001-12 50-001-13 50-001-14 50-001-15 50-001-16	
	Rectangular	Flat		<input type="checkbox"/> blue <input type="checkbox"/> green <input type="checkbox"/> orange <input type="checkbox"/> red <input type="checkbox"/> white <input type="checkbox"/> yellow	50-002-11 50-002-12 50-002-13 50-002-14 50-002-15 50-002-16	
	Square	Flat		<input type="checkbox"/> blue <input type="checkbox"/> green <input type="checkbox"/> orange <input type="checkbox"/> red <input type="checkbox"/> white <input type="checkbox"/> yellow	50-003-11 50-003-12 50-003-13 50-003-14 50-003-15 50-003-16	
	Mushroom head	Transparent		<input type="checkbox"/> green <input type="checkbox"/> red	50-012-11 50-012-12	
Lamp	Incandescent	6 V	AC/DC	200 mA	50-004-02	
		14 V	AC/DC	80 mA	50-004-04	
		28 V	AC/DC	40 mA	50-004-05	
		48 V	AC/DC	25 mA	50-004-06	
		60 V	AC/DC	20 mA	50-004-07	
		33 V	AC/DC	35 mA	50-004-08	
		14 V	AC/DC	40 mA	50-004-03	
	6 V	AC/DC	40 mA	50-004-01		
	Neon	110 V	AC	green	50-004-11	
		220 V	AC	red	50-004-12	
			green	50-004-13		
LED	6 V	DC	green	50-004-16		
			red	50-004-17		
			yellow	50-004-18		
	12 V	DC	green	50-004-19		
			red	50-004-20		
			yellow	50-004-21		
	24 V	DC	green	50-004-22		
red			50-004-23			
		yellow	50-004-24			

Accessories

Category	Description	Parts No	Illustration
Lamp Extractor	Removing lamp tool	50-005-01	
Blanking Plate Block	PVC stopper to stuff the superfluous hole of the panel board	50-013-01	
Connector	Insulation Socket 2.8 × 0.5 mm	50-014-01	
PCB Socket Mounting	Socket insert into PCB board is available for socket type pushbutton switch installation	50-015-01	
Mounting Wrench	Use this for tightening the switch in the mounting hole	50-006-01	
Lens Removing	Use this for replaced the fitting color lens	50-007-01	
Spray Cover	Meets requirement of IP65, two pieces of transparent plastic, rectangular head	50-010-01	
Protection Cap	To avoid faulty operation, housing for locking, transparent For square head (90 °) For square head (180 °) For rectangular head (90 °) For rectangular head (180 °)	50-011-01 50-011-11 50-011-02 50-011-12	