Power Swap Controller Batteries



Experience zero downtime /

Why do controller batteries always die at the worst possible moment? With Power Swap Controller Batteries, that's a question you never have to answer. Power Swap Controller Batteries cut the cord and set you free by delivering uninterrupted gameplay and zero controller downtime. The quick-release batteries swap on-the-fly with one hand during gameplay, no pause needed. Low battery indicator lets you know when it's time to find a safe place in the game to swap batteries and maintain game dominance without loss of power or controller connection. The included dock charges both batteries simultaneously and keeps the backup battery fully charged until you need it. Power Swap Controller Batteries deliver all the power you need with the gaming industry's FIRST on-the-fly hot-swap design that keeps your attention where it should be, in the game.

Features /

- Continuous power eliminates need to resync
- Never connect controller to console to charge again
- Reserve energy cell sustains controller power while you swap
- · Low battery alert illuminates hands, always know when you're running low
- Optimized for natural controller balance and feel
- Dock charges two batteries simultaneously
- Backup battery always ready
- LEDs display charging status and battery life
- Able to charge individual batteries via USB-C cable
- Compatible with Xbox One and Xbox X | S controllers
- Compatible with all OtterBox gaming products
- Proven durability withstands the test of time
- Hassle-free customer service
- Each battery delivers up to 10+ hours of unterhered playtime

*up to 30 seconds

Tech Specs /

Product Name:	Power Swap Controller Batteries
Device Compatibility:	Xbox Series One and Xbox Series X S
Unit Dimensions:	1.44 x 1.45 x 1.03 in 3.66 x 3.69 x 2.61 cm
Unit Weight:	0.40 lbs 179.87 g
Languages:	en/fr/de/es/it/pt/ja/ko/zh/zht
Master Carton Quantity:	10
Master Carton Weight:	9.64 lb 4371.70 g
Master Carton Dimensions:	15.16 x 8.47 x 11.42 in 38.51 x 21.51 x 29.01 cm
Retail Carton Dimensions:	6.00 x 7.81 x 2.88 in 15.24 x 19.84 x 7.30 cm



BLACK 77-80482 840104230091



LOW BATTERY ALERT ILLUMINATES HANDS, ALWAYS KNOW WHEN YOU'RE RUNNING LOW



RESERVE ENERGY CELL SUSTAINS CONTROLLER POWER WHILE YOU SWAP



V GIVING BACK

otterbox.com/givingback

©2021 Otter Products, LLC. All rights reserved. The OtterBox name and OtterBox trademarks are the property of Otter Products, LLC, registered in the U.S. and other countries. All other trademarks are the property of their respective owners. *Source: The NPD Group/Consumer Tracking Service, US, January 2016 – July 2019