



Item	Part No.	Description
1	CP108VCSBO.01	Housing Screw
2	CP108VCSBO.02	Handle Complete
3	CP108VCSBO.03	Trigger
4	CP108VCSBO.04	Trigger Spring
5	CP108VCSBO.05	Lever
6	CP108VCSBO.06	Microswitch
7	CP108VCSBO.07	PCB
8	CP108VCSBO.08	Indicator Holder
9	CP108VCSBO.09	Cover
10	CP108VCSBO.10	Screw M4 x 25
11	CP108VCSBO.11	Screw M4 x 15
12	CP108VCSBO.12	Back Cover
13	CP108VCSBO.13	Housing (Inner)

Item	Part No.	Description
14-38	CP108VCSBO.14-38	Motor/Gearbox Assembly
39	CP108VCSBO.39	Guide Ruler
40	CP108VCSBO.40	Base Plate
41	CP108VCSBO.41	Screw M6x30
42	SN6.S	Steel Nut M6 Zinc
43	SN4.S	Steel Nut M4 Zinc
44	FWM4.S	Flat Washer M4
45	CP108VCSBO.45	Tension Knob
--	CP108VCSBO.46	Wrench (Not Shown)
--	CP108VBP	Power Tool Battery 10.8V 2Ah Lithium-ion for SV108 Series (Not Shown)
--	CP108VMC	Battery Charger for 10.8V Lithium-ion SV108 Series (Not Shown)

**NOTE:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice. There may be alternative versions of this product, please contact us should you require this information.

**IMPORTANT:** No liability is accepted for incorrect use of product. Spare parts must be fitted by a competent person

**WARRANTY:** Guarantee is 12 months from purchase date, proof of which will be required for any claim.