c(Ul CE **OIO**-Link US

# **Model Number**

# OBR7500-R101-2EP-IO

Retroreflective sensor with fixed cable

### **Features**

- Miniature design with versatile moun-• ting options
- Extended temperature range ٠ -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and pro-• cess data


## **Product information**

The R101 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design - from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.


The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.


The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.



### **Electrical connection**



## Indicators/operating means



	1	1 Light-on/dark-on changeover switch		
2 Sensitivity adjuster		Sensitivity adjuster		
	3 Operating indicator / dark on			
	4	4 Signal indicator		
	5	Operating indicator / light on		

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



		I
		Accessories
		IO-Link-Master02-USB
	0 7.5 m	IO-Link master, supply via USB port or se-
	0.03 7.5 m	parate power supply, LED indicators, M12
е	10 m	
	H85-2 reflector	plug for sensor connection
	LED	REF-H85-2
	modulated visible red light	Reflector, rectangular 84.5 mm x
	exempt group	84.5 mm, mounting holes
	yes	04.5 mm, mounting holes
	approx. 65 mm at a distance of 1 m	REF-H50
	3.7 °	Reflector, rectangular 51 mm x 61 mm,
	EN 60947-5-2	mounting holes, fixing strap
l parameters		mounting noice, inking strup
	724 a	REF-VR10
	20 a	Reflector, rectangular 60 mm x 19 mm,
))	0 %	mounting holes
ans		-
	LED green:	OFR-100/100
	constantly on - power on	Reflective tape 100 mm x 100 mm
	flashing (4Hz) - short circuit	
	flashing with short break (1 Hz) - IO-Link mode	REF-H33
	Yellow LED: Permanently lit—light path clear	Reflector with screw fixing
	Permanently off—object detected	Other quitable appearing and be found at
	Flashing (4 Hz)—operating reserve not reached	Other suitable accessories can be found at
	Light-on/dark-on changeover switch	www.pepperl-fuchs.com
	sensitivity adjustment	
r	IO link communication: green LED goes out briefly (1 Hz)	
U <sub>B</sub>	10 30 V DC	
- 0	max. 10 %	
I <sub>0</sub>	< 25 mA at 24 V supply voltage	
-0	III	
	IO-Link ( via C/Q = pin 4 )	
	COM 2 (38.4 kBaud)	
	1.1	
	2.3 ms	
	Process data input 2 Bit	
	Process data input 2 Bit	
	yes	
	0x110201 (1114625)	
уре	A	
<b>)</b> po		
	The switching type of the sensor is adjustable. The default set-	
	ting is:	
	C/Q - BK: NPN normally open / dark-on, PNP normally closed /	
	light-on, IO-Link	
	/Q - WH: NPN normally closed / light-on, PNP normally open / dark-on	
	2 push-pull (4 in 1)outputs, short-circuit protected, reverse pola-	
	rity protected, overvoltage protected	
	max. 30 V DC	
	max. 100 mA , resistive load	
	DC-12 and DC-13	
U <sub>d</sub>	≤ 1.5 V DC	
f	1000 Hz	
4	0.5 ms	
	-40 60 °C (-40 140 °F) , fixed cable	
	-25 60 °C (-13 140 °F) , movable cable not appropriate for	
	conveyor chains	
	-40 70 °C (-40 158 °F)	
ns		
	IP67 / IP69 / IP69K	
	2 m fixed cable	
	PC (Polycarbonate)	
	PMMA	
	approx. 36 g	
	2 m	
rds and directi-		
8/EC	EN 60947-5-2·2007 ± Δ1·2012	

## **Technical data** General specifications

Effective detection range

Reflector distance Threshold detection range Reference target Light source Light type LED risk group labelling Polarization filter Diameter of the light spot Angle of divergence Ambient light limit Functional safety related MTTF<sub>d</sub> Mission Time (T<sub>M</sub>) Diagnostic Coverage (DC) Indicators/operating mea Operation indicator Function indicator Control elements Control elements Parameterization indicator Electrical specifications Operating voltage Ripple No-load supply current Protection class Interface Interface type Transfer rate **IO-Link Revision** Min. cycle time Process data witdh SIO mode support Device ID Compatible master port ty Output Switching type Signal output Switching voltage Switching current Usage category Voltage drop Switching frequency Response time Ambient conditions Ambient temperature Storage temperature Mechanical specifications Degree of protection Connection Material Housing Optical face Mass Cable length Compliance with standard

# ves Directive conformity EMC Directive 2004/108/EC

Standard conformity

Pepperl+Fuchs Group

www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

EN 60947-5-2:2007 + A1:2012

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

2

#### Product standard


Standards


EN 60947-5-2:2007 + A1:2012 IEC 60947-5-2:2007 + A1:2012 UL 60947-5-2: 2014 IEC 61131-9:2013 EN 62471:2008 EN 61131-9:2013

### Approvals and certificates UL approval


E87056 , cULus Listed , class 2 power supply , type rating 1

### **Curves/Diagrams**





## **Functions and Operation**



- 1 Light-on / dark-on changeover switch
- 2 Sensing range /sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range adjuster for more than 180 degrees.

## Sensing Range / Sensitivity

Turn sensing range / sensivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range /sensivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



## Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on / dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

### **Restore Factory Settings**

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensivity adjustment is locked. In order to reactivate the sensing range /sensivity adjustment, turn the sensing range / sensivity adjuster for more than 180 degrees.

4

