

# MAX38889A Evaluation Kit

Evaluates: MAX38889

## General Description

The MAX38889A evaluation kit (EV kit) evaluates the MAX38889 supercapacitor backup regulator, which is designed to transfer power between a supercapacitor and a system supply rail. When the main battery is present and above the minimum system voltage for charging, the MAX38889 charges the supercapacitor with an average current of 1.5A.

Once the supercapacitor is charged, the circuit draws only 4 $\mu$ A of current while it maintains the supercapacitor in its ready state. When the main battery is removed, the MAX38889 draws power from the supercapacitor and regulates the system voltage to the set backup voltage with a programmed maximum peak inductor current of 3A. The MAX38889 is externally programmable for maximum supercapacitor voltage, system backup voltage, peak charging, and peak backup inductor currents.

## Features and Benefits

- 2.5V to 5.5V System Output Voltage Range
- 0.5V to 5.5V Supercapacitor Voltage Range
- 3A Peak Charging and Backup Inductor Currents
- Resistor-Adjustable VSYS, VCAP Voltages
- Resistor-Adjustable Charging and Backup Currents
- Proven Two-Layer, 2oz Copper PCB Layout
- Demonstrates Compact Solution Size
- Fully Assembled and Tested

## MAX38889A EV Kit Files

| FILE                    | DESCRIPTION              |
|-------------------------|--------------------------|
| MAX38889A EV BOM        | EV Kit Bill of Materials |
| MAX38889A EV PCB Layout | EV Kit Layout            |
| MAX38889A EV Schematic  | EV Kit Schematic         |

[Ordering Information](#) appears at end of data sheet.

## Quick Start

### Required Equipment

- MAX38889A EV Kit
- 6V, 4A DC Power Supply
- Two Digital Multimeters (DMM)


### Procedure

The EV kit is fully assembled and tested. Use the following steps to verify board operation.

**Caution: Do not turn on the power supply until all connections are completed.**

- 1) Verify that a shunt is installed onto pins 1 and 2, jumper ENC (charging enabled).
- 2) Verify that a shunt is installed onto pins 1 and 2, jumper ENB (backup enabled).
- 3) Verify that jumper LOAD is opened. (No load is connected across VSYS and PGND.)
- 4) Set the power supply output to 3.4V and disable the power supply.
- 5) Connect the power supply between the VSYS and PGND terminal posts.
- 6) Connect the DMM between the VSYS and PGND terminal posts.
- 7) Connect the DMM between the VCAP and PGND terminal posts.
- 8) Enable the power supply and verify that the supercapacitor voltage at VCAP is ramping up and stops at about 2.7V.
- 9) Disable and disconnect the power supply from the VSYS and PGND terminal posts.
- 10) Verify that VSYS regulates to 3V and the supercapacitor starts to discharge.
- 11) Install jumper JU2. (This connects a 4.02 $\Omega$  load across VSYS and PGND.)
- 12) Verify that VSYS regulates to 3V while VCAP is ramping down to 1V.
- 13) Verify that VSYS is 0V when VCAP drops below 1V.

MAX38889A EV Kit Photo



## Detailed Description of Hardware

The MAX38889A EV kit provides a flexible circuit to evaluate the supercapacitor backup regulator. External components allow a wide range of system and supercapacitor voltages as well as charging and discharging currents.

### Charger Enable (ENC)

The MAX38889A EV kit provides a jumper (ENC) to enable or disable the supercapacitor charging by the MAX38889 when VSYS is above the charging threshold. See [Table 1](#) for ENC jumper settings.

**Table 1. ENC**

| SHUNT POSITION | DESCRIPTION                  |
|----------------|------------------------------|
| 1-2*           | EN = VSYS. Charging Enabled  |
| 2-3            | EN = PGND. Charging Disabled |

\*Default position

### System Backup (ENB)

The MAX38889A EV kit provides a jumper (ENB) to enable or disable the MAX38889 system backup while VSYS drops below the backup threshold. See [Table 2](#) for ENB jumper settings.

**Table 2. ENB**

| SHUNT POSITION | DESCRIPTION                |
|----------------|----------------------------|
| 1-2*           | EN = VSYS. Backup Enabled  |
| 2-3            | EN = PGND. Backup Disabled |

\*Default position

### VSYS Load (LOAD)

The MAX38889A EV kit provides a jumper (LOAD) to connect a 4.02Ω resistive load across VSYS and PGND to simulate a discharging scenario during test. See [Table 3](#) for LOAD jumper settings.

**Table 3. LOAD**

| SHUNT POSITION  | DESCRIPTION   |
|-----------------|---|
| 1-2             | Test mode: A 4.02Ω resistive load is connected across VSYS and PGND |
| Any 1 pin only* | Normal operating mode   |

\*Default position

### Charge Mode

When the main battery is present and above the minimum system voltage for charging, the MAX38889 charges the supercapacitor with an average current of 1.5A. The MAX38889A EV kit backup voltage is set to 3V by resistors R5 and R6 with  $V_{FBS} = 1.2V$ .

### Ready Mode

The MAX38889A EV kit maximum supercapacitor voltage is set to 2.7V by resistors R1, R2, and R3 with  $V_{FBCH} = 0.5V$ . Once the supercapacitor is charged to the set maximum charge voltage of 2.7V, the MAX38889 consumes only 4 $\mu$ A current. The MAX38889A EV kit provides a RDY test point to monitor the supercapacitor charge status. The RDY test point will be high when the voltage of the FBCR pin crosses the FBCR threshold ( $V_{TH\_FBCR} = 0.5V$ ) set by R1, R2, and R3. In this EV kit, the VCAP at which RDY goes high is 1.5V. Similarly, when the supercapacitor is providing backup, the RDY flag goes low when the supercapacitor discharges below 1.5V.

### Discharge (Backup) Mode

When the main battery is removed and  $V_{FBS}$  drops to 1.2V, the MAX38889 draws power from the supercapacitor and regulates the VSYS to the set backup voltage. The backup voltage is set to 3V by resistors R5 and R6 with  $V_{FBS} = 1.2V$ .

The MAX38889A EV kit provides a BKB test point to monitor the system backup status. BKB is pulled low when the system is backing up (the supercapacitor is discharging) and pulled high when the system is charging or in idle state.

### Charge/Backup Current Configuration

The MAX38889A EV kit provides a resistor R4 to configure the charge/backup peak inductor current.

The peak inductor current is set by resistor R4 connecting between the ISET and GND pins.

$$\text{Peak charging current (I}_{LX\_CHG}) = 3A \times \left( \frac{33k\Omega}{R4} \right)$$

$$\text{Peak backup current (I}_{LX\_BU}) = 3A \times \left( \frac{33k\Omega}{R4} \right)$$

Set R4 to 33k $\Omega$  to ensure accurate current compliance.

## Ordering Information

| PART            | TYPE   |
|-----------------|--------|
| MAX38889AEVKIT# | EV Kit |

#Denotes RoHS-compliant.

## Component Suppliers

| SUPPLIER          | WEBSITE           |
|-------------------|-------------------|
| AVX               | www.avx.com       |
| Kemet             | www.kemet.com     |
| Murata/TOKO       | www.murata.com    |
| Würth Electronics | www.we-online.com |

Note: Indicate that you are using the MAX38889A when contacting these component suppliers.


## MAX38889A EV Kit Bill of Materials

| ITEM | REF_DES           | QTY | VALUE        | DESCRIPTION   | MFG PART #  | MANUFACTURER                                       |
|------|-------------------|-----|--------------|---|---|--|
| 1    | BKB, RDY          | 2   | N/A          | TEST POINT; PIN DIA=0.1IN;<br>TOTAL LENGTH=0.3IN;<br>BOARD HOLE=0.04IN;<br>WHITE; PHOSPHOR<br>BRONZE WIRE SILVER;                 | 5002  | KEYSTONE   |
| 2    | C1, C6,<br>C7     | 3   | 22µF         | CAP; SMT (1206); 22µF; 10%;<br>10V; X7R; CERAMIC  | GCM31CR71A226KE02   | MURATA   |
| 3    | C2                | 1   | 11F          | CAP; THROUGH HOLE-<br>RADIAL LEAD; 11F; +30%/-<br>10%; 2.7V; ALUMINUM-<br>ELECTROLYTIC;   | SCCS30B116SRBA1   | AVX  |
| 4    | C3                | 1   | 0.47µF       | CAP; SMT (0603); 0.47µF;<br>10%; 16V; X7R; CERAMIC  | C0603C474K4RAC;<br>GRM188R71C474K;<br>EMK107B7474KA;<br>C1608X7R1C474K080AC                           | KEMET; MURATA;<br>TAIYO YUDEN;<br>TDK              |
| 5    | C4, C5            | 2   | 47µF         | CAP; SMT (1210); 47µF; 10%;<br>10V; X7R; CERAMIC  | GRM32ER71A476KE15   | MURATA   |
| 6    | C8                | 1   | 1µF          | CAP; SMT (0603); 1µF; 10%;<br>16V; X7R; CERAMIC   | C0603C105K4RAC;<br>C1608X7R1C105K080AC;<br>EMK107B7105KA;<br>CGA3E1X7R1C105K080AC<br>; 0603YC105KAT2A | KEMET; MURATA;<br>TDK; TAIYO<br>YUDEN; TDK;<br>AVX |
| 7    | C11               | 1   | 2200pF       | CAP; SMT (0603); 2200pF;<br>10%; 100V; X7R; CERAMIC   | C0603C222K1RAC  | KEMET  |
| 8    | ENB, ENC          | 2   | PEC03SAAN    | CONNECTOR; MALE;<br>THROUGH HOLE;<br>BREAKAWAY; STRAIGHT;<br>3PINS  | PEC03SAAN   | SULLINS  |
| 9    | GND               | 1   | N/A          | TEST POINT; PIN DIA=0.1IN;<br>TOTAL LENGTH=0.3IN;<br>BOARD HOLE=0.04IN;<br>BLACK; PHOSPHOR<br>BRONZE WIRE SILVER<br>PLATE FINISH; | 5001  | KEYSTONE   |
| 10   | L1                | 1   | 0.47µH       | INDUCTOR; SMT (1008);<br>METAL; 0.47µH; 20%; 4.9A   | DFE252012F-R47M   | MURATA   |
| 11   | LOAD              | 1   | PEC02SAAN    | CONNECTOR; MALE;<br>THROUGH HOLE;<br>BREAKAWAY; STRAIGHT;<br>2PINS  | PEC02SAAN   | SULLINS  |
| 12   | LX, VCAP,<br>VSYN | 3   | 131-4353-00  | CONNECTOR; WIREMOUNT;<br>CIRCUIT BOARD TEST<br>POINT MINIATURE PROBE;<br>STRAIGHT; 4PINS  | 131-4353-00   | TEKTRONICS   |
| 13   | PGND,<br>TP1-TP3  | 4   | 108-0740-001 | CONNECTOR; MALE;<br>PANELMOUNT; BANANA<br>JACK; STRAIGHT; 1PIN  | 108-0740-001  | EMERSON<br>NETWORK<br>POWER                        |
| 14   | R1                | 1   | 499kΩ        | RES; SMT (0603); 499kΩ; 1%;<br>+/-100PPM/DEGC; 0.1000W  | CRCW0603499KFK; ERJ-<br>3EKF4993; RC0603FR-<br>07499KL  | VISHAY DALE;<br>PANASONIC;<br>YAGEO                |
| 15   | R2                | 1   | 402kΩ        | RES; SMT (0603); 402kΩ; 1%;<br>+/-100PPM/DEGC; 0.1000W  | CRCW06034023FK; ERJ-<br>3EKF4023  | VISHAY;<br>PANASONIC                               |


|       |         |    |                   |  |  |  |
|-------|---------|----|-------------------|--|--|--|
| 16    | R3, R6  | 2  | 1.82M $\Omega$    | RES; SMT (0603); 1.82M $\Omega$ ;<br>1%; +/-100PPM/DEGK;<br>0.1000W  | CRCW06031M82FK   | VISHAY   |
| 17    | R4      | 1  | 33k $\Omega$      | RES; SMT (0603); 33k $\Omega$ ; 1%;<br>+/-100PPM/DEGC; 0.1000W   | CRCW060333K0FK   | VISHAY DALE                                      |
| 18    | R5      | 1  | 1.21M $\Omega$    | RES; SMT (0603); 1.21M $\Omega$ ;<br>1%; +/-100PPM/DEGK;<br>0.1000W  | CRCW06031M21FK   | VISHAY   |
| 19    | R7, R8  | 2  | 1M $\Omega$       | RES; SMT (0603); 1M $\Omega$ ; 5%;<br>+/-200PPM/DEGC; 0.1000W  | CRCW06031M00JN   | VISHAY DALE                                      |
| 20    | R9      | 1  | 0 $\Omega$        | RES; SMT (0603); 0 $\Omega$ ;<br>JUMPER; JUMPER; 0.1000W   | CRCW06030000Z0   | VISHAY DALE                                      |
| 21    | R10     | 1  | 4.02 $\Omega$     | RES; SMT (2512); 4.02 $\Omega$ ; 1%;<br>+/-200PPM/DEGK; 1W   | CRCW25124R02FN   | VISHAY DALE                                      |
| 22    | R11     | 1  | 20k $\Omega$      | RES; SMT (0603); 20k $\Omega$ ; 1%;<br>+/-100PPM/DEGC; 0.1000W   | MCR03EZPFX2002; ERJ-<br>3EKF2002; CR0603-FX-<br>2002ELF;<br>CRCW060320K0FK | ROHM;<br>PANASONIC;<br>BOURNS; VISHAY<br>DALE    |
| 23    | SU1-SU3 | 3  | SX1100-B          | TEST POINT; JUMPER; STR;<br>TOTAL LENGTH=0.24IN;<br>BLACK; INSULATION=PBT;<br>PHOSPHOR BRONZE<br>CONTACT=GOLD PLATED | S1100-B; SX1100-B;<br>STC02SYAN  | KYCON; KYCON;<br>SULLINS<br>ELECTRONICS<br>CORP. |
| 24    | U1      | 1  | MAX38889AA<br>TE+ | IC; REG; REVERSIBLE<br>BUCK/BOOST REGULATOR;<br>TQFN16-EP  | MAX38889AATE+  | MAXIM  |
| 25    | PCB     | 1  | PCB               | PCB:MAX38889A  | MAX38889A  | MAXIM  |
| 26    | J2-J5   | 0  | MAXIMPAD          | EVK KIT PARTS; MAXIM<br>PAD; WIRE; NATURAL;<br>SOLID; WEICO WIRE; SOFT<br>DRAWN BUS TYPE-S;<br>20AWG                 | 9020 BUSS  | WEICO WIRE                                       |
| TOTAL |         | 39 |                   |  |  |  |




MAX38889A EV Kit PCB Layout




MAX38889A EV Kit Component Placement Guide—Top Silkscreen



MAX38889A EV Kit PCB Layout—Top



MAX38889A EV Kit PCB Layout—Bottom



MAX38889A EV Kit Component Placement Guide—Bottom Silkscreen



**Revision History**

| REVISION NUMBER | REVISION DATE | DESCRIPTION     | PAGES CHANGED |
|-----------------|---------------|-----------------|---------------|
| 0               | 4/21          | Initial release | —             |

For pricing, delivery, and ordering information, please visit Maxim Integrated's online storefront at <https://www.maximintegrated.com/en/storefront/storefront.html>.

*Maxim Integrated cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim Integrated product. No circuit patent licenses are implied. Maxim Integrated reserves the right to change the circuitry and specifications without notice at any time. The parametric values (min and max limits) shown in the Electrical Characteristics table are guaranteed. Other parametric values quoted in this data sheet are provided for guidance.*