



CYJV.E191684

Cable Assemblies and Fittings for Industrial Control and Signal Distribution

[Page Bottom](#)

Cable Assemblies and Fittings for Industrial Control and Signal Distribution

[See General Information for Cable Assemblies and Fittings for Industrial Control and Signal Distribution](#)

IFM ELECTRONIC GMBH

E191684

FRIEDRICHSTRASSE 1

45128 ESSEN, GERMANY



Trademark and/or Tradename: "ifm" , "www.ifm.com" ,

Cable assemblies, "Series M12", Model(s) V, followed by DO, followed by A or G, followed by H, followed by 02, 03, 04 or 05, followed by 0, 2 or 3, followed by MS or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 02, 03, 04 or 05, followed by ST, followed by A or G, followed by H, followed by 02, 03, 04 or 05, followed by 0, followed by MS or VA followed by S.

V, followed by DO, followed by A or G, followed by H, followed by 03, 04 or 05, followed by 0, 2 or 3, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03, 04 or 05, followed by ST, followed by A or G, followed by H, followed by 03, 04 or 05, followed by 0, followed by VA, followed by S.

V, followed by DO, followed by A or G, followed by H, followed by 04 or 05, followed by 0 or 3, followed by SC, followed by S, followed by four numbers (xxxx), followed by T, followed by 04 or 05, followed by ST, followed by A or G, followed by H, followed by 04 or 05, followed by 0, followed by SC, followed by S.

Cable assemblies, "Series M8", Model(s) V, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0 or 2, followed by MS, ZD or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 03 or 04, followed by ST, followed by G, followed by F, followed by 03 or 04, followed by 0, followed by MS, ZD or VA, followed by S.

V, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0 or 2, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04, followed by ST, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by VA, followed by S.

V, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by SC, followed by S, followed by four numbers (xxxx), followed by T, followed by 03 or 04, followed by ST, followed by G, followed by F, followed by 03 or 04, followed by 0, followed by SC, followed by S.

Cable assemblies, "Series M8-M12", Model(s) V, followed by DO, followed by A or G, followed by F or H, followed by 03 or 04, followed by 0, 2 or 3, followed by MS or VA, followed by S, followed by four digits, followed by H, followed by 03 or 04, followed by ST, followed by A or G, followed by F or H, followed by 03 or 04, followed by 0, followed by MS or VA, followed by S.

V, followed by DO, followed by A or G, followed by F or H, followed by 03 or 04, followed by 0, 2 or 3, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04, followed by ST, followed by A or G, followed by F or H, followed by 03 or 04, followed by 0, followed by VA, followed by S.

V, followed by DO, followed by A or G, followed by F or H, followed by 03 or 04, followed by 0, followed by SC, followed by S, followed by four digits, followed by T, followed by 03 or 04, followed by ST, followed by G, followed by F or H, followed by 03 or 04, followed by 0, followed by SC, followed by S.

Female cable fittings, "Series M12", Model(s) A, followed by DO, followed by A or G, followed by H, followed by 02, 03, 04 or 05, followed by 0, 2 or 3, followed by MS or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 02, 03, 04 or 05.

A, followed by DO, followed by A or G, followed by H, followed by 03, 04 or 05, followed by 0, 2 or 3, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03, 04 or 05.

A, followed by DO, followed by A or G, followed by H, followed by 03, followed by 0, followed by ZD, followed by B, followed by four numbers (xxxx), followed by E, followed by 03.

A, followed by DO, followed by A or G, followed by H, followed by 04 or 05, followed by 0 or 3, followed by SC, followed by S, followed by four numbers (xxxx), followed by T, followed by 04 or 05.

A, followed by DO, followed by A or G, followed by H, followed by 04 or 05, followed by 0, followed by MS, followed by S, followed by four numbers (xxxx), followed by C or K, followed by 04 or 05.

A, followed by DO, followed by A or G, followed by H, followed by 04 or 05, followed by 0, followed by VA, followed by S, followed by four numbers (xxxx), followed by G or L, followed by 04 or 05.

Female cable fittings, "Series M8", Model(s) A, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0 or 2, followed by MS, ZD or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 03 or 04.

A, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0 or 2, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04.

A, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by SC, followed by S, followed by four numbers (xxxx), followed by T, followed by 03 or 04.

Male cable fittings, "Series M12", Model(s) A, followed by ST, followed by A or G, followed by H, followed by 02, 03, 04 or 05, followed by 0, followed by MS or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 02, 03, 04 or 05.

A, followed by ST, followed by A or G, followed by H, followed by 03, 04 or 05, followed by 0, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03, 04 or 05.

A, followed by ST, followed by A or G, followed by H, followed by 04 or 05, followed by 0, followed by SC, followed by S, followed by four numbers (xxxx), followed by T, followed by 04 or 05.

Male cable fittings, "Series M8", Model(s) A, followed by ST, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by MS, ZD or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 03 or 04.

A, followed by ST, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04.

Splitters, "Series M12 to M12", Model(s) Y, followed by DO, followed by A or G, followed by H, followed by 03 or 04, followed by 0 or 2, followed by MS or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 03 or 04, followed by ST, followed by G, followed by H, followed by 04 or 05, followed by 0, followed by MS or VA, followed by S.

Y, followed by DO, followed by A or G, followed by H, followed by 03 or 04, followed by 0 or 2, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04, followed by ST, followed by G, followed by H, followed by 04 or 05, followed by 0, followed by VA, followed by S.

Y, followed by DO, followed by A or G, followed by H, followed by 03 or 04, followed by 0, followed by SC followed by S, followed by four numbers (xxxx), followed by T, followed by 03 or 04, followed by ST, followed by G, followed by H, followed by 04, followed by 0, followed by SC followed by S.

Splitters, "Series M12 to M8", Model(s) Y, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04, followed by ST, followed by G, followed by H, followed by 04, followed by 0, followed by VA, followed by S.

Y, followed by DO, followed by A or G, followed by F, followed by 03, followed by 0, followed by MS or VA followed by S, followed by four numbers (xxxx), followed by H, followed by 03, followed by ST, followed by G, followed by H, followed by 04, followed by 0, followed by MS or VA followed by S.

Y, followed by DO, followed by A or G, followed by F, followed by 03, followed by 0, followed by SC followed by S, followed by four numbers (xxxx), followed by T, followed by 03, followed by ST, followed by G, followed by H, followed by 04, followed by 0, followed by SC followed by S.

Y-Splitters, "Series M12 to M12", Model(s) Z, followed by DO, followed by 2, followed by H, followed by 03, 04 or 05, followed by 0, followed by MS, followed by S, followed by 0000, followed by -, followed by 00, followed by ST, followed by G, followed by H, followed by 04 or 05, followed by 0, followed by MS, followed by S.

Last Updated on 2016-03-04

[Questions?](#)

[Print this page](#)

[Terms of Use](#)

[Page Top](#)

© 2016 UL LLC

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2016 UL LLC".



CYJV2.E191684

Cable Assemblies and Fittings for Industrial Control and Signal Distribution - Component

Page Bottom

Cable Assemblies and Fittings for Industrial Control and Signal Distribution - Component

See General Information for Cable Assemblies and Fittings for Industrial Control and Signal Distribution - Component

IFM ELECTRONIC GMBH

E191684

FRIEDRICHSTRASSE 1
45128 ESSEN, GERMANY

Cable assemblies, Model(s) E10662, E10663, E10700, E10701, E10702, E10703, E10704, E10705, E10745, E10773, E10800, E10801, E10840, E10899, E10900, E10901, E10902, E10903, E10904, E10905, E10906, E10907, E10908, E10909, E10910, E10911, E10912, E10913, E10914, E10915, E10916, E10917, E10953, E10954, E10955, E10956, E10957, E10958, E10959, E10960, E10961, E10962, E10963, E10964, E10965, E10966, E10967, E10968, E11073, E11074, E11075, E11248, E11249, E11250, E11251, E11312, E11767, E11815, E11888, E11904, E11943



Marking: Company name or tradename "ifm" , "www.ifm.com" or trademark and model designation.

Last Updated on 2015-11-11

[Questions?](#)

[Print this page](#)

[Terms of Use](#)

[Page Top](#)

© 2016 UL LLC

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2016 UL LLC".



CYJV7.E191684

Cable Assemblies and Fittings for Industrial Control and Signal Distribution Certified for Canada

Page Bottom

Cable Assemblies and Fittings for Industrial Control and Signal Distribution Certified for Canada

[See General Information for Cable Assemblies and Fittings for Industrial Control and Signal Distribution Certified for Canada](#)

IFM ELECTRONIC GMBH

E191684

FRIEDRICHSTRASSE 1
45128 ESSEN, GERMANY

Cable assemblies, "Series M12", Model(s) V, followed by DO, followed by A or G, followed by H, followed by 02, 03, 04 or 05, followed by 0, 2 or 3, followed by MS or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 02, 03, 04 or 05, followed by ST, followed by A or G, followed by H, followed by 02, 03, 04 or 05, followed by 0, followed by MS or VA followed by S.

V, followed by DO, followed by A or G, followed by H, followed by 03, 04 or 05, followed by 0, 2 or 3, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03, 04 or 05, followed by ST, followed by A or G, followed by H, followed by 03, 04 or 05, followed by 0, followed by VA, followed by S.

V, followed by DO, followed by A or G, followed by H, followed by 04 or 05, followed by 0 or 3, followed by SC, followed by S, followed by four numbers (xxxx), followed by T, followed by 04 or 05, followed by ST, followed by A or G, followed by H, followed by 04 or 05, followed by 0, followed by SC, followed by S.

Cable assemblies, "Series M8", Model(s) V, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0 or 2, followed by MS, ZD or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 03 or 04, followed by ST, followed by G, followed by F, followed by 03 or 04, followed by 0, followed by MS, ZD or VA, followed by S.

V, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0 or 2, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04, followed by ST, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by VA, followed by S.

V, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by SC, followed by S, followed by four numbers (xxxx), followed by T, followed by 03 or 04, followed by ST, followed by G, followed by F, followed by 03 or 04, followed by 0, followed by SC, followed by S.

Cable assemblies, "Series M8-M12", Model(s) V, followed by DO, followed by A or G, followed by F or H, followed by 03 or 04, followed by 0, 2 or 3, followed by MS or VA, followed by S, followed by four digits, followed by H, followed by 03 or 04, followed by ST, followed by A or G, followed by F or H, followed by 03 or 04, followed by 0, followed by MS or VA, followed by S.

V, followed by DO, followed by A or G, followed by F or H, followed by 03 or 04, followed by 0, 2 or 3, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04, followed by ST, followed by A or G, followed by F or H, followed by 03 or 04, followed by 0, followed by VA, followed by S.

V, followed by DO, followed by A or G, followed by F or H, followed by 03 or 04, followed by 0, followed by SC, followed by S, followed by four digits, followed by T, followed by 03 or 04, followed by ST, followed by G, followed by F or H, followed by 03 or 04, followed by 0, followed by SC, followed by S.

Female cable fittings, "Series M12", Model(s) A, followed by DO, followed by A or G, followed by H, followed by 02, 03, 04 or 05, followed by 0, 2 or 3, followed by MS or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 02, 03, 04 or 05.

A, followed by DO, followed by A or G, followed by H, followed by 03, 04 or 05, followed by 0, 2 or 3, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03, 04 or 05.

A, followed by DO, followed by A or G, followed by H, followed by 03, followed by 0, followed by ZD, followed by B, followed by four numbers (xxxx), followed by E, followed by 03.

A, followed by DO, followed by A or G, followed by H, followed by 04 or 05, followed by 0 or 3, followed by SC, followed by S, followed by four numbers (xxxx), followed by T, followed by 04 or 05.

A, followed by DO, followed by A or G, followed by H, followed by 04 or 05, followed by 0, followed by MS, followed by S, followed by four numbers (xxxx), followed by C or K, followed by 04 or 05.

A, followed by DO, followed by A or G, followed by H, followed by 04 or 05, followed by 0, followed by VA, followed by S, followed by four numbers (xxxx), followed by G or L, followed by 04 or 05.

Female cable fittings, "Series M8", Model(s) A, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0 or 2, followed by MS, ZD or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 03 or 04.

A, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0 or 2, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04.

A, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by SC, followed by S, followed by four numbers (xxxx), followed by T, followed by 03 or 04.

Male cable fittings, "Series M12", Model(s) A, followed by ST, followed by A or G, followed by H, followed by 02, 03, 04 or 05, followed by 0, followed by MS or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 02, 03, 04 or 05.

A, followed by ST, followed by A or G, followed by H, followed by 03, 04 or 05, followed by 0, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03, 04 or 05.

A, followed by ST, followed by A or G, followed by H, followed by 04 or 05, followed by 0, followed by SC, followed by S, followed by four numbers (xxxx), followed by T, followed by 04 or 05.

Male cable fittings, "Series M8", Model(s) A, followed by ST, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by MS, ZD or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 03 or 04.

A, followed by ST, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04.

Splitters, "Series M12 to M12", Model(s) Y, followed by DO, followed by A or G, followed by H, followed by 03 or 04, followed by 0 or 2, followed by MS or VA, followed by S, followed by four numbers (xxxx), followed by H, followed by 03 or 04, followed by ST, followed by G, followed by H, followed by 04 or 05, followed by 0, followed by MS or VA, followed by S.

Y, followed by DO, followed by A or G, followed by H, followed by 03 or 04, followed by 0 or 2, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04, followed by ST, followed by G, followed by H, followed by 04 or 05, followed by 0, followed by VA, followed by S.

Y, followed by DO, followed by A or G, followed by H, followed by 03 or 04, followed by 0, followed by SC followed by S, followed by four numbers (xxxx), followed by T, followed by 03 or 04, followed by ST, followed by G, followed by H, followed by 04, followed by 0, followed by SC followed by S.

Splitters, "Series M12 to M8", Model(s) Y, followed by DO, followed by A or G, followed by F, followed by 03 or 04, followed by 0, followed by VA, followed by S, followed by four numbers (xxxx), followed by E, followed by 03 or 04, followed by ST, followed by G, followed by H, followed by 04, followed by 0, followed by VA, followed by S.

Y, followed by DO, followed by A or G, followed by F, followed by 03, followed by 0, followed by MS or VA followed by S, followed by four numbers (xxxx), followed by H, followed by 03, followed by ST, followed by G, followed by H, followed by 04, followed by 0, followed by MS or VA followed by S.

Y, followed by DO, followed by A or G, followed by F, followed by 03, followed by 0, followed by SC followed by S, followed by four numbers (xxxx), followed by T, followed by 03, followed by ST, followed by G, followed by H, followed by 04, followed by 0, followed by SC followed by S.

Y-Splitters, "Series M12 to M12", Model(s) Z, followed by DO, followed by 2, followed by H, followed by 03, 04 or 05, followed by 0, followed by MS, followed by S, followed by 0000, followed by -, followed by 00, followed by ST, followed by G, followed by H, followed by 04 or 05, followed by 0, followed by MS, followed by S.



Trademark and/or Tradename: "ifm" , "www.ifm.com" ,

Last Updated on 2016-03-04

[Questions?](#)

[Print this page](#)

[Terms of Use](#)

[Page Top](#)

© 2016 UL LLC

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2016 UL LLC".



CYJV8.E191684

Cable Assemblies and Fittings for Industrial Control and Signal Distribution Certified for Canada - Component

[Page Bottom](#)

Cable Assemblies and Fittings for Industrial Control and Signal Distribution Certified for Canada - Component


[See General Information for Cable Assemblies and Fittings for Industrial Control and Signal Distribution Certified for Canada - Component](#)

IFM ELECTRONIC GMBH

E191684

FRIEDRICHSTRASSE 1
45128 ESSEN, GERMANY

Cable assemblies, Model(s) E10662, E10663, E10700, E10701, E10702, E10703, E10704, E10705, E10745, E10773, E10800, E10801, E10840, E10899, E10900, E10901, E10902, E10903, E10904, E10905, E10906, E10907, E10908, E10909, E10910, E10911, E10912, E10913, E10914, E10915, E10916, E10917, E10953, E10954, E10955, E10956, E10957, E10958, E10959, E10960, E10961, E10962, E10963, E10964, E10965, E10966, E10967, E10968, E11073, E11074, E11075, E11248, E11249, E11250, E11251, E11312, E11767, E11815, E11888, E11904, E11943

Marking: Company name or tradename "ifm" , "www.ifm.com" or trademark  , model designation and the Recognized Component Mark for

Canada,  .

[Last Updated on 2015-11-11](#)

[Questions?](#)

[Print this page](#)

[Terms of Use](#)

[Page Top](#)

© 2016 UL LLC

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2016 UL LLC".