MAX14721 Evaluation Kit

Evaluates: MAX14721-MAX14723

General Description

The MAX14721 evaluation kit (EV kit) is a fully assembled and tested circuit board that demonstrates the MAX14721 overvoltage, undervoltage, and overcurrent-protection device. The EV kit features an external pMOSFET and LED input/output reading. The EV kit comes with the MAX14721ATP+ installed, but can also be used to evaluate the pin-compatible MAX14722 and MAX14723 devices with IC replacement of U1. Request samples from Maxim when ordering the EV kit.

Features

- 5.5V to 58V Operating Voltage Range
- External pMOSFET Installed
- Proven PCB Layout
- Fully Assembled and Tested

EV Kit Contents

• EV kit board containing a MAX14721

Ordering Information appears at end of data sheet.

Quick Start

Required Equipment

- MAX14721 EV kit
- 40V DC power supply
- 5V DC power supply
- Multimeter

Procedure

The EV kit is fully assembled and tested. Follow the steps below to verify board operation:

- 1) Verify that all jumpers are in their default positions.
- Set the 40V DC power supply to 10V and connect to VIN (TP1).
- 3) Connect the 5V DC power supply to VIO (TP21).
- 4) Turn on both power supplies. Verify that LED1 is on and FLAG (TP15) is 0V.
- 5) Increase voltage on the DC power supply to TP1 and verify that LED2 turns on when voltage reaches ~12.4V. Check that the voltage on VOUT (TP5) is ~12.5V and FLAG (TP15) is 5V.
- 6) Increase the voltage on the DC power supply to TP1 and verify that LED2 turns off when the voltage reaches ~36V. Check that the voltage on VOUT (TP5) goes down and FLAG (TP15) is 0V.
- 7) Decrease the voltage on the DC power supply to TP1 and verify that LED2 turns on when the voltage reaches ~35V. Check that the voltage on VOUT (TP5) is ~35V and FLAG (TP15) is 5V.
- 8) Decrease the voltage on the DC power supply to TP1 and verify that LED2 turns off when the voltage reaches ~12V. Check that voltage on VOUT (TP5) goes down and FLAG (TP5) is 0V.



Table 1. LED Indicators (LED1, LED2)

LED	DESCRIPTION
LED1	LED1 is on when IN is powered
LED2	LED2 is on when OUT is powered

Evaluates: MAX14721-MAX14723

Detailed Description of Hardware The EV kit is a fully assembled and tested circulations.

The EV kit is a fully assembled and tested circuit board demonstrating the MAX14721 overvoltage, undervoltage, and overcurrent-protection device in a 20-pin, surface-mount TQFN-EP package.

Note that when the input supply voltage is higher than 36V, the current-to-input increases due to the current going to 36V TVS (D2). If a current measurement beyond 36V is desired, remove D2 to get an accurate measurement.

LED Indicators

The EV kit features LEDs to indicate the power for input and output (see Table 1).

Enable Inputs (EN, HVEN)

Use JU1 and JU12 to enable the device (see <u>Table 2</u> for jumper settings and Table 3 for enable input switch status).

Overvoltage-Lockout Threshold (OVLO)

Use JU3 and JU5 to select the internal/external OVLO threshold. Install a shunt on either JU3 or JU5, but not both at the same time (see Table 4 for jumper settings).

Undervoltage-Lockout Threshold (UVLO)

Use JU4 and JU6 to select the internal/external UVLO threshold. Install a shunt on either JU4 or JU6, but not both at the same time (see Table 5 for jumper settings).

Table 2. Enable Inputs Jumper Settings (JU1, JU12)

JUMPER	SHUNT POSITION	DESCRIPTION
11.14	1-2	HVEN is connected to VIN
JU1	2-3*	HVEN is connected to GND
11.14.0	Installed	EN is high
JU12	Not installed*	EN is low

^{*}Default position.

Table 3. Enable Inputs Switch Status

EN	HVEN	HVEN SWITCH STATUS	
0	0	On	
1 0		On	
0	1	Off	
1	1	On	

Table 4. OVLO Threshold Jumper Settings (JU3, JU5)

JUMPER SHUNT POSITION		DESCRIPTION
JU3	Installed*	OVLO is connected to ground; internal OVLO threshold is used (do not install JU5)
303	Not installed	OVLO is open
JU5	Installed	OVLO is connected to an external voltage-divider; use R2/R3 or R6 to set overvoltage threshold (do not install JU3)
	Not installed*	OVLO is open

^{*}Default position.

Table 5. UVLO Threshold Jumper Settings (JU4, JU6)

JUMPER SHUNT POSITION		DESCRIPTION		
JU4	Installed*	UVLO is connected to ground; internal UVLO threshold is used (do not install JU6)		
304	Not installed	UVLO is open		
JU6	Installed	UVLO is connected to an external voltage-divider; use R4/R5 or R7 to set the undervoltage threshold (do not install JU4)		
	Not installed*	UVLO is open		

^{*}Default position.

Current-Limit Threshold Current-Limit Mode

Use JU7-JU10 to use different resistors to program the current-limit threshold (see Table 6 for jumper settings).

Reverse Current-Blocking

Use JU13 to enable/disable reverse current-blocking (see Table 7 for jumper settings). RIPEN is usually pulled up high from VIO. When there is only power on OUT and no power on VIO, RIPEN needs to be high to avoid damaging the input. Set JU13 to 1-2 in this case. To evaluate the reverse current-blocking feature, replace C1 with 100nF X7R ceramic capacitor.

Use JU14 and JU15 to select the current-limit mode (see <u>Table 8</u> for jumper settings and <u>Table 9</u> for current-limit type select).

Evaluates: MAX14721-MAX14723

Table 6. Current-Limit Threshold Jumper Settings (JU7-JU10)

JUMPER	SHUNT POSITION	DESCRIPTION
JU7	Installed*	SETI is connected to ground with a 62kΩ resistor (~0.2A current limit)
307	Not installed	SETI is not connected to ground with a 62kΩ resistor
11.10	Installed	SETI is connected to ground with a 13kΩ resistor (~0.9A current limit)
JU8	Not installed*	SETI is not connected to ground with a 13kΩ resistor
JU9	Installed	SETI is connected to ground with a 6.8kΩ resistor (~1.8A current limit)
109	Not installed*	SETI is not connected to ground with a 6.8kΩ resistor
11.140	Installed	SETI is connected to ground with a 100kΩ potentiometer (programmable current limit)
JU10	Not installed*	SETI is not connected to ground with a 100kΩ potentiometer

^{*}Default position.

Table 7. Reverse Current-Blocking Jumper Settings (JU13)

JUMPER SHUNT POSITION		DESCRIPTION
	Open	RIPEN is low (disable)
JU13	1-2	RIPEN is high (enable) from either IN or OUT
	2-3*	RIPEN is high (enable) from VIO

^{*}Default position.

Table 8. Current Limit Type Jumper Settings (JU14, JU15)

JUMPER SHUNT POSITION		DESCRIPTION
11.14.4	Installed*	CLTS2 is low
JU14	Not installed	CLTS2 is high
11145	Installed	CLTS1 is low
JU15	Not installed*	CLTS1 is high

^{*}Default position.

Table 9. Current Limit Type Select (CLTS1, CLTS2)

CLTS2	CLTS1	CURRENT-LIMIT TYPE	
0	0	Latchoff mode	
0	1	Autoretry mode	
1	0	Continuous mode	
1	1	Continuous mode	




Figure 1. MAX14721 EV Kit—Silkscreen Top




Figure 2. MAX14721 EV Kit—Top




Figure 3. MAX14721 EV Kit—Internal 2




Figure 4. MAX14721 EV Kit—Internal 3




Figure 5. MAX14721 EV Kit—Bottom

Component List and Schematic

See the following links for component information and schematic:

- MAX14721 BOM
- MAX14721 Schematic

Ordering Information

PART	TYPE	
MAX14721EVKIT#	EVKIT	

#Denotes RoHS compliant.

MAX14721 Evaluation Kit

Evaluates: MAX14721-MAX14723

Revision History

REVISION NUMBER	REVISION DATE	DESCRIPTION	PAGES CHANGED
0	5/15	Initial release	_

For pricing, delivery, and ordering information, please contact Maxim Direct at 1-888-629-4642, or visit Maxim Integrated's website at www.maximintegrated.com.

Maxim Integrated cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim Integrated product. No circuit patent licenses are implied. Maxim Integrated reserves the right to change the circuitry and specifications without notice at any time.

BILL OF MATERIALS - Revision 5/15

Part Reference	Qty	Description
C1,C5	2	CAPACITOR CER 1UF 100V ±10% X7R 1206
C2,C4	2	CAPACITOR RADIAL 10UF 63V ±20%
C3	1	CAPACITOR CER 1UF 6.3V ±10% X5R 0603
D1	1	DIODE 2A 50V
D2	1	DIODE TVS 1500 WATT TRANSIENT VOLTAGE SUPPRESSOR 1A 36V
D3	1	DIODE ZENER 3.3V 0.02A SOT23-3
D4	1	DUAL DIODE 80V 0.25A SOT-963
JU1,JU13	2	CONN HEADER 3PINS
JU3-JU10,JU12,JU14,JU15	11	CONN HEADER 2PINS
LED1	1	LED GREEN 1206
LED2	1	LED YELLOW 1206
Q1	1	P-CHANNEL 60V 50A MOSFET
R1	1	RES 220K OHM 1% 0805 SMD
R6,R7	2	RES TRIMMER POTENTIOMETER 1M OHM
R8	1	RES 62K OHM 1% 0805 SMD
R9	1	RES 13K OHM 1% 0805 SMD
R10	1	RES 6.8K OHM 1% 0805 SMD
R11	1	RES TRIMMER POTENTIOMETER 100K OHM
R12,R13,R15,R16	4	RES 10K OHM 1% 0805 SMD
R14,R21	2	RES 100K OHM 1% 0805 SMD
R17,R18	2	RES 2.7K OHM 1% 0805 SMD
R19,R20	2	RES 0 OHM 0805 SMD
R22,R23	2	RES 10K OHM 5% 0.5W 0805 SMD
TP1,TP2,TP5,TP6,TP17,TP18	6	RED TEST POINT
TP3,TP4,TP7,TP8,TP22-TP27	10	BLACK TEST POINT
TP9,TP10,TP14,TP16,TP20	5	YELLOW TEST POINT
TP11-TP13,TP15,TP19	5	WHITE TEST POINT
TP21	1	ORANGE TEST POINT
U1	1	IC OVERCURRENT OVERVOLTAGE PROTECTOR (MAX14721ATP+)
	1	PCB: EPCB14721
	10	SHUNT
DNI		
R2-R5	0	RESISTOR; 0805 PACKAGE; GENERIC

