## **SIEMENS**

Data sheet 3RB3026-1NE0



OVERLOAD RELAY 0.32...1.25 A FOR MOTOR PROTECTION SIZE S0, CLASS 10 CONTACTOR ASS. MAIN CIRCUIT: SPR.-LOAD.TERM. AUX.CIRCUIT: SPR.-LOAD.TERM. MANUAL-AUTOM.-RESET

product brand name	SIRIUS
Product designation	solid-state overload relay

General technical data:			
Active power loss total typical	W	0.1	
Insulation voltage			
<ul> <li>with degree of pollution 3 Rated value</li> </ul>	V	690	
Shock resistance			
• acc. to IEC 60068-2-27		15g / 11 ms	
Vibration resistance		1-6 Hz, 15 mm; 6-500 Hz, 20 m/s <sup>2</sup> ; 10 cycles	
Surge voltage resistance Rated value	kV	6	
Size of contactor can be combined company-specific		S0	
Type of assignment		2	
Protection class IP			
• on the front		IP20	
• of the terminal		IP20	
Type of protection		II (2) G [Ex e] [Ex d] [Ex px] II (2) D [Ex t] [Ex p]	
Equipment marking			
• acc. to DIN EN 61346-2		F	
• acc. to DIN EN 81346-2		F	

Main circuit:		
Number of poles for main current circuit		3
Adjustable response value current of the current- dependent overload release	A	0.32 1.25
Operating voltage		
<ul> <li>at AC-3 Rated value maximum</li> </ul>	V	690

Operating current  • at AC-3  — at 400 V Rated value  Auxiliary circuit:  Number of NC contacts  • for auxiliary contacts  — Note  Number of NO contacts  • for auxiliary contacts  — Note  Number of CO contacts  • for auxiliary contacts  — Note  Number of CO contacts  • for auxiliary contacts  — Note  Operating current of the auxiliary contacts at AC-15  • at 24 V  • at 110 V  • at 125 V  • at 230 V  Operating current of the auxiliary contacts at DC-13  • at 24 V  • at 60 V  • at 110 V  • at 125 V  • at 220 V  A  Protective and monitoring functions:  Trip class	1.25  1 for contactor disconnection  1 for message "tripped"  0 integrated  4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4
at AC-3 — at 400 V Rated value  Auxiliary circuit:  Number of NC contacts  • for auxiliary contacts — Note  Number of NO contacts  • for auxiliary contacts — Note  Number of CO contacts  • for auxiliary contacts  • for auxiliary contacts  • for auxiliary contacts  Design of the auxiliary switch  Operating current of the auxiliary contacts at AC-15  • at 24 V • at 110 V • at 125 V • at 230 V  Operating current of the auxiliary contacts at DC-13  • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V  Protective and monitoring functions:	1 for contactor disconnection  1 for message "tripped"  0 integrated  4 4 4 4 3
Auxiliary circuit:  Number of NC contacts  • for auxiliary contacts  — Note  Number of NO contacts  • for auxiliary contacts  — Note  Number of CO contacts  • for auxiliary contacts  • for auxiliary contacts  • for auxiliary switch  Operating current of the auxiliary contacts at AC-15  • at 24 V  • at 110 V  • at 125 V  • at 230 V  Operating current of the auxiliary contacts at DC-13  • at 24 V  • at 60 V  • at 110 V  • at 125 V  • at 220 V  Protective and monitoring functions:	1 for contactor disconnection  1 for message "tripped"  0 integrated  4 4 4 4 3
Auxiliary circuit:  Number of NC contacts  • for auxiliary contacts  — Note  Number of NO contacts  • for auxiliary contacts  — Note  Number of CO contacts  • for auxiliary contacts  Design of the auxiliary switch  Operating current of the auxiliary contacts at AC-15  • at 24 V  • at 110 V  • at 125 V  • at 230 V  Operating current of the auxiliary contacts at DC-13  • at 24 V  • at 60 V  • at 110 V  • at 125 V  • at 220 V  Protective and monitoring functions:	1 for contactor disconnection  1 for message "tripped"  0 integrated  4 4 4 4 3
Number of NC contacts  • for auxiliary contacts  — Note  Number of NO contacts  • for auxiliary contacts  — Note  Number of CO contacts  • for auxiliary contacts  • for auxiliary contacts  Operating current of the auxiliary contacts at AC-15  • at 24 V  • at 110 V  • at 120 V  • at 230 V  Operating current of the auxiliary contacts at DC-13  • at 24 V  • at 60 V  • at 125 V  • at 220 V  A  Protective and monitoring functions:	for contactor disconnection  1 for message "tripped"  0 integrated  4 4 4 3
for auxiliary contacts         — Note  Number of NO contacts         • for auxiliary contacts         — Note  Number of CO contacts         • for auxiliary contacts  Pesign of the auxiliary switch  Operating current of the auxiliary contacts at AC-15          • at 24 V         • at 110 V         • at 125 V         • at 230 V  Operating current of the auxiliary contacts at DC-13         • at 60 V         • at 125 V         • at 125 V         • at 24 V         • at 24 V         • at 24 V         • at 25 V         • at 24 V         • at 25 V         • at 24 V         • at 34 C         • at 35 V	for contactor disconnection  1 for message "tripped"  0 integrated  4 4 4 3
Number of NO contacts  ● for auxiliary contacts  — Note  Number of CO contacts  ● for auxiliary contacts  Design of the auxiliary switch  Operating current of the auxiliary contacts at AC-15  ● at 24 V  ● at 110 V  ● at 125 V  ● at 230 V  Operating current of the auxiliary contacts at DC-13  ● at 24 V  ● at 25 V  ● at 25 V  ● at 25 V  A  Operating current of the auxiliary contacts at DC-13  ● at 24 V  ● at 25 V  ● at 20 V  A  Protective and monitoring functions:	for contactor disconnection  1 for message "tripped"  0 integrated  4 4 4 3
Number of NO contacts  • for auxiliary contacts  — Note  Number of CO contacts  • for auxiliary contacts  Design of the auxiliary switch  Operating current of the auxiliary contacts at AC-15  • at 24 V  • at 110 V  • at 120 V  • at 230 V  Operating current of the auxiliary contacts at DC-13  • at 24 V  • at 230 V  A  Operating current of the auxiliary contacts at DC-13  • at 24 V  • at 60 V  • at 110 V  • at 125 V  • at 220 V  A  Protective and monitoring functions:	for message "tripped"  0 integrated  4 4 4 3
for auxiliary contacts     — Note  Number of CO contacts         • for auxiliary contacts  Design of the auxiliary switch  Operating current of the auxiliary contacts at AC-15         • at 24 V         • at 110 V         • at 125 V         • at 230 V  Operating current of the auxiliary contacts at DC-13         • at 60 V         • at 125 V         • at 125 V         • at 24 V         • at 34 A         • at 35 V         • at 35 V	for message "tripped"  0 integrated  4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4
Number of CO contacts  • for auxiliary contacts  Design of the auxiliary switch  Operating current of the auxiliary contacts at AC-15  • at 24 V  • at 110 V  • at 120 V  • at 230 V  Operating current of the auxiliary contacts at DC-13  • at 24 V  • at 230 V  A  Operating current of the auxiliary contacts at DC-13  • at 24 V  • at 60 V  • at 110 V  • at 125 V  • at 220 V  A  Protective and monitoring functions:	for message "tripped"  0 integrated  4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4
Number of CO contacts  • for auxiliary contacts  Design of the auxiliary switch  Operating current of the auxiliary contacts at AC-15  • at 24 V  • at 110 V  • at 125 V  • at 230 V  Operating current of the auxiliary contacts at DC-13  • at 24 V  • at 60 V  • at 110 V  • at 125 V  • at 220 V  A  Protective and monitoring functions:	o integrated  4 4 4 4 3
for auxiliary contacts  Design of the auxiliary switch  Operating current of the auxiliary contacts at AC-15          • at 24 V         • at 110 V         • at 120 V         • at 230 V  Operating current of the auxiliary contacts at DC-13          • at 24 V         • at 230 V  A  Operating current of the auxiliary contacts at DC-13          • at 60 V         • at 110 V         • at 125 V         • at 220 V  Protective and monitoring functions:	integrated  4 4 4 4 3
Design of the auxiliary switch  Operating current of the auxiliary contacts at AC-15  • at 24 V • at 110 V • at 120 V • at 125 V • at 230 V  Operating current of the auxiliary contacts at DC-13  • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V  Protective and monitoring functions:	integrated  4 4 4 4 3
Operating current of the auxiliary contacts at AC-15  • at 24 V • at 110 V • at 120 V • at 125 V • at 230 V  Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V  Protective and monitoring functions:	4 4 4 4 3
<ul> <li>at 24 V</li> <li>at 110 V</li> <li>at 120 V</li> <li>at 125 V</li> <li>at 230 V</li> </ul> Operating current of the auxiliary contacts at DC-13 <ul> <li>at 24 V</li> <li>at 60 V</li> <li>at 110 V</li> <li>at 125 V</li> <li>at 220 V</li> </ul> Protective and monitoring functions:	4 4 4 3
at 110 V  at 120 V  at 125 V  at 230 V  A  Operating current of the auxiliary contacts at DC-13  at 24 V  at 60 V  at 110 V  at 125 V  at 220 V  A  Protective and monitoring functions:	4 4 4 3
<ul> <li>at 120 V</li> <li>at 125 V</li> <li>at 230 V</li> <li>A</li> </ul> Operating current of the auxiliary contacts at DC-13 <ul> <li>at 24 V</li> <li>at 60 V</li> <li>at 110 V</li> <li>at 125 V</li> <li>at 220 V</li> </ul> Protective and monitoring functions:	4 4 3
at 125 V  at 230 V  A  Operating current of the auxiliary contacts at DC-13  at 24 V  at 60 V  at 110 V  at 125 V  at 220 V  A  Protective and monitoring functions:	4 3
at 230 V  Operating current of the auxiliary contacts at DC-13      at 24 V     at 60 V     at 110 V     at 125 V     at 220 V  A  Protective and monitoring functions:	3
Operating current of the auxiliary contacts at DC-13  • at 24 V  • at 60 V  • at 110 V  • at 125 V  • at 220 V  A  Protective and monitoring functions:	
<ul> <li>at 24 V</li> <li>at 60 V</li> <li>at 110 V</li> <li>at 125 V</li> <li>at 220 V</li> </ul> Protective and monitoring functions:	2
<ul> <li>at 60 V</li> <li>at 110 V</li> <li>at 125 V</li> <li>at 220 V</li> <li>A</li> </ul> Protective and monitoring functions:	2
at 110 V     at 125 V     at 220 V  A  Protective and monitoring functions:	_
at 125 V     at 220 V  Protective and monitoring functions:  A  A	0.55
• at 220 V  Protective and monitoring functions:	0.3
Protective and monitoring functions:	0.3
	0.11
Trip class	
	CLASS 10
Design of the overload circuit breaker	electronic
UL/CSA ratings:	
Contact rating of the auxiliary contacts acc. to UL	B600 / R300
Short-circuit:	
Design of the fuse link	
for short-circuit protection of the main circuit	
— required	Fuse gG: 6 A
• for short-circuit protection of the auxiliary switch	fuse gG: 6 A
required	
Installation/ mounting/ dimensions:	
mounting position	
Mounting type	any direct mounting

Height	mm	109
Width	mm	45
Depth	mm	85
Required spacing		
<ul><li>with side-by-side mounting</li></ul>		
— forwards	mm	0
— Backwards	mm	0
— upwards	mm	0
— downwards	mm	0
— at the side	mm	0
• for grounded parts		
— forwards	mm	6
— Backwards	mm	0
— upwards	mm	6
— at the side	mm	6
— downwards	mm	6
• for live parts		
— forwards	mm	6
— Backwards	mm	0
— upwards	mm	6
— downwards	mm	6
— at the side	mm	6

Connections/ Terminals:	
Type of electrical connection	
• for main current circuit	spring-loaded terminals
<ul> <li>for auxiliary and control current circuit</li> </ul>	spring-loaded terminals
Arrangement of electrical connectors for main current circuit	Top and bottom
Product function	
<ul> <li>removable terminal for auxiliary and control circuit</li> </ul>	Yes
Type of connectable conductor cross-section	
• for main contacts	
<ul><li>— single or multi-stranded</li></ul>	1x (1 10 mm²)
<ul> <li>finely stranded with core end processing</li> </ul>	1x (1 6 mm²)
<ul> <li>finely stranded without core end processing</li> </ul>	1x (1 6 mm²)
<ul> <li>for AWG conductors for main contacts</li> </ul>	1x (18 8)
<ul> <li>for auxiliary contacts</li> </ul>	
<ul> <li>single or multi-stranded</li> </ul>	1x (0,5 1,5 mm²), 2x (0,5 1,5 mm²)
— finely stranded with core end processing	1x (0.25 1.5 mm²), 2x (0.25 1.5 mm²)

<ul> <li>finely stranded without core end processing</li> </ul>		1x (0.25 1.5 mm²), 2x (0.25 1.5 mm²)
for AWG conductors for auxiliary contacts		1x (24 16), 2x (24 16)
Safety related data:		
Protection against electrical shock		finger-safe
Mechanical data:		
Size of overload relay		S0
Communication/ Protocol:		
Protocol is supported		
IO-Link protocol		No
Type of voltage supply via input/output link master		No
Ambient conditions:		
Installation altitude at height above sea level maximum	m	2 000
Ambient temperature		
during operation	°C	-25 +60
during storage	°C	-40 +80
during transport	°C	-40 +80
Relative humidity during operation	%	95
Electromagnetic compatibility:		
EMC emitted interference		
• acc. to IEC 60947-1		CISPR 11, environment B (residential area)
EMI immunity acc. to IEC 60947-1		corresponds to degree of severity 3
Conducted interference due to burst acc. to IEC 61000-4-4		2 kV (power ports), 1 kV (signal ports) corresponds to degree of severity 3
Conducted interference due to conductor-earth surge acc. to IEC 61000-4-5		2 kV (line to earth) corresponds to degree of severity 3
Conducted interference due to conductor-conductor surge acc. to IEC 61000-4-5		1 kV (line to line) corresponds to degree of severity 3
Field-bound parasitic coupling acc. to IEC 61000-4-3		10 V/m
Electrostatic discharge acc. to IEC 61000-4-2		6 kV contact discharge / 8 kV air discharge
Display:		
Display version		
• for switching status		Slide switch
Certificates/ approvals:		

## General Product Approval EMC

For use in hazardous locations













 $\mathsf{GL}$ 

Declaration of Conformity	Test Certificates		Shipping App	proval	
CE	Type Test Certificates/Test Report	Special Test Certificate	CAN BURNEY PC	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	GL®

Shi	pping	Appi	roval

other



EG-Konf.



Environmental Confirmations

Confirmation

ABS

## Further informatior

Information- and Downloadcenter (Catalogs, Brochures,...)

http://www.siemens.com/industrial-controls/catalogs

Industry Mall (Online ordering system)

http://www.siemens.com/industrymall

Cax online generator

 $\underline{\text{http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en\&mlfb=3RB30261NE0}\\$ 

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)

http://support.automation.siemens.com/WW/view/en/3RB30261NE0/all

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...) http://www.automation.siemens.com/bilddb/cax\_de.aspx?mlfb=3RB30261NE0&lang=en



