Laser thru-beam sensor

OBE20M-R103-S2EP-IO-0,3M-V1-L



Model Number

OBE20M-R103-S2EP-IO-0,3M-V1-L

Laser thru-beam sensor

with fixed cable and M12 connector, 4-pin

Features

- Miniature design with versatile moun-• ting options
- DuraBeam Laser Sensors durable ٠ and employable like an LED
- IO-link interface for service and pro-• cess data
- Various frequencies for avoiding mutual interference (cross-talk immunity)
- Extended temperature range -40°C ... 60°C
- High degree of protection IP69K ٠

Product information


The R103 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design - from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform


practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.


The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.






Electrical connection emitter



Electrical connection receiver



234

Pinout



Wire colors in accordance with EN 60947-5-2 BN WH BU BK (brown (white) (blue) (black)

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Indicators/operating means Laserlabel Emitter 1 Operating indicator CLASS 1 I ASER 1 PRODUCT Receiver 1 Light-on/Dark-on switch 2 1 CLASS 1 LASER PRODUCT 2 Sensitivity adjuster 3 Operating indicator / dark on IEC 60825-1: 2007 certified. æ 4 Signal indicator Complies with 21 CFR 1040.10 and 1040.11 except 5 Operating indicator / light on for deviations pursuant to Laser Notice No. 50, dated June 24, 2007 5 CLASS 1 LASER PRODUCT IEC 60825-1: 2007 certified. Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007 **Accessories** V1-W-2M-PUR Female cordset, M12, 4-pin, PUR cable V1-G-2M-PUR Female cordset, M12, 4-pin, PUR cable IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

Other suitable accessories can be found at www.pepperl-fuchs.com



2

Technical data
leconical data
loominour autu

Release date: 2017-04-04 13:20 Date of issue: 2017-04-04 284464_eng.xml

System components		
Emitter		OBE20M-R103-S-IO-0,3M-V1-L
Receiver		OBE20M-R103-2EP-IO-0,3M-V1-L
General specifications		
Effective detection range		0 20 m
Threshold detection range		30 m
Light source		laser diode
Light type		modulated visible red light
Laser nominal ratings		
Note		LASER LIGHT , DO NOT STARE INTO BEAM
Laser class		1
Wave length		680 nm
Beam divergence		> 5 mrad ; d63 < 2 mm in the range 250 750 mm
Pulse length		1.6 μs max. 17.6 kHz
Repetition rate		9.6 nJ
max. pulse energy Diameter of the light spot		approx. 50 mm at a distance of 20 m
Angle of divergence		approx. 0.3 °
Ambient light limit		EN 60947-5-2 : 30000 Lux
Functional safety related parar	meters	
MTTF _d	inclui o	440 a
Mission Time (T _M)		20 a
Diagnostic Coverage (DC)		0%
Indicators/operating means		
Operation indicator		LED green:
		constantly on - power on
		flashing (4Hz) - short circuit
Function in direct		flashing with short break (1 Hz) - IO-Link mode
Function indicator		Yellow LED: Permanently lit - light path clear
		Permanently off - object detected
		Flashing (4 Hz) - operating reserve not reached
Control elements		Receiver: light/dark switch
Control elements		Receiver: sensitivity adjustment
Parameterization indicator		IO link communication: green LED goes out briefly (1 Hz)
Electrical specifications		
Operating voltage	UB	10 30 V DC
Ripple		max. 10 %
No-load supply current	I ₀	Emitter: ≤ 13 mA
		Receiver: ≤ 13 mA at 24 V supply voltage
Protection class		III
Interface		
Interface type Transfer rate		IO-Link (via C/Q = pin 4) COM 0 (28.4 kBaud)
IO-Link Revision		COM 2 (38.4 kBaud) 1.1
Min. cycle time		2.3 ms
Process data witdh		Emitter:
1 TOCESS GAIA WIGH		Process data output: 2 Bit
		Receiver:
		Process data input: 2 Bit
SIO mode support		Process data output: 2 Bit
Device ID		yes Emitter: 0x110404 (1115140)
		Emitter: 0x110404 (1115140) Receiver: 0x110304 (1114884)
Compatible master port type		A
Input		
Test input		emitter deactivation at +U _B
Output		
Switching type		The switching type of the sensor is adjustable. The default set
		ting is:
		C/Q - Pin4: NPN normally open / dark-on, PNP normally close
		light-on, IO-Link /Q - Pin2: NPN normally closed / light-on, PNP normally open
		dark-on
Signal output		2 push-pull (4 in 1)outputs, short-circuit protected, reverse pol
		rity protected, overvoltage protected
Switching voltage		max. 30 V DC
Switching current		max. 100 mA , resistive load
Usage category		DC-12 and DC-13
Voltage drop	U _d	≤ 1.5 V DC
_ · · · · ·	f	1250 Hz
Switching frequency		0.4 ms
Response time		
Response time Ambient conditions		
Response time		-40 60 °C (-40 140 °F) , fixed cable
Response time Ambient conditions		-25 60 °C (-13 140 °F) , movable cable not appropriate for
Response time Ambient conditions		-40 60 °C (-40 140 °F) , fixed cable -25 60 °C (-13 140 °F) , movable cable not appropriate for conveyor chains -40 70 °C (-40 158 °F)

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com


PEPPERL+FUCHS SENSING YOUR NEEDS 3


Mechanical specifications

Mechanical specifications			
Housing width	15 mm		
Housing height	36.5 mm		
Housing depth	26.7 mm		
Degree of protection	IP67 / IP69 / IP69K		
Connection	300 mm fixed cable with M12 x 1, 4-pin connector		
Material			
Housing	PC (Polycarbonate)		
Optical face	PMMA		
Mass	Emitter: approx. 23 g receiver: approx. 23 g		
Cable length	0.3 m		
Compliance with standards and directi- ves			
Directive conformity			
EMC Directive 2004/108/EC	EN 60947-5-2:2007+A1:2012		
Standard conformity			
Product standard	EN 60947-5-2:2007+A1:2012 IEC 60947-5-2:2007 + A1:2012		
Standards	UL 60947-5-2: 2014 IEC 61131-9:2013 IEC 60825-1:2007 EN 60825-1:2007 EN 61131-9:2013		
Approvals and certificates			
UL approval	E87056 , cULus Listed , class 2 power supply , type rating 1		
	IEC 60825 1:2007 Complice with 21 CEB 1040 10 and		

UL approval FDA approval E87056 , cULus Listed , class 2 power supply , type rating 1 IEC 60825-1:2007 Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007

Curves/Diagrams






Release date: 2017-04-04 13:20 Date of issue: 2017-04-04 284464_eng.xml

4



Functions and Operation



- 1 Light-on / dark-on changeover switch 2 - Sensing range / sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range adjuster / sensitivity adjuster for more than 180 degrees.

Sensing Range/ Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range / sensitivity adjuster for more than 180 degrees.

