Counterbalance Valve BVD

RE 95522/10.08 1/12

Replaces: 04.08

Data sheet

Series 41 Size NG20, 25 Nominal pressure 350 bar Peak pressure 420 bar for travel drives, winch drives and track drives



Contents

Ordering Code / Standard Program	2
Design and Safety Instructions	4
Technical Data	4
Operation	6
Dimensions, Size 20	8
Dimensions, Size 25	9
Fixing the Counterbalance Valve	10
Port Types	11
Cross-References	11
General Instructions	12

Features

- Space-saving installation due to compact design and direct mounting on A2FM(E) and A6VM axial piston motors (series 63)
- Available as a complete set with A2FM(E) and A6VM axial piston motors (series 63) and GFT gear units; test stand run as standard.
- Standard service line ports according to SAE J518
- Integrated brake release valve, with and without pressure reduction
- High efficiency due to low flow resistance
- Easy optimization options during commissioning due to modular design.

Ordering Code / Standard Program

BVD					/	41		ı	٧				
01	02	03	04	05		06	07		08	09	10	11	12

	Valve type	
01	Counterbalance valve, double-acting	в۷
	Size	
	Flow, max. q _{v max} 220 l/min	20

00	How, max. $q_{v \text{ max}}$ 220 mm	20
02	Flow, max. q _{v max} 320 I/min	25

Control range (pressu	re when brake p	iston starts/stops	openina)
-----------------------	-----------------	--------------------	----------

00	730 bar (travel drive)	F	١
03	2040 bar (winch and track drive)	W	ĺ

Ports (size classification)

	. O.13 (O.20	oladolilloation)				
	NG	A2FM/E./.181	A2FE./.171	A6VM./.370	A6VM./.380	
	20	28, 32, 45¹)				16
04		56, 63			55	17
04		80, 90			80	27
			107, 125	107		28
	25	107, 125, 160, 180			107, 140, 160	38

Ports for brake release

05	with high pressure	S	
05	with reduced high pressure 21 ⁺⁴ bar (brake release valve)	L	

Series

П.	[1
10)6	Series 4, Index 1				41	

Long cover

07	B-side (standard)	В	
07	A-side	0	

Seals

FKM (fluor-caoutchouc)	$\overline{}$

Piston version

	r istori version	
	100% of max. flow q _{v max} (see size)	01
09	75% of max. flow q _{v max} (see size)	02
	50% of max. flow q _{v max} (see size)	03

Residual opening in piston

	Residual opening in p	istori	
	Without residual openi	ing (obligatory for winches)	K00
	With residual opening	Ø 1.2	K12
10		Ø 1.6	K16
		Ø 1.8	K18
		Ø 2.0	K20

¹⁾ Intermediate plate necessary for all three sizes

RE 95522/10.08 | BVD Bosch Rexroth AG 3/12

Ordering Code / Standard Program

BVD					/	41		-	٧				
01	02	03	04	05		06	07		08	09	10	11	12

Damping during closing

	Throttle pin	Comparative surface area 0.0361 mm ²	Designation on pin 25		D2500
		0.0520 mm ²	3		D0300
11		0.0836 mm ²	382	2)	D0400
		0.1762 mm ²	55		D0600
		0.2798 mm ²	69 ³	3)	D0800

Flushing cavity

	Plugged		S00
	With ori-	Ø 1.2	S12
	fice (only for A6VM)	Ø 1.6	S16
	IUI AOVIVI)	Ø 1.8	S18

²⁾ Standard for travel drives

Ordering information

When placing the order, the following information is necessary to ensure correct settings at our test stands:

- Motor ordering code
- Counterbalance valve ordering code
- Flow
- Application (e.g. excavator, winch etc.)
- Pressure setting of the secondary pressure relief valves in the motor

Gear unit and/or counterbalance valve and axial piston motor can be ordered as ready-assembled and tested units.

Type selection (Ordering Code)

Size

depends on the necessary flow rate and the available motor port plates.

Control range

defines the pressure range at which the brake piston starts to open.

For travel drives in wheeled vehicles, use code "F":

The control piston opens at a differential pressure between A and B of 7 bar. In this case, the brake is not operated via the port for brake release on the counterbalance valve.

For winch and track drives, use code "W"

The control piston opens at a differential pressure between A and B of 20 bar. This ensures that the mechanical park brake actuated via the brake release port is fully opened (generally at 18 bar) before the brake piston opens.

Ports

depend on the motor size used.

The line ports A and B on the motor port plates are of different distance and diameter. To choose the appropriate connection, please refer to the table in the ordering code and on page 10.

For A2FM/E, sizes 28, 32 and 45, a intermediate plate is required between motor port plate 181 and the counterbalance valve. This intermediate plate is automatically included when motor and counterbalance valve are ordered as a set.

Brake release

The integrated pressure reduction valve is necessary when the mechanical brake on the gear unit cannot handle the full system pressure.

The maximum permitted brake release pressure must be agreed with the winch manufacturer. The brake release valve limits the high pressure to 21...25 bar (4 bar tolerance). It opens at about 10-14 bar.

Piston version ...

depends on the maximum flow across the counterbalance valve.

If for instance the maximum operational flow is only some 110 l/min while using a size 20 counterbalance valve which features a nominal flow of 220 l/min, then select the 50% control piston (code "03"). This ensures smooth operation.

If the desired flow is not within the range of the pistons supplied, please contact us.

Residual opening in piston ...

ensures soft stopping of wheeled vehicles. In winch applications, any residual opening is prohibited, since otherwise the load would not stay suspended. Therefore select code "K00".

Damping

defines the closing speed of the counterbalance valve. The higher the value, the faster the valve closes.

For the initial layout (prototype), we recommend the following damping:

- for wheel drives: D0400

- for winches and track drives: D0800

Flushing cavity

supplies motor flushing oil via an internal port. Only available for A6VM.

³⁾ Standard for winch and track drive

Design and Safety Instructions

Failure to observe any of the following points can lead to uncontrolled working conditions with serious personal injury and material damage:

- The counterbalance valve does not replace the mechanical park brake. Provide appropriate mechanical brake systems.
- Counterbalance valves are only used in open circuit.
- System optimization for the first prototype is recommended with regard to the valve block, axial piston motor, counterbalance valve and park brake.
- The counterbalance valve and main control valve must be matched to one another.
- If a park brake is installed, it must not close until after the counterbalance valve has closed. Otherwise excessive wear will be caused to the brake linings.
- Comply with the maximum control pressure of the park brake. If necessary, use the integrated pressure reduction valve as a brake release valve with reduced high pressure (code "L")
- The counterbalance valve converts the entire kinetic energy/ potential energy into heat during the braking/lowering process.
 Consequently, ensure sufficient cooler and/or tank capacity.

- Counterbalance valves should be operated in combination with close-by secondary pressure relief valves, in order to protect the motor against pressure spikes. The motor port plates for direct installation of the counterbalance valve (A2FM: plate 181; A2FE: plate 171/181; A6VM: plate 370/380) already contain these secondary pressure relief valves.
- Auxiliary boost pressure at port S of the counterbalance valve reliably reduces the risk of cavitation due to lack of fluid in the low-pressure line. Ensure sufficient boost pressure and flow.
- The axial piston motor and counterbalance valve should always be ordered as a complete set. This ensures optimal matching and combined testing.
- If motor and counterbalance valve are ordered separately, consult our application engineers for the appropriate motor version

The above safety measures and instructions must be adapted to the application and extended if necessary.

Technical Data

Hydraulic fluid

4/12

Please refer to the detailed information in our catalog sheets concerning the choice of hydraulic fluids and application conditions (see cross-references on page 11).


Table of values

Table of Values					
Size				20	25
Operating pressure	p	bar	Nominal pressure	350	350
			Peak pressure	420	420
Flow, max.	q _{v max}	l/min		220	320
Opening pressure of brake piston	р	bar	BVD.F	7	7
			BVD.W	20	20
Pressure at which brake piston finishes opening	р	bar	BVD.F	30	30
			BVD.W	40	40
Pressure reduction valve for brake release (fixed values)	р	bar	BVDL/	21+4	21+4
Opening pressure			BVDL/	10+4	10+4
Weight, approx.	m	kg		9	15


Technical Data

Characteristics

Size 20




BVD 20 - boost characteristic (Boost port SM22x1.5)




Size 25

BVD 25...38



BVD 25 - boost characteristic



The above specifications are based on:

- Oil viscosity $v = 41 \text{ mm}^2/\text{s}$
- Oil temperature 9 = 50 °C
- Brake piston fully open
- Piston code 01 (100% $q_{v max}$)


Operation

Travel/winch counterbalance valves are designed to reduce the danger of overspeeding and cavitation of axial piston motors in open controls. Cavitation occurs if the motor speed is greater than it should be for the given flow during braking, downhill travel or decrease in motor load.

BVD circuit diagram

Counterbalance valve with shuttle valve and G_{ext} (plugged).


Ordering code designation "S" for brake release via port Gext-




1) Residual opening


Brake piston

with residual opening (K..) without residual opening (K00)






2) Damping














Operation

Circuit diagram - Travel counterbalance valve BVD..F


Application example

Travel drive for wheeled excavators e.g. A6VM80HA1T/63W-VAB380 + BVD20F27S/41B-V03K16D0400S12

Variable motor with high pressure related control and hydraulic override (HA1T), port plate with integrated pressure-relief valves, prepared for mounting a counterbalance valve (380).

Travel counterbalance valve, size 20 with 50% piston (03) for approx. 110 l/min, internal residual opening in piston for smooth braking (K16),

high damping rate (D0400), internal flushing cavity to motor with 1.2 mm orifice (S12).



Circuit diagram - Winch counterbalance valve BVD..W


Application example

Winch drive in cranes; track drive in crawler excavators

e.g. A2FE160/61W-VAL181 + BVD25W38L/41B-V02K00D0600S00 mounted on a GFT-W Rexroth winch gear unit


Fixed motor with port plate with integrated pressure-relief valves for mounting a counterbalance valve (181).

Winch counterbalance valve, size 25 with pressure reduction valves for brake release pressure (L), with 75% piston (02) for approx. 240 l/min, without internal residual opening (K00, obligatory for winches), low damping rate (D0800).



Other A6VM and A2FM/E axial piston motors can alternatively also be used.

Dimensions, Size 20




- 1) Countersink ø 11x6.5 and through-hole ø 6.6 for 2x M6 mounting screws for fixing the counterbalance valve to the motor. In order to prevent incorrect assembly, the mounting screws must be used (included in the delivery contents)
- 2) Width across flats

Detail X

With shuttle valve and G_{ext} port (code S)

With shuttle valve, brake release valve and Br port (code L)



	B1	B2	В3	B4	ØB5	B6
BVD 2016	66	23.8	50.8	M10x1.5	10.5	25.5
BVD 2017	75	23.8	50.8	M10x1.5	10.5	27.0
BVD 2027	75	27.8	57.2	M12x1.75	13	27.0
BVD 2028	84	27.8	57.2	M12x1.75	13	27.0

Ports

Designa- tion	Operation		Standard	Size 1)	Peak pres- sure (bar) 2)	Status
A, B	Service line port, fixing thread A/B	Version 16, 17	SAE J518 ³⁾ DIN 13	3/4 in M10x1.5; 15 deep	420	0
		Version 27, 28	SAE J518 ³⁾ DIN 13	1 in M10x1.75; 16 deep	420	0
S	Boost port		DIN 3852	M22x1.5; 14 deep	30	Х
Br	Brake release, reduced high pressure	Version L	DIN 3852	M12x1.5; 12.5 deep	30	0
G _{ext}	Brake release, high pressure	Version S	DIN 3852	M12x1.5; 12.5 deep	420	Х


O-rings for connection to mounted axial piston motor

A', B'	Service line port	Version 16, 17	AS 568 A	24.99x3.53 (S-FKM90)	
		Version 27, 28	AS 568 A	32.92x3.53 (S-FKM90)	
G	High pressure for A6VM motor HA control (with O-ring)		DIN 3771	9x2 (N-V80G1)	
L	Flushing (with O-ring)		DIN 3771	9x2 (N-V80G1)	

- ¹⁾ Please observe the general instructions for the max. tightening torques on page 12
- ²⁾ Short-term pressure spikes may occur depending on the application. Please keep this in mind when selecting testers and armatures.
- 3) Only dimensions according to SAE J518
- O = open, must be connected (plugged on delivery)
- X = plugged (in normal operation)

RE 95522/10.08 | BVD Bosch Rexroth AG 9/12

Dimensions, Size 25




- 1) Countersink ø 11x6.5 and through-hole ø 6.6 for 2x M6 mounting screws for fixing the counterbalance valve to the motor. In order to prevent incorrect assembly, the mounting screws must be used (included in the delivery contents)
- 2) Width across flats

Detail X

With shuttle valve and G_{ext} port (code S)

With shuttle valve, brake release valve and Br port (code L)

	B1	B2	В3	B4	ØB5	B6
BVD 2538	84	31.8	66.7	M14x2	15	31.6



Ports

Designa- tion	Operation		Standard	Size 1)	Peak pres- sure (bar) ²⁾	Status
A, B	Service line port, fixing thread A/B	Version 38	SAE J518 ³⁾ DIN 13	1 1/4 in M14x2; 19 deep	420	0
S	Boost port		DIN 3852	M27x2; 16 deep	30	Х
Br	Brake release, reduced high pressure	Version L	DIN 3852	M12x1.5; 12 deep	30	0
G _{ext}	Brake release, high pressure	Version S	DIN 3852	M12x1.5; 12.5 deep	420	Х

O-rings for connection to mounted axial piston motor

		•			
A', B'	Service line port	Version 38	AS 568 A	37.69x3.53 (S-FKM90)	
G	High pressure for A6VI O-rings)	M motor HA control (with	DIN 3771	9x2 (N-V80G1)	
L	Flushing (with O-ring)		DIN 3771	9x2 (N-V80G1)	

¹⁾ Please observe the general instructions for the max. tightening torques on page 12

O = open, must be connected (plugged on delivery)

X = plugged (in normal operation)

²⁾ Short-term pressure spikes may occur depending on the application. Please keep this in mind when selecting testers and armatures.

³⁾ Only dimensions according to SAE J518


Fixing the Counterbalance Valve


When delivered, the counterbalance valve is attached to the motor using 2 tacking screws. Do not remove the tacking screws when connecting the service lines. If the counterbalance valve and motor are delivered separately, the counterbalance valve must first be attached to the motor port plate using the provided tacking screws. In both cases, the final attachment of the counterbalance valve to the motor is by the connectio of the service lines, e.g. using SAE 4-bolt flanges. A total of 6 screws with thread lengths B1+B2+B3 and 2 screws with thread lengths B3+B4 are required.

When tightening the screws, it is imperative that the sequence 1 to 8 (as shown in the adjacent diagram) be adhered to and carried out in two phases.

In the first phase the screws should be tightened to 50% of their tightening torque before being tightened to maximum tightening torque in the second phase (see table below).

Thread	Strength class	Tightening torque in Nm
M10	10.9	75
M12	10.9	130
M14	10.9	205





Axial piston motor	A2FM/E	A2FM/E	A6VM	A2FM/E	A6VM	A2FE	A6VM	A2FM/E	A6VM
NG	28, 32, 45	56, 63	55	80, 90	80	107, 125	107	107, 125, 160, 180	107, 140 160
Dimension B1 ¹)	M10x1.5 17 deep	M10x1.5 17 deep	M10x1.5 17 deep	M12x1.75 18 deep	M12x1.75 15 deep	M12x1.75 17 deep	M12x1.75 15 deep	M14x2 19 deep	M14x2 19 deep
Dimension B2	78 ²)	68	68	68	68	68	68	85	85
Dimension B3	Customer-specific								
Dimension B4	M10x1.5 15 deep	M10x1.5 15 deep	M10x1.5 15 deep	M12x1.75 16 deep	M12x1.75 16 deep	M12x1.75 16 deep	M12x1.75 16 deep	M14x2 19 deep	M14x2 19 deep

¹⁾ Minimum necessary screw insertion depth 1xØ

²⁾ Including intermediate plate

Port Types

	NG20					NG25			
Ordering code	16	17		27		28		38	
Service line port A and B	3/4 in		1 in				1 1/4 in		
Boost port S (plugged)	M22x1.5; 14 deep				M27x2; 16 deep				
Spacing between service line ports (A'-B')	66	66 75			84		84		
For mounting on axial piston motor	A2FM/E	A2FM/E	A6VM	A2FM/E	A6VM	A2FE	A6VM	A2FM/E	A6VM
Size	28, 32, 45	56,63	55	80, 90	80	107, 125	107	107, 125, 160, 180	107, 140, 160
Motor port plate required (with secondary pressure-relief valves, mutual bleed-off)	181	181	380	181	380	171	370	181	380

Cross-References

Mineral oil	RE 90220
Environmentally acceptable hydraulic fluids	RE 90221
HF hydraulic fluids	RE 90223
A2FM	_RE 91001
A2FE	RE 91008
A6VM	RE 91604
Hydrotrac GFT	_RE 77110
Mobilex GFT-W	RE 77502

General Instructions

- The BVD counterbalance valve is designed to be used in open circuits.
- Project planning, assembly and commissioning of the axial piston unit with counterbalance valve require the involvement of qualified personnel.
- The service line ports and function ports are only designed to mounting hydraulic lines.
- During and shortly after operation, there is a risk of burns on the axial piston unit. Take suitable safety measures (e.g. wear protective clothing).
- There may be shifts in the characteristic depending on the operating state of the axial piston unit (operating pressure, fluid temperature).
- The data and note contained herein must be adhered to.
- The following tightening torques apply:
 - Threaded hole in axial piston unit:

 The maximum permissible tightening torques M_{Gmax} are the maximum values for the threaded holes that must not be exceeded.

 For values, refer to the following table.
 - Armatures:
 Observe the manufacturer's instruction regarding tightening torques for the used armatures.
 - Fixing screws:
 For fixing screws according to DIN 13, we recommend checking the tightening torque in individual cases as per VDI 2230.
 - Locking screws:

 For the metallic locking screws supplied with the axial piston unit, the required tightening torques of locking screws M_V apply.

 For values, refer to the following table.

Thread size at ports		Max. permissible tightening torque of the threaded holes M _{Gmax}	Required tightening torque of the locking screws M _V	WAF hexagon socket	
M12x1.5	DIN 3852	50 Nm	25 Nm	6 mm	
M22x1.5	DIN 3852	210 Nm	80 Nm	10 mm	
M27x2	DIN 3852	330 Nm	135 Nm	12 mm	

Bosch Rexroth AG
Hydraulics
Axial Piston Units
Glockeraustraße 2
89275 Elchingen, Germany
Phone: +49-7308-82-0

Fax: +49-7308-72-74 info.brm-ak@boschrexroth.de

www.boschrexroth.com/axial-piston-pumps

© This document, as well as the data, specifications and other information set forth in it, are the exclusive property of Bosch Rexroth AG. It may not be reproduced or given to third parties without its consent.

The data specified above only serve to describe the product. No statements concerning a certain condition or suitability for a certain application can be derived from our information. The information given does not release the user from the obligation of own judgment and verification. It must be remembered that our products are subject to a natural process of wear and aging.

Subject to change.