











VISC+

Model Number


VT18-8-400-M-LAS/32/40a/118


Diffuse mode sensor with 4-pin, M12 x 1 connector

Features


- M18 threaded housing made of brass, nickel plated
- · Visible red light, pulsed LASER light
- Array control panel with highly visible LED display
- Flashing power on LED in case of short-circuit
- Multiple device installation possible, no mutual interference (no cross-talk)
- Not sensitive to ambient light, even with switched energy saving lamps
- Protection class II

Dimensions





Electrical connection



- O = Light on
- = Dark on

Pinout



Technical data General specifications 0 ... 400 mm, adjustable Detection range Detection range min. 0 ... 25 mm 0 ... 400 mm Detection range max Light source laser diode modulated visible red light Light type Laser nominal ratings LASER LIGHT, DO NOT STARE INTO BEAM Note Laser class Wave length 655 nm Beam divergence 31.5 mrad Pulse length $4 \, \mu s$ 11.91 kHz Repetition rate max. pulse energy 4.95 nJ Diameter of the light spot approx. 0.5 mm at a distance of 120 mm Optical face frontal Ambient light limit 30000 Lux Hysteresis < 15 % Н Functional safety related parameters $MTTF_d$ 700 a Mission Time (T_M) 20 a Diagnostic Coverage (DC) 0 % Indicators/operating means Operation indicator LED green, flashes in case of short-circuit Function indicator LED yellow, lights up with receiver lit Detection range adjuster, light/dark switch Control elements **Electrical specifications** Operating voltage U_{B} 10 ... 30 V DC, class 2 No-load supply current < 25 mA I_0 Protection class II, rated voltage ≤ 250 V AC with pollution degree 1-2 according to IEC 60664-1 Output Switching type light/dark on, switchable Signal output 1 PNP output, short-circuit protected, reverse polarity protected, open collector Switching voltage 30 V DC max. 200 mA Switching current Switching frequency 500 Hz Response time 1 ms **Ambient conditions** Ambient temperature -25 ... 55 °C (-13 ... 131 °F) -30 ... 70 °C (-22 ... 158 °F) Storage temperature **Mechanical specifications** Protection degree connector M12 x 1, 4-pin (Vario-Quick quick connect techno-Connection logy) Material brass, nickel-plated Housing Optical face plastic Mass 60 g Compliance with standards and directi-Directive conformity EMC Directive 2004/108/EC Standard conformity Product standard EN 60947-5-2:2007 IEC 60947-5-2:2007 IEC 60825-1:2007 Complies with 21 CFR 1040.10 and 1040.11 Laser class except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007 Approvals and certificates II, rated voltage ≤ 300 V AC with pollution degree 1-2 accor-Protection class ding to IEC 60664-1 **UL** approval cULus Listed, Type 1 enclosure

Accessories

OMH-VL18

Mounting Bracket with swivel nut

BF 18

Mounting flange, 18 mm

BF 18-F

Mounting flange with dead stop, 18 mm

RF 5-30

Universal mounting bracket for cylindrical sensors with a diameter of 5 ... 30 mm

V1-G-2M-PUR

Female cordset, M12, 4-pin, PUR cable


V1-W-2M-PUR


Female cordset, M12, 4-pin, PUR cable

Other suitable accessories can be found at www.pepperl-fuchs.com


CCC approval

CCC approval / marking not required for products rated ≤36 V





Curves/Diagrams




Adjustment

Sensitivity adjustment

- Turn sensitivity adjuster (counterclockwise) to minimum position.
- Place the object to be detected in the sensing range and turn the sensitivity adjuster clockwise until the yellow indication LED lights up. This setting indicates the position A of the sensitivity adjuster.
- · Remove the object. Increase the sensitivity slowly (turning the sensitivity adjuster clockwise) until the yellow LED lights up again. This setting indicates the position B of the sensitivity adjuster.



In case of no background object, the LED won't light up, even in MAX. adjustment. In that case take care, that in normal operation conditions no temporal background object can appear in the sensing range (e. g. parked pallets). If this can not be excluded, place (only for adjustment matter) an object at the appropriate location. Then repeat this adjustment step. After finishing the adjustment this temporal object should be



· For optimal setting, now turn the sensitivity adjuster to the middle position between the positions A and B.

Laser notice laser class 1

- The irradiation can lead to irritation especially in a dark environment. Do not point at people!
- Maintenance and repairs should only be carried out by authorized service personnel!
- Attach the device so that the warning is clearly visible and readable.
- The warning accompanies the device and should be attached in immediate proximity to the device.
- Caution Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

PEPPERL+FUCHS