

Model Number

OBE20M-R101-S2EP-IO-V31-L

Laser thru-beam sensor with 4-pin, M8 x 1 connector

Features

- Miniature design with versatile moun-• ting options
- DuraBeam Laser Sensors durable ٠ and employable like an LED
- IO-link interface for service and pro-• cess data
- Various frequencies for avoiding mutual interference (cross-talk immunity)
- Extended temperature range -40°C ... 60°C
- High degree of protection IP69K ٠

Product information

The R101 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design - from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform

practically all standard automation tasks.

The entire series enables sensors to communicate via IO-Link.


The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.



41.4

Dimensions



18.3


Emitter

Receiver

6

(27.3)

Electrical connection receiver



Pinout



Wire colors in accordance with EN 60947-5-2 (brown (white) (blue) (black)

Receiver 9.85

Emitter

8.8 80

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com


Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com




Indicators/operating means

Emitter



Receiver



1 Operating indicator

1	Light-on/dark-on changeover switch
2	Sensitivity adjuster
3	Operating indicator / light on
4	Signal indicator
5	Operating indicator / dark on



Accessories

V31-WM-2M-PUR Female cordset, M8, 4-pin, PUR cable

V31-GM-2M-PUR

Female cordset, M8, 4-pin, PUR cable

IO-Link-Master02-USB

IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

Other suitable accessories can be found at www.pepperl-fuchs.com

PEPPERL+FUCHS

www.pepperl-fuchs.com

Technical data	
System components	
Emitter	OBE20M-R101-S-IO-V31-L
Receiver	OBE20M-R101-2EP-IO-V31-L
General specifications	
Effective detection range	0 20 m
Threshold detection range	30 m
Light source	laser diode modulated visible red light
Light type Laser nominal ratings	modulated visible red light
Note	LASER LIGHT , DO NOT STARE INTO BEAM
Laser class	1
Wave length	680 nm
Beam divergence	> 5 mrad ; d63 < 2 mm in the range 250 750 mm
Pulse length	1.6 μs max. 17.6 kHz
Repetition rate max. pulse energy	9.6 nJ
Diameter of the light spot	approx. 50 mm at a distance of 20 m
Angle of divergence	approx. 0.3 °
Ambient light limit	EN 60947-5-2 : 30000 Lux
Functional safety related parameters	
MTTFd	440 a
Mission Time (T _M)	20 a 0 %
Diagnostic Coverage (DC) Indicators/operating means	U /0
Operation indicator	LED green:
Operation indicator	constantly on - power on flashing (4Hz) - short circuit
Function indicator	flashing with short break (1 Hz) - IO-Link mode Yellow LED:
	Permanently lit—light path clear Permanently off—object detected Flashing (4 Hz)—operating reserve not reached
Control elements	Receiver: light/dark switch
Control elements	Receiver: sensitivity adjustment
Parameterization indicator	IO link communication: green LED goes out briefly (1 Hz)
Electrical specifications	
Operating voltage U _B	10 30 V DC
Ripple No-load supply current I ₀	max. 10 % Emitter: ≤ 13 mA
No-load supply current I ₀ Protection class	Receiver: ≤ 13 mA at 24 V supply voltage
Interface	
Interface type	IO-Link (via C/Q = pin 4)
Transfer rate	COM 2 (38.4 kBaud)
IO-Link Revision	1.1
Min. cycle time	2.3 ms
Process data witdh	Emitter: Process data output: 2 Bit Receiver: Process data input: 2 Bit Process data output: 2 Bit
SIO mode support	yes
Device ID	Emitter: 0x110402 (1115138) Reciever: 0x110302 (1114882)
Compatible master port type	A
Input	
Test input	emitter deactivation at +U _B
Output Switching type	The switching type of the sonsor is adjustable. The default set
Switching type	The switching type of the sensor is adjustable. The default set- ting is: C/Q - Pin4: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link /Q - Pin2: NPN normally closed / light-on, PNP normally open / dark-on
Signal output	2 push-pull (4 in 1)outputs, short-circuit protected, reverse pola- rity protected, overvoltage protected
Switching voltage	max. 30 V DC
Switching current Usage category	max. 100 mA , resistive load DC-12 and DC-13
Voltage drop U _d	≤ 1.5 V DC
Switching frequency f	1250 Hz
Response time	0.4 ms
Ambient conditions	
Ambient temperature	-40 60 °C (-40 140 °F)
Storage temperature	-40 70 °C (-40 158 °F)
Mechanical specifications	

 Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

 Pepperl+Fuchs Group
 USA: +1 330 486 0001
 Gr

 www.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com
 fa-info@us.pepperl-fuchs.com

330 486 0001 Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com





Laser thru-beam senso	r	0		
Degree of protection	IP67 / IP69 / IP69K			
Connection	M8 x 1 connector, 4-pin			
Material				
Housing	PC (Polycarbonate)			
Optical face	PMMA			
Mass	Emitter: approx. 10 g receiver: approx. 10 g			
Compliance with standards and directi- ves				
Directive conformity				
EMC Directive 2004/108/EC	EN 60947-5-2:2007+A1:2012			
Standard conformity				
Product standard	EN 60947-5-2:2007+A1:2012 IEC 60947-5-2:2007 + A1:2012			
Standards	UL 60947-5-2: 2014 IEC 61131-9:2013 IEC 60825-1:2007 EN 60825-1:2007 EN 61131-9:2013			

Approvals and certificates

UL approval FDA approval $\mathsf{E87056}$, cULus Listed , class 2 power supply , type rating 1 IEC 60825-1:2007 Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007

Curves/Diagrams








4

Functions and Operation



- 1 Light-on / dark-on changeover switch 2 - Sensing range /sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range adjuster for more than 180 degrees.

Sensing Range / Sensitivity

Turn sensing range / sensivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range /sensivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on / dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

Restore Factory Settings

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensivity adjustment is locked. In order to reactivate the sensing range /sensivity adjustment, turn the sensing range / sensivity adjuster for more than 180 degrees.

