





Model Number

RJ15-14-N

Features

• 15 mm inside diameter

Technical Data		
General specifications		
Switching element function		NAMUR, NC
Installation		
Output polarity		NAMUR
Inside diameter		15 mm
Measuring cylinder		9S20K
Diameter		3 mm
Length		6 mm
Nominal ratings		
Nominal voltage	Uo	8.2 V (R _i approx. 1 kΩ)
Operating voltage	UB	5 25 V
Switching frequency	f	0 1500 Hz
Current consumption		
Measuring plate not detected		≥ 3 mA
Measuring plate detected		≤ 1 mA
Functional safety related paramet	ers	
MTTF _d		10800 a
Mission Time (T _M)		20 a
Diagnostic Coverage (DC)		0 %
Ambient conditions		
Ambient temperature		-25 70 °C (-13 158 °F)
Mechanical specifications		
Connection type		cable PVC, 2 m
Core cross-section		0.14 mm ²
Housing material		PBT
Degree of protection		IP67
General information		
Use in the hazardous area		see instruction manuals
Category		2G
Compliance with standards and directives		
Standard conformity		
NAMUR		EN 60947-5-6:2000
		IEC 60947-5-6:1999
Standards		EN 60947-5-2:2007

IEC 60947-5-2:2007


cULus Listed, General Purpose

cCSAus Listed, General Purpose


CSA approval Dimensions

UL approval

Approvals and certificates



Electrical Connection



ATEX 2G

Instruction

Device category 2G

EC-Type Examination Certificate

CE marking

ATEX marking

Directive conformity

Standards

Appropriate type

Effective internal capacitance Ci Effective internal inductance Li

General

Ambient temperature

Installation, Comissioning

Maintenance

Specific conditions

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PTB 99 ATEX 2128 X

€0102

⟨ II 2G Ex ia IIC T6 Gb

EN 60079-0:2009, EN 60079-11:2012 Ignition protection "Intrinsic safety"

Use is restricted to the following stated conditions

RJ15-...-N...

≤ 130 nF; a cable length of 10 m is considered.

 \leq 20 μH ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The temperature ranges, according to temperature class, are given in the EC-Type $\,$ Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.



PEPPERL+FUCHS