SIEMENS

Data sheet 3RB3026-1NB0



OVERLOAD RELAY 0.32...1.25 A FOR MOTOR PROTECTION SIZE S0, CLASS 10 CONTACTOR ASS. MAIN CIRCUIT: SCREW CONN. AUX.CIRCUIT: SCREW CONN. MANUAL-AUTOM.-RESET

product brand name	SIRIUS
Product designation	solid-state overload relay

General technical data:		
Active power loss total typical	W	0.1
Insulation voltage		
 with degree of pollution 3 Rated value 	V	690
Shock resistance		
• acc. to IEC 60068-2-27		15g / 11 ms
Vibration resistance		1-6 Hz, 15 mm; 6-500 Hz, 20 m/s ² ; 10 cycles
Surge voltage resistance Rated value	kV	6
Size of contactor can be combined company-specific		S0
Type of assignment		2
Protection class IP		
• on the front		IP20
• of the terminal		IP20
Type of protection		II (2) G [Ex e] [Ex d] [Ex px] II (2) D [Ex t] [Ex p]
Equipment marking		
• acc. to DIN EN 61346-2		F
• acc. to DIN EN 81346-2		F

Main circuit:		
Number of poles for main current circuit		3
Adjustable response value current of the current- dependent overload release	A	0.32 1.25
Operating voltage		
 at AC-3 Rated value maximum 	V	690

Operating current • at AC-3 — at 400 V Rated value Auxiliary circuit: Number of NC contacts • for auxiliary contacts — Note Number of NO contacts • for auxiliary contacts — Note Number of CO contacts • for auxiliary contacts — Note Number of CO contacts • for auxiliary contacts — Note Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 125 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V A Protective and monitoring functions: Trip class	1.25 1 for contactor disconnection 1 for message "tripped" 0 integrated 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4
at AC-3 — at 400 V Rated value Auxiliary circuit: Number of NC contacts • for auxiliary contacts — Note Number of NO contacts • for auxiliary contacts — Note Number of CO contacts • for auxiliary contacts • for auxiliary contacts • for auxiliary contacts Design of the auxiliary switch Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 125 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V Protective and monitoring functions:	1 for contactor disconnection 1 for message "tripped" 0 integrated 4 4 4 4 3
Auxiliary circuit: Number of NC contacts • for auxiliary contacts — Note Number of NO contacts • for auxiliary contacts — Note Number of CO contacts • for auxiliary contacts • for auxiliary contacts • for auxiliary switch Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 125 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V Protective and monitoring functions:	1 for contactor disconnection 1 for message "tripped" 0 integrated 4 4 4 4 3
Auxiliary circuit: Number of NC contacts • for auxiliary contacts — Note Number of NO contacts • for auxiliary contacts — Note Number of CO contacts • for auxiliary contacts Design of the auxiliary switch Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 125 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V Protective and monitoring functions:	1 for contactor disconnection 1 for message "tripped" 0 integrated 4 4 4 4 3
Number of NC contacts • for auxiliary contacts — Note Number of NO contacts • for auxiliary contacts — Note Number of CO contacts • for auxiliary contacts • for auxiliary contacts Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 120 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 125 V • at 220 V A Protective and monitoring functions:	for contactor disconnection 1 for message "tripped" 0 integrated 4 4 4 3
for auxiliary contacts — Note Number of NO contacts • for auxiliary contacts — Note Number of CO contacts • for auxiliary contacts Pesign of the auxiliary switch Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 125 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 60 V • at 125 V • at 125 V • at 24 V • at 24 V • at 24 V • at 220 V • A Protective and monitoring functions:	for contactor disconnection 1 for message "tripped" 0 integrated 4 4 4 3
Number of NO contacts ● for auxiliary contacts — Note Number of CO contacts ● for auxiliary contacts Design of the auxiliary switch Operating current of the auxiliary contacts at AC-15 ● at 24 V ● at 110 V ● at 125 V ● at 230 V Operating current of the auxiliary contacts at DC-13 ● at 24 V ● at 25 V ● at 25 V ● at 25 V A Operating current of the auxiliary contacts at DC-13 ● at 24 V ● at 25 V ● at 20 V A Protective and monitoring functions:	for contactor disconnection 1 for message "tripped" 0 integrated 4 4 4 3
Number of NO contacts • for auxiliary contacts — Note Number of CO contacts • for auxiliary contacts Design of the auxiliary switch Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 120 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 24 V • at 230 V A Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V A Protective and monitoring functions:	for message "tripped" 0 integrated 4 4 4 3
for auxiliary contacts — Note Number of CO contacts • for auxiliary contacts Design of the auxiliary switch Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 125 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 60 V • at 125 V • at 125 V • at 220 V Protective and monitoring functions:	for message "tripped" 0 integrated 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4
Number of CO contacts • for auxiliary contacts Design of the auxiliary switch Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 120 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 24 V • at 230 V A Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V A Protective and monitoring functions:	for message "tripped" 0 integrated 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4
Number of CO contacts • for auxiliary contacts Design of the auxiliary switch Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 125 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V A Protective and monitoring functions:	o integrated 4 4 4 4 3
for auxiliary contacts Design of the auxiliary switch Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 120 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 24 V • at 230 V A Operating current of the auxiliary contacts at DC-13 • at 60 V • at 110 V • at 125 V • at 220 V Protective and monitoring functions:	integrated 4 4 4 4 3
Design of the auxiliary switch Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 120 V • at 125 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V Protective and monitoring functions:	integrated 4 4 4 4 3
Operating current of the auxiliary contacts at AC-15 • at 24 V • at 110 V • at 120 V • at 125 V • at 230 V Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V Protective and monitoring functions:	4 4 4 4 3
 at 24 V at 110 V at 120 V at 125 V at 230 V Operating current of the auxiliary contacts at DC-13 at 24 V at 60 V at 110 V at 125 V at 220 V Protective and monitoring functions:	4 4 4 3
at 110 V at 120 V at 125 V at 230 V A Operating current of the auxiliary contacts at DC-13 at 24 V at 60 V at 110 V at 125 V at 220 V A Protective and monitoring functions:	4 4 4 3
 at 120 V at 125 V at 230 V A Operating current of the auxiliary contacts at DC-13 at 24 V at 60 V at 110 V at 125 V at 220 V Protective and monitoring functions:	4 4 3
at 125 V at 230 V A Operating current of the auxiliary contacts at DC-13 at 24 V at 60 V at 110 V at 125 V at 220 V A Protective and monitoring functions:	4 3
at 230 V Operating current of the auxiliary contacts at DC-13 at 24 V at 60 V at 110 V at 125 V at 220 V A Protective and monitoring functions:	3
Operating current of the auxiliary contacts at DC-13 • at 24 V • at 60 V • at 110 V • at 125 V • at 220 V A Protective and monitoring functions:	
 at 24 V at 60 V at 110 V at 125 V at 220 V Protective and monitoring functions:	2
 at 60 V at 110 V at 125 V at 220 V A Protective and monitoring functions:	2
at 110 V at 125 V at 220 V A Protective and monitoring functions:	_
at 125 V at 220 V Protective and monitoring functions: A A	0.55
• at 220 V Protective and monitoring functions:	0.3
Protective and monitoring functions:	0.3
	0.11
Trip class	
	CLASS 10
Design of the overload circuit breaker	electronic
UL/CSA ratings:	
Contact rating of the auxiliary contacts acc. to UL	B600 / R300
Short-circuit:	
Design of the fuse link	
for short-circuit protection of the main circuit	
— required	Fuse gG: 6 A
• for short-circuit protection of the auxiliary switch	fuse gG: 6 A
required	
Installation/ mounting/ dimensions:	
mounting position	
Mounting type	any direct mounting

Height	mm	87
Width	mm	45
Depth	mm	84
Required spacing		
with side-by-side mounting		
— forwards	mm	0
— Backwards	mm	0
— upwards	mm	0
— downwards	mm	0
— at the side	mm	0
• for grounded parts		
— forwards	mm	6
— Backwards	mm	0
— upwards	mm	6
— at the side	mm	6
— downwards	mm	6
• for live parts		
— forwards	mm	6
— Backwards	mm	0
— upwards	mm	6
— downwards	mm	6
— at the side	mm	6

Connections/ Terminals:		
Type of electrical connection		
• for main current circuit	screw-type terminals	
 for auxiliary and control current circuit 	screw-type terminals	
Arrangement of electrical connectors for main current circuit	Top and bottom	
Product function		
 removable terminal for auxiliary and control circuit 	Yes	
Type of connectable conductor cross-section		
• for main contacts		
— single or multi-stranded	1x (1 10 mm²), 2x (1 10 mm²)	
 finely stranded with core end processing 	1x (1 6 mm²), 2 x (1 6 mm²), 1x 10 mm²	
 for AWG conductors for main contacts 	1x (16 8), 2x (16 8)	
 for auxiliary contacts 		
— single or multi-stranded	1x (0,5 4 mm²), 2x (0,5 1,5 mm²), 2x (0,75 2, mm²)	,5
— finely stranded with core end processing	1x (0.5 1.5 mm²), 2x (0.5 1.5 mm²), 1x (0.5 2.5 mm²)	
 for AWG conductors for auxiliary contacts 	1x (20 14), 2x (20 14)	

Safety related data:		
Protection against electrical shock		finger-safe
Mechanical data:	_	
Size of overload relay		S0
•		
Communication/ Protocol:		
Protocol is supported		Na
IO-Link protocol Trace of college complete in installation of the college college.		No
Type of voltage supply via input/output link master		No
Ambient conditions:		
Installation altitude at height above sea level	m	2 000
maximum		
Ambient temperature		
during operation	°C	-25 + 60
during storage	°C	-40 +80
during transport	°C	-40 + 80
Relative humidity during operation	%	95
Electromagnetic compatibility:		
EMC emitted interference		
● acc. to IEC 60947-1		CISPR 11, environment B (residential area)
EMI immunity acc. to IEC 60947-1		corresponds to degree of severity 3
Conducted interference due to burst acc. to IEC 61000-4-4		2 kV (power ports), 1 kV (signal ports) corresponds to degree of severity 3
Conducted interference due to conductor-earth surge acc. to IEC 61000-4-5		2 kV (line to earth) corresponds to degree of severity 3
Conducted interference due to conductor-conductor surge acc. to IEC 61000-4-5		1 kV (line to line) corresponds to degree of severity 3
Field-bound parasitic coupling acc. to IEC 61000-4-3		10 V/m
Electrostatic discharge acc. to IEC 61000-4-2		6 kV contact discharge / 8 kV air discharge
Display:		
Display version		
• for switching status		Slide switch
Certificates/ approvals:		

For use in **General Product Approval EMC**















Declaration of Conformity			Shipping App	Shipping Approval	
ϵ	Type Test Certificates/Test Report	Special Test Certificate	OF CONSTRUCTION	10 U V 10 U 10 U 10 U 10 U 10 U 10 U 10	[GL®]
EG-Konf.			ARS	BUREAU	GI

Shipping Approval

other





Environmental Confirmations

Confirmation

Further information

Information- and Downloadcenter (Catalogs, Brochures,...)

http://www.siemens.com/industrial-controls/catalogs

Industry Mall (Online ordering system)

http://www.siemens.com/industrymall

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RB30261NB0

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)

http://support.automation.siemens.com/WW/view/en/3RB30261NB0/all

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...) http://www.automation.siemens.com/bilddb/cax_de.aspx?mlfb=3RB30261NB0&lang=en



