



Model Number

CCB10-30GS55-N1

Features

- 10 mm flush
- The switching distance can be set over a wide range with the potentiometer

Accessories


- BF 30
- Mounting flange, 30 mm

Technical Data			
General specifications			
Switching element function		NAMUR, NO	
Rated operating distance	s _n	10 mm	
Installation		flush	
Output polarity		NAMUR	
Nominal ratings			
Installation conditions			
A		0 mm	
В		0 mm	
С		20 mm	
F		60 mm	
Nominal voltage	Uo	8.2 V (R _i approx. 1 kΩ)	
Operating voltage	UB	5 15 V	
Switching frequency	f	0 50 Hz	
Reverse polarity protection		reverse polarity protected	
Current consumption			
Measuring plate not detected		≤ 1.5 mA	
Measuring plate detected		≥ 2.5 mA	
Switching state indicator		LED, yellow	
Ambient conditions			
Ambient temperature		-20 70 °C (-4 158 °F)	
Mechanical specifications			
Connection type		cable PUR , 2 m	
Core cross-section		0.75 mm ²	
Housing material		Stainless steel 1.4305 / AISI 303	
Sensing face		PTFE	
Protection degree		IP67	
General information			
Use in the hazardous area		see instruction manuals	
Category		1G; 1D	
Compliance with standards and directives			
Standard conformity			
NAMUR		EN 60947-5-6:2000 IEC 60947-5-6:1999	
Standards		EN 60947-5-2:2007 IEC 60947-5-2:2007	

Approvals and certificates

ETL approval CCC approval


Dimensions



cETLus

CCC approval / marking not required for products rated \leq 36 V

Electrical Connection



Refer to "General Notes Relating to Pepperl+Fuchs Product Information"


Pepperl+Fuchs Group www.pepperl-fuchs.com fa Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com





CCB10-30GS55-N1

Installation Conditions



Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2

Capacitive sensor

ATEX 1G

Instruction

Device category 1G

EC-Type Examination Certificate CE marking

ATEX marking

Directive conformity Standards

Appropriate type Effective internal capacitance Ci Effective internal inductance Li General

Highest permissible ambient temperature T6 when Pi = 100 mW, Ui = 15 V, Ii = 30 mA T5 when Pi = 100 mW, Ui = 15 V, li = 30 mA T4 when Pi = 100 mW, Ui = 15 V, Ii = 30 mA T3, T2, T1 when Pi = 100 mW, Ui = 15 V, Ii = 30 mA Installation. Comissioning

Maintenance

Specific conditions Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist BVS 13 ATEX E 074 X €0102

(Ex) II 1G Ex ia IIC T1-T6 Ga

94/9/EG

EN 60079-0:2012, EN 60079-11:2012, EN 60079-26:2007 Ignition protection "Intrinsic safety"

CCB10-30GS55-N1...

< 250 nF ≤ 200 μH

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The 94/9 EC Directive generally applies only to the use of electrical apparatus under atmospheric conditions. When using the apparatus outside atmospheric conditions, a reduction in the per-

missible ignition energy must be taken into account where appropriate.

40 °C (104 °F) 40 °C (104 °F) 80 °C (176 °F)

100 °C (212 °F)

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia.

Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Alternatively, for devices with cable connections, connect the ground wire (yellow/ green) that is connected galvanically to the metal bushing.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



ATEX 1D	
Instruction	Manual electrical apparatus for hazardous areas
Device category 1D	for use in hazardous areas with combustible dust
EC-Type Examination Certificate	BVS 13 ATEX E 074 X
CE marking	C € 0102
ATEX marking	 II 1D Ex ia IIIC T101°C Da
Directive conformity	94/9/EG
Standards	EN 60079-0:2012; EN 60079-11:2012 type of protection intrinsic safety "ia"
Appropriate type	CCB10-30GS55-N1
Effective internal capacitance Ci	≤ 250 nF
Effective internal inductance Li	≤ 200 μH
General	The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!
Permissible ambient temperature range	-20 90 °C (-4 194 °F)
Installation, Comissioning	Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related appara- tus and according to the proof of intrinsic safety. If the apparatus is placed entirely in Zone 20, the supply cable is introduced via a cable duct positioned close by in Zone 20 or 21.
Maintenance	No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. EN 50281-1-2 requirements, including those relating to dust deposits and tempera- tures, must be met.
Specific conditions	
Electrostatic charging	Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. Alternatively, for devices with cable connections, connect the ground wire (vellow/

Alternatively, for devices with cable connections, connect the ground wire (yellow/ green) that is connected galvanically to the metal bushing. If the apparatus is placed entirely in Zone 20, the supply cable must be protected against electrostatic charge using a metal braid or pipe woven into the equipotential bonding.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

