

Electrical connection

Dimensions


Model number

VAA-4E4A-G2-ZA/EA2


G2 flat module 4 inputs (PNP) and 4 electronic outputs

Features

- AS-Interface certificate
- Protection degree IP67
- Addressing jack
- Flat cable connection with cable piercing technique, variable flat cable guide
- Communication monitoring
- Inputs for 2-, 3-, and 4-wire sensors
- Power supply of outputs from the external auxiliary voltage
- Supply for inputs from AS-Interface
- Ground connection (FE) possible
- Function display for bus, ext. auxiliary voltage, inputs and outputs
- Detection of overload on sensor supply
- Detection of output overload



Indicating / Operating means



Release date: 2013-12-12 13:57 Date of issue: 2013-12-12 188848_eng.xml

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group USA: www.pepperl-fuchs.com fa-info@u

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com 1

AS-Interface sensor/actuator module

The VAA-4E4A-G2-ZA/EA2 is an AS-Interface module with 4 Inputs and 4 outputs. Mechanical contacts (e.g. push buttons) as well as 2-, 3- and 4-wire sensors can be connected to the inputs. The outputs are electronic outputs, which can be collectively loaded

The IP67 flat module is ideal for applications in the field. An addressing jack is integrated in

The connection for the sensors/actuators is via M12 x 1 screw connections. An LED is provided on the top of the module, for each channel, to indicate the current switching status. Similarly, an LED is provided to monitor the AS-Interface communication and to indicate that the module has the address 0. LEDs are also provided to indicate AS-Interface vol-

The mounting plate U-G2FF is used as standard for the connection to the AS-Interface

with 24 V DC and 1 A per output.

tage and external power supply.

Technical data

Technical data				
General specifications				
Slave type		Standard slave		
AS-Interface specification		V3.0		
Required master specification		≥ V2.0		
UL File Number		E87056		
Functional safety related parar	neters			
MTTF _d		140 a		
Mission Time (T _M)		20 a		
Diagnostic Coverage (DC)		0 %		
Indicators/operating means				
LED FAULT			red n error or address is 0 ad of sensor power supply or outputs	
LED PWR		AS-Interface voltag		
LED AUX			je U _{AUX} ; LED green	
LED IN LED OUT		switching state (inp		
		Switching state (00	tput); 4 LED yellow	
Electrical specifications Auxiliary voltage (output)		20 30 V DC PEL	V	
Rated operating voltage	U _{AUX}	26.5 31.6 V from		
Rated operating current	l _e		ensors) / max. 220 mA	
Protection class	·e			
Input				
Number/Type			wire sensors (PNP), DC 4-wire sensors (PNP), DC	
Supply		from AS-Interface		
Voltage Current loading capacity		21 31 V ≤ 180 mA (T _B ≤ 40	°C)	
		\leq 140 mA (T _B \leq 60	°C), , overload and short-circuit protect	ted
Input current Switching point		\leq 9 mA (limited internally)		
Switching point 0 (unattenuated)		according to DIN EN 61131-2 (Type 2) ≤ 3 mA		
1 (attenuated)		≥5 mA		
Signal delay		< 2 ms (input/AS-Ir	nterface)	
Signal frequency		≤ 250 Hz	Nonaco,	
Output				
Number/Type			s, PNP, overload and short-circuit proof	
Supply		from external auxiliary voltage U _{AUX}		
Current		2 A per output Sum 4 A ($T_B \le 40^{\circ}$ Sum 3 A ($T_B \le 60^{\circ}$		
Voltage		\geq (U _{AUX} - 0.5 V)		
Programming instructions				
Profile		S-7.F		
IO code		7		
ID code		F		
ID1 code ID2 code		F		
Data bits (function via AS-Interf	200)	⊏ input	output	
D0	ace)	IN1	OUT1	
D1		IN2	OUT2	
D2		IN3	OUT3	
D3			OUT4	
Parameter bits (programmable	via AS-i)	function		
P0		communication monitoring P0 = 1 (basic setting), monitoring = ON, i.e. if communication fails, the outputs are de-energised P0 = 0, monitoring = OFF, if communication fails, the outputs maintain their condition		
P1		not used		
P2 P3		not used		
Ambient conditions		noruseu		
Ambient temperature		-25 60 °C (-13	140 °F)	
Storage temperature		-25 85 °C (-13		
Mechanical specifications			,	
Protection degree		IP67		
Connection		Cable piercing method flat cable yellow/flat cable black inputs/outputs: M12 round connector		
Material		DOT		
Housing		PBT		
Mass Mounting		150 g Mounting base		
Compliance with standards an	d directi	-		
ves				

flat cable and the external 24 V DC supply. The specially designed base enables the user to connect flat cable from both sides. The device incorporates communication monitoring, which switches off power to the outputs if no communication has taken place on the AS-Interface line for longer than 40 ms. An overloading of the internal input supply or of the outputs is signalled to the AS-interface master via the "Peripheral fault" function. Communication via the AS-Interface remains intact.

Note:

Function

the module.

The mounting base for the module is sold separately.

Accessories

VBP-HH1-V3.0-KIT

AS-Interface Handheld with accessory

VBP-HH1-V3.0

AS-Interface Handheld

VAZ-PK-1.5M-V1-G

Adapter cable module/hand-held programming device

VAZ-FK-ED-G2

AS-Interface end seal for G2 modules

Matching system components

U-G2FF

AS-Interface module mounting base for connection to flat cable (AS-Interface and external auxiliary power)

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group w.pepperl-fuchs.com

2

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.co

PEPPERL+FUCHS

Directive conformity
EMC Directive 2004/108/EC
Standard conformity
Noise immunity
Emitted interference
Input
Protection degree
Fieldbus standard

EN 61000-6-2:2001, EN 61000-6-4:2001, EN 50295:1999

EN 61000-6-2:2001 EN 61000-6-4:2001 EN 61131-2:2007 EN 60529:2000 EN 50295:1999, IEC 62026-2:2006

Notes

For 4-wire sensors, it is only possible to use plug-in slot IN1 or IN3 for inputs 1+2 or 3+4 (jumpered internally).

Do not connect inputs and outputs, which are supplied via the module from AS-interface or via auxiliary power, with power supply and signal circuits with external potentials.

Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group

www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

