

Part no. Article no.

Catalog No.

DX-EMC34-030 184502 DX-EMC34-030



Delivery programme

Denvery programme			
Description			three-phase
Mains voltage (50/60Hz)	U _{LN}	V	max. 520 + 10%
Rated operational current	l _e	А	30
For use with			DC1 DA1 DG1
Degree of Protection			IP20
Connection type			Screw terminal, PE stud
Notes			Separate mounting

Technical data General

General		
Standards		EN 50178, IEC 61800-3, EN 61800-3 incl. A11
Environmental conditions		
Altitude	m	Up to 2000 m a.s.l.; observe drating at higher altitudes
Degree of Protection		IP20

Design verification as per IEC/EN 61439

In	А	30
P _{vid}	w	15
P _{vs}	W	0
	°C	-25
	°C	50
		IP20
		Meets the product standard's requirements.
		Meets the product standard's requirements.
		Meets the product standard's requirements.
at		Meets the product standard's requirements.
		Meets the product standard's requirements.
		Does not apply, since the entire switchgear needs to be evaluated.
		Does not apply, since the entire switchgear needs to be evaluated.
		Meets the product standard's requirements.
		Does not apply, since the entire switchgear needs to be evaluated.
		Meets the product standard's requirements.
		Does not apply, since the entire switchgear needs to be evaluated.
		Does not apply, since the entire switchgear needs to be evaluated.
		Is the panel builder's responsibility.
		Is the panel builder's responsibility.
	P _{vid}	P _{vid} W P _{vs} W C C C C C C C C

10.9.2 Power-frequency electric strength	Is the panel builder's responsibility.
10.9.3 Impulse withstand voltage	Is the panel builder's responsibility.
10.9.4 Testing of enclosures made of insulating material	Is the panel builder's responsibility.
10.10 Temperature rise	The panel builder is responsible for the temperature rise calculation. Eaton will provide heat dissipation data for the devices.
10.11 Short-circuit rating	Is the panel builder's responsibility. The specifications for the switchgear must be observed.
10.12 Electromagnetic compatibility	Is the panel builder's responsibility. The specifications for the switchgear must be observed.
10.13 Mechanical function	The device meets the requirements, provided the information in the instruction leaflet (IL) is observed.

Technical data ETIM 6.0

Low-voltage industrial components (EG000017) / Accessories for frequency controller (EC002025)

Electric engineering, automation, process control engineering / Electrical drive / El	ectrical drive (accessorie	es) / Frequency controller (accessories) (ecl@ss8.1-27-02-92-01 [ACN127008])
Type of accessory		Filter

Approvals	
Product Standards	UL 1283
UL File No.	E192040
North America Certification	UL listed, certified by UL for use in Canada

Additional product information (links)

IL04012018Z*.pdf Radio interference suppression filter for PowerXL		
IL04012018Z*.pdf Radio interference suppression filter for PowerXL	ftp://ftp.moeller.net/DOCUMENTATION/AWA_INSTRUCTIONS/IL04012018Z2016_06.pdf	
MN04020005Z DA1 variable frequency drives,	nstallation manual	
MN04020005Z DA1 variable frequency drives, Installation manual - Deutsch	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN04020005Z_DE.pdf	
MN04020005Z DA1 variable frequency drives, Installation manual - English	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN04020005Z_EN.pdf	
MN04020003Z DC1 variable frequency drives, Installation manual		
MN04020003Z DC1 variable frequency drives, Installation manual - Deutsch	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN04020003Z_DE.pdf	
MN04020003Z DC1 variable frequency drives, Installation manual - English	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN04020003Z_EN.pdf	
MN04020003Z DC1 variable frequency drives, Installation manual - čeština	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN04020003Z_CZ.pdf	
MN04020003Z DC1 variable frequency drives, Installation manual - italiano	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN04020003Z_IT.pdf	
MN040002 PowerXL DG1 Series VFD, Installation Manual		
MN040002 PowerXL DG1 Series VFD, Installation Manual - Deutsch	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN040002_DE.pdf	
MN040002 PowerXL DG1 Series VFD, Installation Manual - English	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN040002_EN.pdf	
MN040002 PowerXL DG1 Series VFD, Installation Manual - français	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN040002_FR.pdf	
MN040002 PowerXL DG1 Series VFD, Installation Manual - italiano	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN040002_IT.pdf	
MN040002 PowerXL DG1 Series VFD, Installation Manual - polski	ftp://ftp.moeller.net/DOCUMENTATION/AWB_MANUALS/MN040002_PL.pdf	