**Dimensions** 



CE **OIO**-Link

## **Model Number**

# OBT300-R103-2EP-IO-V31-1T

Triangulation sensor (BGE) with 4-pin, M8 x 1 connector

#### **Features**

- Miniature design with versatile moun-• ting options
- Secure and gapless detection, even ٠ near the surface through background evaluation
- Precision object detection, almost ir-٠ respective of the color
- Extended temperature range -40°C ... 60°C
- High degree of protection IP69K
- IO-link interface for service and process data


#### **Product information**

The R103 series miniature optical sensors are the first devices of their kind to offer an end-to-end solution in a small single standard design - from thru-beam sensor through to a distance measurement device. As a result of this design, the sensors are able to perform practically all standard automation tasks.


The entire series enables sensors to communicate via IO-Link.

The DuraBeam laser sensors are durable and can be used in the same way as a standard sensor.

The use of Multi Pixel Technology gives the standard sensors a high level of flexibility and enables them to adapt more effectively to their operating environment.




## **Electrical connection**







# Indicators/operating means



1	Light-on/dark-on changeover switch
2	Sensing range adjuster
3	Operating indicator / dark on
4	Function indicator
5	Operating indicator / light on



eng.xml

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"

Pepperl+Fuchs Group www.pepperl-fuchs.com

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



UB

# **Technical data** General specifications Detection range Detection range min. Detection range max Adjustment range Reference target Light source Light type LED risk group labelling Black/White difference (6 %/90 %) Diameter of the light spot Angle of divergence Ambient light limit Functional safety related parameters MTTF<sub>d</sub> Mission Time (T<sub>M</sub>) Diagnostic Coverage (DC) Indicators/operating means Operation indicator Function indicator Control elements

Control elements **Electrical specifications** Operating voltage Ripple No-load supply current Protection class Interface Interface type Device profile Transfer rate **IO-Link Revision** Min. cycle time Process data witdh SIO mode support Device ID Compatible master port type Output Switching type

Signal output Switching voltage Switching current Usage category Voltage drop Switching frequency Response time Ambient conditions Ambient temperature Storage temperature **Mechanical specifications** Housing width Housing height Housing depth Degree of protection Connection Material Housing Optical face Mass Compliance with standards and directives Directive conformity EMC Directive 2004/108/EC

5 300 mm
5 25 mm
5 300 mm
25 300 mm
standard white, 100 mm x 100 mm
LED
modulated visible red light
exempt group
< 15 % at 300 mm
approx. 18 mm at a distance of 300 mm
approx. 3 °
EN 60947-5-2 : 40000 Lux
600 a
20 a
0 %
LED green: constantly on - power on flashing (4Hz) - short circuit flashing with short break (1 Hz) - IO-Link mode
LED yellow: constantly on - background detected (object not detected) constantly off - object detected
Light-on/dark-on changeover switch

Light-on/dark-on changeover switch
Sensing range adjuster
10 30 V DC
max. 10 %
< 25 mA at 24 V supply voltage
III
IO-Link ( via C/Q = pin 4 )
Smart Sensor
COM 2 (38.4 kBaud)
1.1
2.3 ms
Process data input 1 Bit Process data output 2 Bit
yes
0x110704 (1115908)
A
The switching type of the sensor is adjustable. The default set- ting is:

	ting is: C/Q - BK: NPN normally open / dark-on, PNP normally closed / light-on, IO-Link /Q - WH: NPN normally closed / light-on, PNP normally open / dark-on
	2 push-pull (4 in 1)outputs, short-circuit protected, reverse pola- rity protected, overvoltage protected
	max. 30 V DC
	max. 100 mA , resistive load
	DC-12 and DC-13
U <sub>d</sub>	$\leq$ 1.5 V DC
f	500 Hz
	1 ms
	-40 60 °C (-40 140 °F)
	-40 70 °C (-40 158 °F)
	15 mm

# Accessories

#### IO-Link-Master02-USB IO-Link master, supply via USB port or separate power supply, LED indicators, M12 plug for sensor connection

V31-GM-2M-PUR Female cordset, M8, 4-pin, PUR cable

#### V31-WM-2M-PUR

Female cordset, M8, 4-pin, PUR cable

Other suitable accessories can be found at www.pepperl-fuchs.com

2

43.9 mm

26.7 mm IP67 / IP69 / IP69K

PMMA

approx. 12 g

M8 x 1 connector, 4-pin

EN 60947-5-2:2007+A1:2012

PC (Polycarbonate)

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



# Standard conformity

Product standard

Standards


EN 60947-5-2:2007+A1:2012 IEC 60947-5-2:2007 + A1:2012 UL 60947-5-2: 2014 IEC 61131-9:2013 EN 62471:2008 EN 61131-9:2013


#### Approvals and certificates


UL approval

E87056 , cULus Listed , class 2 power supply , type rating 1

### **Curves/Diagrams**








Refer to "General Notes Relating to Pepperl+Fuchs Product Information" Pepperl+Fuchs Group www.pepperl-fuchs.com


USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com





#### **Functions and Operation**



- 1 Light-on / dark-on changeover switch
- 2 Sensing range / sensitivity adjuster
- 3 Operating indicator / dark on
- 4 Signal indicator
- 5 Operating indicator / light on

To unlock the adjustment functions turn the sensing range adjuster / sensitivity adjuster for more than 180 degrees.

#### Sensing Range/ Sensitivity

Turn sensing range / sensitivity adjuster clockwise to increase sensing range / sensitivity.

Turn sensing range / sensitivity adjuster counter clockwise to decrease sensing range / sensitivity.

If the end of the adjustment range is reached, the signal indicator starts flashing with 8 Hz.

#### Light-on / Dark-on Configuration

Press the light-on / dark-on changeover switch for more than 1 second (less than 4 seconds). The light-on / dark-on mode changes and the operating indicators are activated accordingly.

If you press the light-on / dark-on changeover switch for more than 4 seconds, the light-on /dark-on mode changes back to the original setting. On release of the light-on / dark-on changeover switch the current state is activated.

### **Restore Factory Settings**

Press the light-on / dark-on changeover switch for more than 10 seconds (less than 30 seconds) until all LEDs turn off. On release of the light-on / dark-on changeover switch the signal indicator turns on. After 5 seconds the sensor resumes operation with factory default settings.

After 5 minutes of inactivity the sensing range / sensitivity adjustment is locked. In order to reactivate the sensing range / sensitivity adjustment, turn the sensing range / sensitivity adjuster for more than 180 degrees.

USA: +1 330 486 0001 fa-info@us.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

